



# **Guardian**

## **User Guide**

## Legal notices

*Information about the Nozomi Networks copyright and use of third-party software in the Nozomi Networks product suite.*

### Copyright

Copyright © 2013-2025, Nozomi Networks. All rights reserved. Nozomi Networks believes the information it furnishes to be accurate and reliable. However, Nozomi Networks assumes no responsibility for the use of this information, nor any infringement of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright, or other intellectual property right of Nozomi Networks except as specifically described by applicable user licenses. Nozomi Networks reserves the right to change specifications at any time without notice.

### Third Party Software

Nozomi Networks uses third-party software, the usage of which is governed by the applicable license agreements from each of the software vendors. Additional details about used third-party software can be found at <https://security.nozominetworks.com/licenses>.

# Contents

|                                               |           |
|-----------------------------------------------|-----------|
| <b>Chapter 1. Introduction.....</b>           | <b>9</b>  |
| Guardian overview.....                        | 11        |
| <b>Chapter 2. Sensors.....</b>                | <b>13</b> |
| List.....                                     | 16        |
| Map.....                                      | 18        |
| Graph.....                                    | 20        |
| Do a force update on sensors.....             | 21        |
| Allow a sensor.....                           | 22        |
| Export a list of sensors.....                 | 23        |
| Upload a map.....                             | 24        |
| Arc sensor configuration.....                 | 25        |
| Execution options.....                        | 25        |
| Traffic monitoring.....                       | 28        |
| Configure an Arc sensor.....                  | 30        |
| <b>Chapter 3. Alerts.....</b>                 | <b>33</b> |
| Standard mode.....                            | 36        |
| Expert mode.....                              | 37        |
| View alerts in standard mode.....             | 38        |
| View alerts in expert mode.....               | 38        |
| Closing alerts.....                           | 39        |
| Actions menu.....                             | 42        |
| Open the Actions menu in standard mode.....   | 44        |
| Open the Actions menu in expert mode.....     | 44        |
| Configure an alert.....                       | 45        |
| Acknowledge an alert.....                     | 46        |
| Close an alert.....                           | 46        |
| Download a trace.....                         | 49        |
| Download a malicious file.....                | 49        |
| Edit a note for an alert.....                 | 50        |
| View a diff from an alert.....                | 52        |
| Navigate from an alert.....                   | 52        |
| Edit a playbook associated with an alert..... | 53        |
| Details page.....                             | 54        |
| <b>Chapter 4. Assets.....</b>                 | <b>57</b> |
| List.....                                     | 59        |
| Diagram.....                                  | 61        |
| Configure an asset.....                       | 62        |
| Generate a PDF report of an asset.....        | 63        |

|                                                                |            |
|----------------------------------------------------------------|------------|
| Navigate from an asset.....                                    | 64         |
| View more details for an asset.....                            | 65         |
| Details page.....                                              | 66         |
| Overview.....                                                  | 68         |
| Sessions.....                                                  | 69         |
| Alerts.....                                                    | 70         |
| Software.....                                                  | 71         |
| Vulnerabilities.....                                           | 72         |
| Variables.....                                                 | 73         |
| Network graph.....                                             | 74         |
| Physical graph.....                                            | 75         |
| Hardware components.....                                       | 76         |
| <b>Chapter 5. Queries.....</b>                                 | <b>79</b>  |
| Data sources.....                                              | 83         |
| Basic operators.....                                           | 86         |
| Commands.....                                                  | 88         |
| Nodes-specific commands reference.....                         | 93         |
| Link-events-specific commands reference.....                   | 95         |
| Functions.....                                                 | 96         |
| Examples.....                                                  | 100        |
| Pie chart.....                                                 | 100        |
| Column chart.....                                              | 100        |
| Where with multiple conditions in OR.....                      | 101        |
| Bucket and history.....                                        | 102        |
| Join.....                                                      | 102        |
| Compute the availability history.....                          | 103        |
| Complex field types.....                                       | 104        |
| <b>Chapter 6. Smart Polling in Guardian.....</b>               | <b>107</b> |
| Plans.....                                                     | 110        |
| Node points.....                                               | 111        |
| Settings.....                                                  | 112        |
| Health.....                                                    | 113        |
| Create a Smart Polling plan.....                               | 114        |
| Edit a Smart Polling plan.....                                 | 116        |
| Add a network node to a Smart Polling plan.....                | 117        |
| Add a node from the Network page.....                          | 119        |
| Edit the run interval of a progressive Smart Polling plan..... | 120        |
| Progressive enablement.....                                    | 121        |
| Enable progressive mode.....                                   | 122        |
| Log level customization.....                                   | 123        |
| View the enriched information history for a node.....          | 124        |
| <b>Chapter 7. Arc in Guardian.....</b>                         | <b>125</b> |
| Architecture.....                                              | 128        |



|                                          |            |
|------------------------------------------|------------|
| Arc in Guardian.....                     | 129        |
| Deployment.....                          | 130        |
| Advanced.....                            | 131        |
| Execution details.....                   | 133        |
| Node points.....                         | 134        |
| <b>Chapter 8. Network.....</b>           | <b>135</b> |
| Nodes.....                               | 138        |
| Configure a node.....                    | 139        |
| Show alerts for a node.....              | 140        |
| Show requested traces for a node.....    | 140        |
| Request a trace for a node.....          | 141        |
| Manage learning for a node.....          | 143        |
| Navigate from a node.....                | 144        |
| Add a node to a Smart Polling plan.....  | 145        |
| Links.....                               | 148        |
| Link events.....                         | 148        |
| Link availability.....                   | 149        |
| Configure a link.....                    | 151        |
| Show alerts for a link.....              | 152        |
| Show requested traces for a link.....    | 152        |
| Request a trace for a link.....          | 152        |
| Show events for a link.....              | 154        |
| Show captured URLs for a link.....       | 154        |
| Manage learning for a link.....          | 155        |
| Navigate from a link.....                | 156        |
| Physical links.....                      | 158        |
| Sessions.....                            | 159        |
| Show requested traces for a session..... | 159        |
| Request a trace for a session.....       | 160        |
| Navigate from a session.....             | 163        |
| Traffic.....                             | 164        |
| Details page.....                        | 165        |
| <b>Chapter 9. Graph.....</b>             | <b>167</b> |
| Network.....                             | 170        |
| Assets.....                              | 173        |
| Physical.....                            | 177        |
| Graph controls.....                      | 181        |
| Layout.....                              | 181        |
| Magic wand.....                          | 183        |
| <b>Chapter 10. Process.....</b>          | <b>185</b> |
| List.....                                | 188        |
| Protocol connections.....                | 189        |
| Settings.....                            | 190        |

|                                          |            |
|------------------------------------------|------------|
| Configure a variable.....                | 191        |
| View the details of a variable.....      | 194        |
| Favorite a variable.....                 | 196        |
| Navigate from a variable.....            | 197        |
| <b>Chapter 11. Reports.....</b>          | <b>199</b> |
| Dashboard.....                           | 202        |
| Management.....                          | 203        |
| Generated.....                           | 206        |
| Scheduled.....                           | 207        |
| Settings.....                            | 208        |
| Create a report.....                     | 209        |
| Generate a report.....                   | 211        |
| Download a report.....                   | 213        |
| Delete a report.....                     | 213        |
| Add a folder.....                        | 214        |
| Edit a folder.....                       | 215        |
| Delete a folder.....                     | 216        |
| Import a schema.....                     | 216        |
| Export a schema.....                     | 217        |
| Upload a custom logo.....                | 218        |
| Configure SMTP settings.....             | 220        |
| Filter a report globally.....            | 222        |
| Add a widget to a report.....            | 225        |
| Filter a report with a widget.....       | 227        |
| <b>Chapter 12. Assertions.....</b>       | <b>229</b> |
| Assertion operators.....                 | 233        |
| Save an assertion.....                   | 234        |
| Edit an assertion.....                   | 237        |
| Configure an assertion.....              | 238        |
| Configure an assertion on links.....     | 239        |
| Configure an assertion on variables..... | 241        |
| <b>Chapter 13. Time machine.....</b>     | <b>245</b> |
| Time machine diffs.....                  | 249        |
| Load a snapshot.....                     | 251        |
| Request a diff.....                      | 252        |
| Reload the diff operation progress.....  | 253        |
| View a diff from an alert.....           | 254        |
| <b>Chapter 14. Vulnerabilities.....</b>  | <b>255</b> |
| Assets.....                              | 258        |
| List.....                                | 259        |
| Stats.....                               | 260        |
| Details page.....                        | 261        |

|                                           |            |
|-------------------------------------------|------------|
| <b>Chapter 15. Administration.....</b>    | <b>263</b> |
| Administration page.....                  | 265        |
| <b>Chapter 16. Personal settings.....</b> | <b>267</b> |
| Other actions.....                        | 270        |
| Change your password.....                 | 271        |
| Edit an OpenAPI key.....                  | 272        |
| Generate an OpenAPI key.....              | 273        |
| Clear your personal settings.....         | 275        |
| Request a continuous trace.....           | 276        |
| Request a custom trace.....               | 277        |
| Show requested traces.....                | 279        |
| Download a requested trace.....           | 280        |
| Zone filters.....                         | 281        |
| Glossary.....                             | 283        |



# Chapter 1. Introduction



## Guardian overview

*Guardian is the main Nozomi Networks sensor.*

### Asset discovery

Guardian gives you the ability to automatically track your *industrial control systems (ICS)*, *operational technology (OT)* and *Internet of Things (IoT)/Industrial Internet of Things (IIoT)* assets.

- Highly accurate asset inventory of all communicating devices
- Extensive node information including name, type, serial number, firmware version and components
- Actionable risk assessment insights including security and reliability alerts, missing patches and vulnerabilities

### Network visualization

Guardian gives you instant visibility of your entire network. This lets you:

- Have instant awareness of your *OT/IoT* networks and normal activity patterns
- Access key data such as traffic throughput, *transmission control protocol (TCP)* connections, and protocols
- Use intuitive dashboards and reports with macro and micro views, plus filtering and grouping

### Automated vulnerability assessment

Guardian lets you quickly identify which *ICS*, *OT* and *IoT* devices are vulnerable. This provides:

- Efficient prioritization and remediation
- A faster response with vulnerability dashboards, drill-downs and reports
- Based on the U.S. government's *National Vulnerability Database (NVD)* for standardized naming, description and scoring

Continuously monitor your networks and automation systems. Guardian gives you:

- The ability to continuously monitor all your assets, network communications and supported protocols
- Easy access to summarized *ICS*, *OT* and *IoT* risk information
- The ability to highlight potential reliability issues, such as unusual process values

### Anomaly-based detection

Guardian builds a baseline of your environment and uses that knowledge to detect threats such as transferred malware, suspicious communications, unwanted operations, or changes to the network.





## Chapter 2. Sensors



The **Sensors** page lets you view all of the sensors that you have in your system.

The **Sensors** page has these three tabs:

- List
- Map
- Graph

# List

The **List** page lets you view all of the sensors that you have in your system.




Figure 1. Sensors list

## Force update

The force update  icon lets you do a force update on the selected sensors.

## Allow/disallow

The allow/disallow  icon lets you allow or disallow sensors.

## Quick search

The quick search field lets you easily do a search on the current page.

## Export

The **Export**  icon lets you export the current list in either *comma-separated value (CSV)* or Microsoft Excel format.

## Download Arc

The **Download Arc** dropdown lets you select, and download, the applicable Arc package for your *operating system (OS)* and architecture.

## Live

The **Live**  toggle lets you change live view on, or off. When live mode is on, the page will refresh periodically.

## Refresh

The **Refresh**  icon lets you immediately refresh the current view.

## Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Information pane

The information pane to the right of the list of sensors shows additional information for the selected sensor.

It also lets you do these actions shown below.

**Table 1. Sensors list actions**

|                                                                                                                       |                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  Allow/Disallow sensor               | After allowing a sensor, this icon shows:  Synchronized data coming from the sensor become part of the Environment of the <a href="#">Central Management Console (CMC)</a> . Alerts coming from the sensor can be seen in the <b>Alerts</b> section. |
|  Focus on sensor                     | Allows to filter out only the sensor chosen data, such as Alerts and Environment.                                                                                                                                                                                                                                                       |
|  Go to sensor                        | Connect to a remote sensor directly from the <a href="#">CMC</a> . Select this to open a new browser tab to the sensor selected login page. The action is hidden if the <a href="#">CMC</a> isn't configured to allow this type of communication between sensors and <a href="#">CMC</a> .                                              |
|  Place in map                      | This action is used to place the sensor on the map.                                                                                                                                                                                                                                                                                     |
|  Toggle version lock               | When locked, the sensor will not automatically update its software.                                                                                                                                                                                                                                                                     |
|  Force update                      | Even if it is locked, the sensor will automatically update its software, with the version installed on the <a href="#">CMC</a> .                                                                                                                                                                                                        |
|  Clear sensor data on this machine | Clear all synchronized data at the <a href="#">CMC</a> received from the selected sensor. Use this in combination with the clearing of the data on the sensor, and you will be able to restart the synchronization between the sensor and the <a href="#">CMC</a> from an empty state                                                   |
|  Delete sensor                     | Clear all data received from the selected sensor and delete it from the list. If the sensor tries to sync with the <a href="#">CMC</a> again, it shows as disallowed in the list.                                                                                                                                                       |

# Map

You can use the **Map** page to upload, and view, a map of the sensors in your environment.




Figure 2. Sensors map

## Info(rmation) pane




Figure 3. Info(rmation) pane

The **Info** pane lets you view information for the related sensor. The *identifier (ID)* of each sensor is used in the map to help you identify it. The marker color of the sensor relates to the risk of its alerts.

In the map view, a red indicator to the right of the sensor's *ID* shows the number of the alerts in the last five minutes. This indicator only shows if there are some alerts for the sensor. If the alerts in last 5 minutes increase, the sensor marker will blink for one minute.

If the site of the sensor has been specified in  > **System** > **General**, it is possible to enable the **Group by site** option, in the bottom right corner of the map view. The sensors with the same site will be grouped to deliver a simpler view of a complex installation.

**Note:**

The sensors map is also available as a widget.

# Graph

The **Graph** page shows a graphical view of all the sensors in you environment.



Figure 4. Sensors graph



## Do a force update on sensors

*If you have disabled auto updates, you can use the force update icon to do a manual update.*

### Procedure


1. In the top navigation bar, select **Sensors**.

**Result:** The **Sensors** page opens.

2. In the top left section, select .

**Result:** A dialog shows.

3. To confirm, select **Yes**.



## Allow a sensor

The allow icon lets you give permission for a new sensor to connect to Central Management Console (CMC).

### Procedure


1. In the top navigation bar, select **Sensors**.

**Result:** The **Sensors** page opens.

2. In the top left section, select the  icon.

**Result:** A dialog shows.

3. To confirm, select **Yes**.



## Export a list of sensors

You can export a list of the sensors from the current view.

### Procedure

1. In the top navigation bar, select **Sensors**.

**Result:** The **Sensors** page opens.


2. In the top right section, select **Export**.

**Result:** A dialog shows.

3. Choose an export format:

**Choose from:**

- Select **CSV** to create a [CSV](#) file
- Select **Excel** to create a Microsoft Excel file



**Result:** The file is created and a **Exported** message shows.

4. To download the file, in the bottom-left of the dialog, select .



### Results

The exported file has been downloaded.

## Upload a map

The **Map** page lets you upload a map of your sensors in your environment.

### Procedure

1. In the top navigation bar, select **Sensors**.  
**Result:** The **Sensors** page opens.
2. In the top right section, select **Map**.  
**Result:** The **Map** page opens.
3. In the top right section, select **Upload map**.
4. Select the image file that you want to upload.


### Results

The map is uploaded.

# Arc sensor configuration

## Execution options

The **Execution options** page lets you configure how Arc collects data, manage detection features, and control network discovery and polling behaviors. You can also set logging levels and adjust specific execution parameters to optimize performance.



Execution options

Execution time [s] ⓘ  
150

Maximum disk space [MB] ⓘ  
200

☒ Local behavior analysis ⓘ  
☒ USB detections  
☒ Discovery  
☒ Local ARP table  
☒ Use static entries ⓘ

☒ Malware detections ⓘ  
☒ Node points  
☒ Smart Polling ⓘ

Log level  
Debug

Figure 5. Execution options

### Execution time

This field lets you set the time that Arc will run to collect data. This is applicable for One-shot and Offline modes.



**Note:**

When this is set to 0, the execution time is interpreted as infinite.

### Maximum disk space

This field lets you control the maximum amount of disk space in [megabyte \(MB\)](#) that will be used for Offline mode.

### Local behavior analysis (Windows only)

This lets you enable/disable Sigma rules for local behavior analysis.

### Malware detections (Windows only)

This lets you enable/disable malware detections based on YARA and [Structured Threat Information Expression \(STIX\)](#) rules. Both rules are applied to every newly-detected non-signed on the host machine's file system.

### USB detections (Windows only)

This lets you enable/disable [universal serial bus \(USB\)](#) detections.

### Node points

This lets you enable/disable the production of node points.

## Discovery

When enabled, this sends out unsolicited lightweight network announcements to discover neighboring nodes.

Discovery uses lightweight protocol-specific broadcast messages to identify network devices. These messages trigger a response from the devices, which includes identity information. The process is repeated at predefined intervals. At each interval, the sensor will identify the suitable network interfaces and send broadcast messages through them to discover devices on each subnetwork connected to the sensor.

## Smart Polling

This lets you enable/disable the execution of Smart Polling strategies from Arc. When enabled, this sends out Smart Polling queries following remote requests coming from Guardian to poll assets that Arc can reach, or assets that have been identified with Discovery.



### Note:

**Smart Polling** requires that a Smart Polling license is enabled upstream.

To force Smart Polling from a specific Arc sensor, even when Guardian was the first to monitor a node, you can use a [command-line interface \(CLI\)](#) command such as: `vi node 192.168.1.1 capture_device arc[1e6a174c]` In this example, `192.168.1.1` is an [internet protocol \(IP\)](#) address of a node you want to poll from a specific Arc sensor. `1e6a174c` are the first eight characters of the Arc sensor [ID](#) that you want to poll the node with. To find that sensor [ID](#), you can select the Arc sensor from the **Sensors** page of your Guardian and read the **ID** field in the right pane. To reset the behavior, you can set the `capture_device` back to the value of the Guardian interface.

## Local ARP table

This lets you enable/disable the ability to use the local table to confirm [media access control \(MAC\)](#) addresses. The **Use static entries** checkbox lets you enable/disable the use of static entries in the table. Static entries are user-defined. You should only use them if they can be trusted.

## Log level

This dropdown lets you select the verbosity level for the log files. The options are:

- Debug
- Info
- Warning
- Error

The logging system options have an increasing level of verbosity, from the least verbose to the most verbose. Error < Warning < Info < Debug.

- Error: Creates a minimalistic log, only unexpected errors are logged
- Warning: Creates extra errors that might show on some [OSs](#), but that are generally considered as acceptable
- Info: Logs relevant successful events, it shows the program's progress (recommended)
- Debug: Logs extra events that are normally useful for debugging purposes. Given its verbosity it is best to activate it only when debugging activities are involved

## Traffic monitoring

The **Traffic monitoring** page lets you track network traffic using either intermittent or continuous modes. You can configure monitoring parameters, manage resource usage, and choose specific network interfaces to optimize performance.

Figure 6. Traffic monitoring

### Enable

This checkbox lets you enable/disable traffic monitoring.

### Enable continuous mode

This checkbox lets you enable/disable continuous mode. For more details, see **Continuous mode**.

Arc uses two different methods for traffic monitoring:

- Intermittent mode
- Continuous mode

### Intermittent mode

This is the default mode, the traffic is monitored, or sniffed, for a duration of 10 seconds at each notify. The purpose of this limitation is to preserve the resources of the host machine, which prevents excessive memory, or *central processing unit (CPU)*, spikes. You can configure these options:

- **Monitoring time [s] per notification**
- **Max packets per notification**
- **Max used Memory (MB)**: this value can be tuned to allow more or less traffic buffering in case the traffic to process exceeds the Arc and network capacity to send it out

### Continuous mode

This mode sniffs traffic continuously from the host's network interface controllers. Depending on the amount of sniffed traffic, continuous mode might utilize more *CPU* and memory on the host. As the traffic is processed upstream, the performance of the remote endpoint is also affected. You can configure:



- **Max used Memory (MB):** this value can be tuned to allow more or less traffic buffering in case the traffic to process exceeds the Arc and network capacity to send it out

### Global BPF filter

This field lets you set a Global BPF filter to apply to all the network interfaces. Filters that are applied to single interfaces will take precedence over the global one.

### Network interface

This dropdown lets you select a network interface to configure. Each network interface can then be enabled, and be tuned with a monitoring filter.

If you add, remove, or edit the network interfaces on the host, Arc does not automatically add it to the list of sniffing interfaces. For example, if you add a new network card, to enable Arc to use it, you should stop Arc, and then start it again.

## Configure an Arc sensor

It is possible to configure an individual Arc sensor directly from the **Sensors** details page for the related sensor.

### Procedure

1. In the top navigation bar, select **Sensors**.

**Result:** The **Sensors** page opens.

2. From the list, select the applicable Arc sensor.

The screenshot shows the Nozomi Guardian interface. The top navigation bar includes the Nozomi logo and a 'Sensors' tab. Below the navigation bar, there's a search bar with 'arc' entered. The main content area is divided into two sections. On the left, a table lists sensors with columns for Type, Hostname, Model, IP, and Health. On the right, a detailed view of a selected sensor is shown, including its ID, IP, Arc version, and various status metrics.

| Type                     | Hostname                 | Model     | IP | Health      |
|--------------------------|--------------------------|-----------|----|-------------|
| MacBook-Pro-14-inch-2021 | MacBook-Pro-14-inch-2021 | ARC/MACOS |    | Good        |
| MacBookPro               | MacBookPro               | ARC/MACOS |    | Unreachable |


**Sensor Details:**

- ID:** 5da7bc58
- IP:**
- Arc version:** v1.9.4\_devel
- # Alerts (5m):** 0
- # Alerts:** 0
- Risk (5m):**
- Stale:** No
- Last sync:** 16:02:31.646
- Uptime:** 1d 2h 4m 54s
- Resources usage:**
  - RAM: 54%
  - Disk: 35%
  - CPU: 12%
  - Arc CPU: 0%
  - Arc RAM: 0%
- Is version locked:** No
- Is updating:** No
- Type:** Arc

3. In the top right section, select the  icon.

**Result:** A dialog shows.

#### 4. Choose the applicable options.



The screenshot shows the 'Configure Arc' dialog box with the following settings:

- Execution options**
  - Execution time [s]: 150
  - Maximum disk space [MB]: 200
  - ☒ Sigma rules
  - ☐ USB detections
  - ☒ Discovery
  - ☒ Local ARP table
  - ☒ Use static entries
  - ☒ VARA rules
  - ☒ Node points
  - ☒ Smart Polling
- Log level**
  - Debug
- Traffic monitoring**
  - ☐ Enable

Buttons at the bottom: **Save** (blue) and **Restore default** (red).

#### 5. Select **Save**.

### Results

The Arc sensor has been configured.




## Chapter 3. Alerts



The **Alerts** page shows all the latest alerts in the system. It lets you view the alerts in different modes, and carry out actions on the alerts.

**Important:**

To perform actions on alerts, the user must belong to a group with admin permissions. Non-admin users can access alerts only if at least one of the groups that they belong to has alerts permission enabled.



**Figure 7. Alerts page menu**

The top right section of the **Alerts** page has two icons that let you change between these two options:

- [Standard mode \(on page 36\)](#)
- [Expert mode \(on page 37\)](#)

# Standard mode

You can view alerts in standard mode to give you an overview of the latest anomalies.




Figure 8. Standard mode

## Risk

This shows the risk associated to each alert or incident.

## Time

The time related to each event.

## Name

The name category of the event.

## Description

This shows a detailed description of the related event.

## Analysis

If you can select a row, this pane will show a more detailed analysis of the alert.



## Expert mode

You can view alerts in expert mode to give you a detailed view of the alerts in the system. This lets you filter, sort, and analyze the information in detail.

Expert mode shows a comprehensive table layout, with details on the alerts and incidents listed, which include:

- Addresses
- Labels
- The roles of the involved nodes, zones, protocol, and ports used in the involved transactions, and more

| ACTIONS ... | RISK | TIME                    | ID       | TYPE ID               | COUNT... | DESCRIPTION                                     | PROTOC... | IP SRC | IP DST |
|-------------|------|-------------------------|----------|-----------------------|----------|-------------------------------------------------|-----------|--------|--------|
| ...         | 7    | 2023-08-14 14:00:22.620 | 9b3c82c8 | SIGNMALFORMED-TRAFFIC | 1        | The IP layer has no data.                       |           |        |        |
| ...         | 7    | 2023-08-07 09:43:38.648 | 29f83285 | SIGNMALFORMED-TRAFFIC | 1        | The IP layer has no data.                       |           |        |        |
| ...         | 7    | 2023-08-02 14:30:45.633 | 8a34431b | SIGNMALFORMED-TRAFFIC | 1        | Invalid IP packet: IP header length is small... |           |        |        |

Figure 9. Expert mode

### Export

The **Export**  icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

### Group by incident

The **Group by incident**  icon lets you group alerts by incident. This will show incidents and hides all the alerts that belong to them.

### Filter

The filter  icon opens a list of items that you let you filter the results.

### Live

The **Live**  toggle lets you change live view on, or off. When live mode is on, the page will refresh periodically.

### Refresh

The **Refresh**  icon lets you immediately refresh the current view.

### Count by field

The **Σ Count by field** dropdown lets you select a data field on which to group and count the alerts.

### Column selection

The columns selection  icon lets you choose which columns to show or hide.

## View alerts in standard mode

*You can view alerts in standard mode to give you an overview of the latest anomalies.*

### Procedure

1. In the top navigation bar, select **Alerts**.

**Result:** The **Alerts** page opens.

2. In the top right corner, select the standard mode  icon.

**Result:** The [Standard mode \(on page 36\)](#) view opens.

## View alerts in expert mode

*You can view alerts in expert mode to give you a detailed view of the alerts in the system. This lets you filter, sort, and analyze the information in detail.*

### Procedure

1. In the top navigation bar, select **Alerts**.


**Result:** The **Alerts** page opens.

2. In the top right corner, select the expert mode  icon.

**Result:** The [Expert mode \(on page 37\)](#) view opens.

## Closing alerts

When you close an alert, or incident, a dialog lets you select a reason, and specify the learning process.



Closing 0 incident(s) and 1 alert(s)

Reason for closing

Choose a reason ▼

- This is an incident
- This is a change
- Custom reason

Comment

Comment

Ok Cancel

Figure 10. Alerts closing dialog

The **Reason for closing** dropdown has these options:

- **This is a change:** If the cause of the alert is an intended change to the network, such as:
  - A new computer being attached
  - New communication between two nodes that were not previously communicating

Guardian can learn the change that has been detected as part of the environment baseline. When you close an alert in this way, the [intrusion detection system \(IDS\)](#) is instructed to learn the related objects. For example, when a **VI : NEW-NODE** alert is closed as a change, Guardian registers that the corresponding node is part of the environment and will not raise subsequent **VI : NEW-NODE** alerts about the same node.

- **This is a change:** If the cause of the alert is an intended change to the network, such as a new computer being attached, or a new communication between two nodes that were not talking before, the change detected by Guardian can be learned as part of the environment baseline. When closing an alert in this way, the IDS is instructed to learn the corresponding objects. For example, when a **VI:NEW-NODE** alert is closed as a change, Guardian registers that the corresponding node is part of the environment and will not raise subsequent **VI:NEW-NODE** alerts about the same node.

- **This is an incident:** If the cause of the alert is a configuration error, an attack, a malfunctioning device, or other security incident, the change is not learned as part of the environment baseline. When closing an alert in this way, the IDS is instructed to delete the corresponding objects. For example, a new node entering the network for the first time causes a VI:NEW-NODE alert. If an alert closes as an incident, reference to the new node is deleted. The VI:NEW-NODE alert is raised again in subsequent communication involving the same node.
- **Custom reason:** This lets you write a custom reason for closing an alert. You can enter a text string as the closing reason, with a request to apply one of the two described behaviors.

You are about to close 0 incident(s) and 1 alert(s) ×

Reason for closing

Custom reason ▼

Custom reason

New controller installed

☐ Treat as incident

New incidents/alerts will be generated if a similar event happens again.

☒ Learn

Learn the change, no new incidents/alerts will be generated if a similar event happens again.

Comment

Team C will be responsible for the maintenance

Ok

Cancel

**Figure 11. Closing alert for custom reason with comment**

You can add a comment so that it shows in the **alert audit** log.

|                       |                                                                                                                             |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Environment           | Audit alert operations                                                                                                      |
| <b>Audit timeline</b> |                                                                                                                             |
| a day ago             | <b>Acknowledged</b> by John Smith                                                                                           |
| 2 days ago            | <b>Closed as a change - New controller installed</b> by Jane Doe<br><i>«Team C will be responsible for the maintenance»</i> |

Figure 12. Audit alert operations

## Actions menu

The **Actions** menu gives you access to all the actions that you can do for the related alert.




Figure 13. Actions menu



### Note:

The options available in the **Actions** menu can change. The options will depend on:

- The type of alert
- The state of the sensor
- Whether the sensor is a Guardian or a [CMC](#)

### Configure alert

You can use the **Configure alert** option to create a new alert rule for future events that are similar to the current one.

### Ack/Unack

Once an alert or incident shows, you can mark it as acknowledged. You can also change the status back to unacknowledged again.

### Close

Once an alert or incident has been addressed, you can mark it as closed, and choose the type of learning operation to perform.

### Download trace

If a trace is available, you can choose to download it. The trace contains the packet that triggered the alert, along with an extract of the same session before and after that packet. Traces might be unavailable if the appliance is under stress. For detections that require multiple packets, such as **Multiple login failures**, the trace might not contain enough traffic to reproduce the alert. Incidents do not have an associated trace.

### Download file causing the alert

Once a sensor has detected a malicious file, it is possible to download it for analysis. After you select this option, a dialog shows to warn the user that the file has been identified as malicious, or unwanted. To download the file, the user must acknowledge that they will do so at their own risk. In a [CMC](#), this option is only available after the applicable file has been requested, (see below).

### Edit note

Once an alert or incident shows, you can write a note for it, or edit an existing one.

### Time machine diff

It is possible to open a time machine diff which corresponds to the time of the alert, or incident.

### Navigate

Alerts and incidents have related nodes, links, vulnerabilities, or sessions. The **Actions** menu lets you navigate to these links.

## Open the Actions menu in standard mode

You can open the **Actions** menu to give you access to additional operations. When you are in standard mode, there are two different options available to open the menu.

### Procedure

1. [View alerts in standard mode \(on page 38\)](#).
2. Choose a method to open the **Actions** menu.

#### Choose from:

- Select the applicable alert, go to the top right corner and select the **...** icon
- Select the **Open details** button. In the detailed view window, go to the top left corner and select the **...** icon

**Result:** The **Actions** menu opens.

## Open the Actions menu in expert mode

You can open the **Actions** menu to give you access to additional operations.

### Procedure

1. [View alerts in expert mode \(on page 38\)](#).
2. Choose a method to open the **Actions** menu.

#### Choose from:

- To the left of the applicable alert, select the **...** icon
- Select the link in the **ID** column. In the detailed view window, go to the top left corner and select the **...** icon

**Result:** The **Actions** menu opens.



## Configure an alert

You can use the **Configure alert** option to create a new alert rule for future events that are similar to the current one.

### Procedure

1. Open the **Actions** menu for the selected alert(s) with one of the these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)
2. Select **Configure alert**.

**Result:** A dialog shows.

Configure alert

On alerts matching with:

☒ Source IP [IP examples](#) 10.41.132.163

☒ Source MAC 88:66:5a:3d:85:c0

☐ Match IPs and MACs in both directions

☒ Source Zone Undefined

☐ Source Port 52237

☒ Type ID SIGN-MALWARE-DETECTED

☒ Protocol http

☒ Destination IP [IP examples](#) 52.216.81.251

☒ Destination MAC 00:09:0f:09:00:06

☒ Destination Zone Internet

☐ Destination Port 80

☒ Trigger ID 6fd2eec6-1aab-4db0-a891-c1474693d83d

Note

Execute action:

Mute Mute until Change Security Profile visibility Change risk Change trace filter Assign Playbook

ON OFF

Priority

Highest: "muting" takes priority over all other possible rules matching to the same filter.

Save Cancel

3. In each of the fields, enter the necessary details.
4. Select **Save**.

### Results

The alert has been configured.

## Acknowledge an alert

*Once an alert or incident shows, you can mark it as acknowledged. You can also change the status back to unacknowledged again.*

### Procedure

1. Open the **Actions** menu for the applicable file with one of the these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)
2. Select **Ack/Unack**.

**Result:** After a few seconds, the tick symbol changes from grey to green.
3. If necessary, click the **Ack/Unack** option again to cancel the acknowledgment.

**Result:** After a few seconds, the tick symbol changes from green to grey.

## Close an alert


*Once an alert or incident shows, you can mark it as closed, and choose the type of learning operation to perform.*

## Procedure

1. Open the **Actions** menu for the applicable file with one of these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)

2. Select **Close**.

**Result:** A dialog shows.



Closing 0 incident(s) and 1 alert(s)

**Reason for closing**

Choose a reason ▼

- This is an incident
- This is a change
- Custom reason

**Comment**

Comment

Ok Cancel

3. In the **Reason for closing** dropdown, choose one of these options:

**Choose from:**

- **This is a security incident**
- **Custom reason**

4. If you chose **Custom reason**, the dialog will extend to show more options.

Closing 0 incident(s) and 1 alert(s) ✕

Reason for closing

Custom reason ▼

Custom reason

Specify the reason

☐ **Treat as incident**

New incidents/alerts will be generated if a similar event happens again.

☐ **Learn**

Learn the change, no new incidents/alerts will be generated if a similar event happens again.

Comment

Comment

Ok

Cancel

5. If you chose **Custom reason**, do the steps that follow.
- In the **Custom reason** field, enter the details as necessary.
  - Choose from one of these options:
    - **Treat as incident**
    - **Learn**
6. If necessary, enter a comment in the **Comment** field.
7. Select **Ok**.

## Download a trace

*If a trace is available, you can choose to download it. The trace contains the packet that triggered the alert, along with an extract of the same session before and after that packet. Traces might be unavailable if the appliance is under stress.*

### Procedure

1. Open the **Actions** menu for the applicable file with one of the these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)
2. Select **Download trace**.

**Result:** The file downloads to your downloads folder.

## Download a malicious file


*Once a sensor has detected a malicious file, it is possible to download it for analysis.*

### About this task


Only qualified personnel should download malicious files. Before you do this procedure, make sure that you have the correct permissions.

### Procedure

1. Open the **Actions** menu for the applicable file with one of the these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)
2. Select **Download file causing the alert**.



**Result:** A dialog shows.




3. If you want to proceed, select **Yes**.

**Important:**

Nozomi Networks recommends that only qualified personnel download malicious, or unwanted, files. Download these files at your own risk.

**Result:** The file downloads to your downloads folder and a password dialog that contains a randomized, single-use password shows.




4. Copy the password, and select **Ok**.

5. Go to the folder where the file was downloaded to.

6. Double-click the [ZIP](#) file to open it.

**Result:** A dialog that prompts you to enter a password shows.



7. Paste the password into the password field and select **OK**.

**Result:** You can now access the file.

## Edit a note for an alert

*Once an alert or incident shows, you can write a note for it, or edit an existing one.*

### Procedure

1. Open the **Actions** menu for the applicable file with one of the these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)

2. Select **Edit note**.

**Result:** A note is opened with the identification of the related alert, or incident.

3. In the text field, write a note.

**Note:**

There is a character limit of 1000 characters.

4. Select **Save**.

**Results**

The note has been edited.

## View a diff from an alert

*This automatic feature will use the previous and subsequent snapshots according to the time of the alert.*

### Procedure

1. In the top navigation bar, select **Alerts**.

**Result:** The **Alerts** page opens.

2. Choose a method to open the actions menu.

**Choose from:**

- In the table, select the hyperlink to open the details page. Select **Actions**
- In the table, select the  icon

3. Select **Time machine diff**.

**Result:** The time diff shows.

4. To see more details on the right side of the graph, select the applicable node or link.

## Navigate from an alert

*Alerts and incidents have related nodes, links, vulnerabilities, or sessions. The actions menu lets you navigate to these links.*

### Procedure

1. Open the **Actions** menu for the applicable file with one of the these options:
  - [Open the Actions menu in standard mode \(on page 44\)](#)
  - [Open the Actions menu in expert mode \(on page 44\)](#)

2. Click the **Navigate** option.

**Result:** A dialog shows.

Go to [29ae764c-4328-4372-93d8-df93b22cc184](#) [source Node]

Go to [29ae764c-4328-4372-93d8-df93b22cc184 / Any / Any](#) [Link]

Go to [Any / 29ae764c-4328-4372-93d8-df93b22cc184 / Any](#) [Link]

Go to [29ae764c-4328-4372-93d8-df93b22cc184](#) [Vulnerabilities]

Go to [29ae764c-4328-4372-93d8-df93b22cc184 / Any / Any](#) [Sessions]

Go to [Any / 29ae764c-4328-4372-93d8-df93b22cc184 / Any](#) [Sessions]

3. Select the desired link.



## Edit a playbook associated with an alert

A playbook associated with an alert can be modified. A change you make on the playbook only affects the playbook related to that specific alert.

### About this task

You can edit a playbook associated with an alert from the **Playbook** tab in the **Alerts** page.

### Procedure

1. In the top navigation bar, select **Alerts**.

**Result:** The **Alerts** page opens.

2. Find the alert on which to edit the assigned playbook.
3. Select the alert, then select **Playbook** at the bottom of the screen.
4. To edit the playbook, select **Edit**.




Figure 14. Playbook tab

5. Edit the playbook as necessary.
6. Select **Save**.




#### Note:

The playbook template from which the alert playbook was generated remains unchanged, as do all other alert playbooks generated from the same playbook template.

## Details page

The **Alerts** details page provides a comprehensive view of a triggered alert, including cause, context, and recommended response. It displays communication paths, affected nodes, and relevant MITRE ATT&CK tactics. Use this page to investigate incidents and track alert handling activity.



### What happened

Shows a summary and a list of key details for the related alert.

### Possible cause

Shows a possible cause of the alert.

### Suggested solution

Our recommendation on the best way to solve the problem.

### Environment

Shows a graph with the logical connections for the related nodes. The **Selection info** section shows all the applicable information for the alert. It also gives you access to the actions menu.

### Alert Path

The **Alert Path** view displays the physical connection path between source and destination devices involved in a triggered alert. This path is traced at the cable level, including intermediate switches and any other devices connected along the route. The alert path shows with a red line.

This view helps users assess the potential impact of response actions, such as disabling a specific switch port to isolate a device. By identifying additional assets that share the same physical infrastructure, operators can evaluate containment strategies and take targeted action directly from the alert interface.

### Audit alert operations

The **Audit alert operations** section shows a timeline of user or system actions taken on a specific alert. This section helps you track how an alert is handled throughout its lifecycle.

It records these types of activity:

- Acknowledgement of the alert
- Escalation of the alert to an incident
- Changes to the alert's severity or classification
- Notes or comments that were added
- Automatic responses or triggered workflows, if the system is integrated with them

### MITRE ATT&CK Enterprise

The **MITRE ATT&CK for ICS** section helps security analysts understand how the current alert maps to known tactics and techniques used by threat actors in *ICS* environments.

This section shows which tactics from the MITRE ATT&CK for ICS framework are relevant to the alert. The tactics represent different stages of an attack lifecycle, such as:

- Initial Access
- Execution
- Persistence
- Evasion
- Discovery
- Lateral Movement
- Collection
- Command and Control
- Inhibit Response Function
- Impair Process Control
- Impact

Each tactic can display one or more techniques observed in the alert. This mapping helps analysts determine the attacker's goals and possible next steps.



## Chapter 4. Assets



The **Assets** page shows all the physical components and systems in the local network environment and their associated details. It also lets you perform actions on those assets. Depending on the nodes and components involved, assets can range from a simple personal computer to an operational technology (OT) device.

The top right section of the **Assets** page has these two tabs:

- [List \(on page 59\)](#)
- [Diagram \(on page 61\)](#)

## List

The **List** page shows all the assets in table format.

Assets

Page 1 of 6,131 entries

Export Confirmed MACs only ☒ Live ☒ 22 selected

| ACTIONS | CAPTURE DEVI... | NAME                        | TYPE     | OS/FIRMWARE                           |
|---------|-----------------|-----------------------------|----------|---------------------------------------|
|         | eml             | iPhone-67.local             | -        | 192.168.68.116                        |
|         | eml             | iPad-7.local                | -        | 192.168.0.142                         |
|         | eml             | Surface_Pro_8.local         | -        | fe80:e2bba057b9d                      |
|         | eml             | CHPs-AirPort-Express.local  | -        | <a href="#">[multiple]</a>            |
|         | eml             | 192.168.69.51               | -        | 192.168.69.51                         |
|         | eml             | BRWA8934A93B2DC.local       | -        | fe80:aa93:4aff:fe93:t                 |
|         | eml             | fe80:1ccb:5916:8319:7142    | -        | fe80:1ccb:5916:8319:7                 |
|         | eml             | Naymis-iPhone.local         | -        | 10.0.1.18                             |
|         | eml             | Craigs-Mac-Studio.local     | -        | fe80:48bc:97a:b04e                    |
|         | eml             | iPad.local                  | -        | fe80:14ab:4e7:4c9d                    |
|         | eml             | Craigs-iPhone-13-mini.local | -        | 192.168.69.12                         |
|         | eml             | iPad.local                  | -        | fe80:1cd4:a715:cbe4                   |
|         | eml             | 192.168.68.69               | -        | 192.168.68.69                         |
|         | eml             | Craigs-Mac-Studio.local     | computer | 10.0.1.9                              |
|         | eml             | 192.168.68.58               | -        | 192.168.68.58                         |
|         | eml             | Naymis-iPhone.local         | -        | fe80:106b:c3d1:a01a                   |
|         | eml             | DESKTOP-QIASE9Q.local       | -        | fe80:1b07:ebc0:307e                   |
|         | eml             | MACBOOKPRO-CACB             | computer | Windows XP <a href="#">[multiple]</a> |

## Export

The **Export** icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

## Confirmed MACs only

The **Confirmed MACs only** ☒ toggle lets you select only assets that have a confirmed [MAC](#) address.

## Live

The **Live** ☒ toggle lets you change live view on, or off. When live mode is on, the page will refresh periodically.

## Refresh

The **Refresh** icon lets you immediately refresh the current view.

## Column selection

The columns selection  icon lets you choose which columns to show or hide.



## Diagram

The **Diagram** page uses the Purdue model format to display the assets. Assets are shown in separate rows, according to their level.




Figure 15. Diagram page

### Search bar

The search bar lets you search for a specific item.

### Live

The live ☒ toggle lets you immediately refresh the graph.

### Refresh

The refresh  icon lets you immediately refresh the graph.

### Levels section

The levels section shows an icon for each asset, and shows on which level of the Purdue model it is.

### Selection info

When you select the link below an asset's icon, the **Selection info** pane shows more details for the selected asset.

## Configure an asset


The **Lists** page lets you configure assets.

### Procedure

1. In the top navigation bar, select **Assets**.

**Result:** The **Assets** page opens.

2. In the Actions column, to the left of the applicable asset, select the  icon.



3. From the dropdown, select the applicable type.
4. Select **Save**.

### Results

The asset has been configured.

## Generate a PDF report of an asset

The **Lists** page lets you generate a report in portable document format (PDF).

### Procedure

1. In the top navigation bar, select **Assets**.


**Result:** The **Assets** page opens.

2. In the Actions column, to the left of the applicable asset, select the  icon.

**Result:** A dialog shows.

3. **Optional:**

If necessary, select the **Include installed software found with Smart Polling** checkbox.



The dialog box is titled "Generate PDF" and has a close button (X) in the top right corner. The main text inside says "You can find the report in the generated report section once it's been generated". Below this text is a checkbox labeled "Include installed software found with Smart Polling". At the bottom right of the dialog are two buttons: "Save" (in blue) and "Cancel" (in white with a grey border).

4. Select **Save**.

**Result:** The *portable document format (PDF)* file generates in the background.  
When it is ready, you can view it on the **Reports** page.

5. To view the report, go to **Reports > Generated**.

## Navigate from an asset

The **Lists** page lets you use hyperlinks to navigate to entities that are related to an asset.

### Procedure

1. In the top navigation bar, select **Assets**.

**Result:** The **Assets** page opens.

2. In the Actions column, to the left of the applicable asset, select the  icon.

**Result:** A list of related entities shows.

3. Select the hyperlink that you want to navigate to.

Go to [fe80::14ab:4e17:4c9d:84e9](#) [Node]

Go to [mdns](#) [Protocol]

Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Link]

Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Link]

Go to [fe80::14ab:4e17:4c9d:84e9](#) [Vulnerabilities]

Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Sessions]

Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Sessions]

### Results

The entity shows in the applicable page.

## View more details for an asset

Both the **Lists** and **Diagrams** pages lets you view more details for a specific asset.

### Procedure

1. In the top navigation bar, select **Assets**.

**Result:** The **Assets** page opens.

2. In the top right section, select either **List** or **Diagram**
3. Choose a method to view more details for an asset:

**Choose from:**

- If you chose the **List** page, in the **NAME** column for the applicable asset, select the hyperlink
- If you chose the **Diagram** page, below the applicable asset, select the hyperlink

### Results

The [Details page \(on page 66\)](#) for the asset shows.

## Details page

The details page lets you view more detailed information for an assets.




Figure 16. Asset details page

This details page shows more details for an asset.

The top section of the screen contains generic data. You can hover your mouse over the information **i** icon to display the source, granularity and confidence of the corresponding piece of data. Data includes:

- **IP** (address)
- Roles
- Vendor
- **MAC** address
- **MAC** vendor

The details window has these tabs:

- Overview (on page 68)
- Sessions (on page 69)
- Alerts (on page 70)
- Software (on page 71)
- Vulnerabilities (on page 72)
- Variables (on page 73)
- Network graph (on page 74)
- Physical graph (on page 75)
- Hardware components (on page 76)

## Information icon

When you hover over the **i** icon, you can see information for:

- Source
- Granularity
- Confidence

## Source

| Information source | Description                                               |
|--------------------|-----------------------------------------------------------|
| manual             | Information that is manually added from the configuration |
| imported data      | Imported information                                      |
| passive detection  | Information from deep packet inspection                   |
| asset-kb           | Information from Asset Intelligence                       |
| smart-polling      | Information from Smart Polling                            |

## Granularity

| Level of detailed information | Description                                             |
|-------------------------------|---------------------------------------------------------|
| manual-or-import              | Information manually added or imported                  |
| complete                      | Detailed information that has been extracted            |
| partial                       | Detailed, but not complete information                  |
| generic                       | A family/generic value is found, but it is not detailed |
| unknown                       | Unknown                                                 |

## Confidence

| Level of confidence in information | Description                                                                                |
|------------------------------------|--------------------------------------------------------------------------------------------|
| manual-or-import                   | Information manually added or imported, with the highest level of confidence at this level |
| high                               | High level of confidence                                                                   |
| good                               | Good level of confidence                                                                   |
| low                                | Low level of confidence                                                                    |
| unknown                            | Unknown confidence                                                                         |

## Overview

The **Overview** page shows a general overview of information for items such as network statistics and location, protocols, and learning status for the related assets.




Figure 17. Overview tab

### Network Stats

This shows useful statistics for the network activity for the related device.

### Network Location

This shows information for the location for the related device on the network.

### Properties

This shows additional information for the related device.

### Protocols

This shows information for the different protocols that the related device uses.

### Learning status

This shows the learning status of the related asset.

### Security

This shows the security status of the related asset.



## Sessions

The **Sessions** page shows detailed information for communication sessions between devices.

| Acti... | Status | From           | To             | Protoco... | Transport proto... | From por... | To port... | Throughpu... | Transferred byte... | Transferred packet... | First activit... | Last activity |
|---------|--------|----------------|----------------|------------|--------------------|-------------|------------|--------------|---------------------|-----------------------|------------------|---------------|
|         | ACTIVE | 192.168.231.71 | 172.22.0.13    | http       | tcp                | 59959       | 80         | 0.0 b/s      | 706.0 B             | 2 pp                  | 11:35:44.703     | 11:35:44.703  |
|         | CLOSED | 172.22.0.13    | 192.168.231.71 | http       | tcp                | 80          | 59959      | 0.0 b/s      | 71.0 B              | 1 pp                  | 11:32:53.286     | 11:32:53.491  |

Figure 18. Sessions tab

### Export

The **Export** icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

### Live / refresh

The **Live** icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection icon lets you choose which columns to show or hide.

## Alerts

The **Alerts** page shows detailed information for all the alerts that have been raised for the related assets.




Figure 19. Alerts tab

### Export

The **Export**  icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

### Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Software

The **Software** page shows a list of software applications that are installed on the related assets.




Figure 20. Software tab

## Vulnerabilities

The **Vulnerabilities** page shows a list of vulnerabilities that are present on the related asset.




Figure 21. Vulnerabilities tab

### Export

The **Export**  icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

### Only unresolved

The **Only unresolved**  toggle lets you filter the column to only show unresolved vulnerabilities.

### Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Variables

The **Variables** page shows detailed information for the variables hosted by the related asset.




Figure 22. Variables tab

### Export

The **Export**  icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

### Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Network graph

The **Network graph** page shows how an asset communicates across the network, using real traffic data. It is ideal for uncovering lateral movement or validating expected behavior.





Figure 23. Network graph tab

The **Network graph** tab displays the asset's logical connections, based on observed network traffic. It shows which devices the asset communicates with, using lines between nodes to represent live or historical communication paths.

This view is useful for analyzing device behavior, identifying communication patterns, and detecting potential lateral movement. While the **Physical graph** focuses on physical connections, the **Network graph** provides visibility into traffic-based interactions, offering a complementary perspective on the asset's network role.

## Physical graph

The **Physical graph** page shows the device's physical link to its switch, including port-level data. It is ideal for tracing, troubleshooting, or safely disconnecting assets.



**Figure 24. Physical graph tab**

The **Physical graph** has a cable-level view that shows how a specific device is physically connected to the network. It shows the direct connection between the asset and its switch, including the exact port in use. This information provides clear insight into the physical location and wiring of the device.

This view supports operational tasks such as device tracing, maintenance, and isolation. Users can confirm port assignments or prepare to disconnect a device without referencing external network diagrams. The graph delivers actionable, asset-level visibility into physical connectivity.

## Hardware components

The **Hardware Components** page shows a list of hardware modules installed on the same chassis as the selected controller, providing details on each component for better visibility and management of the device's physical configuration.




Figure 25. Hardware components tab

### Choose

This dropdown lets you select from a list of attributes.






Figure 26. Choose dropdown

### Search bar

The search bar lets you enter a term to filter the list.

Figure 27. Search bar

### Add filter

Select this button to apply the filter in the search bar.



Figure 28. Add filter button

## Chapter 5. Queries



You can use the Nozomi Networks Query Language (N2QL) syntax to create complex data processes to obtain, filter, and analyze lists of information from the Nozomi Networks software.

In [Nozomi Networks Query Language \(N2QL\)](#), queries consist of:

- [Data sources \(on page 83\)](#)
- [Commands \(on page 88\)](#)
- [Functions \(on page 96\)](#)

## Data sources

Queries start by calling a data source. For example:

```
nodes | sort received.bytes desc | head
```

This query will show, in table format, the first 10 nodes that received the most bytes. If you add the **pie** command at the end of the query, the results will show in a pie chart format, where each slice has **node id** as the label and the **received.bytes** field as data.

For example:

```
nodes | sort received.bytes desc | head | pie ip received.bytes
```




Figure 29. Queries example

## Functions

You might not achieved your desired result just using queries. Consequently, query syntax supports functions. With functions, you can apply calculations to the fields and use the results as a new temporary field. For example, the query:

```
nodes | sort sum(sent.bytes, received.bytes) desc | column ip  
sum(sent.bytes, received.bytes)
```

uses the **sum** function to **sort** on the aggregated parameters, which produces a chart with the columns representing the sum of the **sent** and **received** bytes.

## Prefix

The **\$** is a prefix that changes the interpretation of the right hand side (rhs) of a **where** clause. By default, the rhs is interpreted as a string. With the **\$** prefix, the interpretation of the rhs changes to a field name.

For example, in a query such as:

```
nodes | where id == 17.179.252.2
```

the right side of the == is expected to be a constant. If you create a query such as:

```
nodes | where id == id
```

the query tries to match all of the nodes having **id** equal to the string **id**.

If, however, you use the \$, the second field is interpreted as a field, not a constant:

```
nodes | where id == $id
```

and returns the full list of records.

## Data sources

These are the available data sources with which you can start a query.

|                    |                                                                                                                                                                                                                          |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| alerts             | Raised events                                                                                                                                                                                                            |
| appliances         | Downstream connected sensors synchronizing data to this, local one                                                                                                                                                       |
| assertions         | Assertions saved by the users. An assertion represents an automatic check against other query sources                                                                                                                    |
| assets             | Identified assets. Assets represent a local (private), physical system to care about, and can be composed of one or more Nodes. Broadcast nodes, grouped nodes, internet nodes, and similar cannot be Assets accordingly |
| audit_log          | System's log for important operational events, e.g., login, backup creation, etc.                                                                                                                                        |
| captured_files     | Files reconstructed for analysis                                                                                                                                                                                         |
| captured_logs      | Logs captured passively over the network                                                                                                                                                                                 |
| captured_urls      | URLs and other protocol calls captured over the network. Access to files, requests to DNS, requested URLs and other are available in this query source                                                                   |
| cpe_items          | CPE maps definitions                                                                                                                                                                                                     |
| cve_files          | CVE definitions                                                                                                                                                                                                          |
| dhcp_leases        | IP to Mac bindings due to the presence of DHCP                                                                                                                                                                           |
| function_codes     | Protocols' function codes used in the environment                                                                                                                                                                        |
| health_log         | System's Health-related events, e.g. high resource utilization or hardware-related issues or events                                                                                                                      |
| link_events        | Events that can occur on a Link, like it being available or not                                                                                                                                                          |
| links              | Identified links, defined as directional one-to-one associations with a single protocol (i.e. source, destination, protocol)                                                                                             |
| microsoft_hotfixes | Microsoft hotfix information                                                                                                                                                                                             |

|                      |                                                                                                                                                                                                                                                                    |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| node_cpe_changes     | Common Platform Enumeration changes identified over known nodes. On the event of update of a CPE (on hardware, operating system and software versions), an entry in this query source is created to keep track of software updates or better detection of software |
| node_cpes            | Common Platform Enumeration identified on nodes (hardware, operating system and software versions)                                                                                                                                                                 |
| node_cves            | Common Vulnerability Exposures: vulnerabilities associated to identified nodes' CPEs                                                                                                                                                                               |
| node_points          | Data points extracted over time, via Smart Polling or via Arc, from monitored Nodes                                                                                                                                                                                |
| node_points_last     | node_points last samples per each included data point                                                                                                                                                                                                              |
| nodes                | Identified nodes, where a node is an L2 or L3 (and above) entity able to speak some protocol                                                                                                                                                                       |
| packet_rules         | Packet rules definitions                                                                                                                                                                                                                                           |
| protocol_connections | Identified protocol handshakes/connections needed to decode process variables                                                                                                                                                                                      |
| report_files         | Generated report files available for consultation                                                                                                                                                                                                                  |
| report_folders       | Generated report folders                                                                                                                                                                                                                                           |
| sessions             | Sessions with recent network activity. A Session is a specific application-level connection between nodes. A Link can hold one or more Session at a given time                                                                                                     |
| sessions_history     | Archived sessions                                                                                                                                                                                                                                                  |
| sigma_rules          | Sigma rules definitions                                                                                                                                                                                                                                            |
| sp_executions        | Executions of Smart Polling plans                                                                                                                                                                                                                                  |
| sp_node_executions   | Results of Smart Polling plans executions per node                                                                                                                                                                                                                 |
| stix_indicators      | STIX definitions                                                                                                                                                                                                                                                   |
| subnets              | Identified network subnets                                                                                                                                                                                                                                         |
| threat_models        | Threat Modeling definitions                                                                                                                                                                                                                                        |
| trace_requests       | Trace requests in processing                                                                                                                                                                                                                                       |



|                  |                                                    |
|------------------|----------------------------------------------------|
| variable_history | Process variables' history of values               |
| variables        | Identified process variables                       |
| yara_rules       | YARA rules definitions                             |
| zone_links       | A list of protocols exchanged by the defined zones |
| zones            | Defined network zones                              |

## Basic operators

|                    |                                                                                                                                                                                                |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | (pipe, AND logical operator)                                                                                                                                                                   |
| <b>Description</b> | Add a where clause with a logical AND, append it using the pipe character ( ). For example, the query below returns links that are from 192.168.254.0/24 <b>AND</b> going to 172.217.168.0/24. |
| <b>Example</b>     | <code>links   where from_in_subnet? 192.168.254.0/24   where to_in_subnet? 172.217.168.0/24</code>                                                                                             |

|                    |                                                                                                                                                                          |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | OR                                                                                                                                                                       |
| <b>Description</b> | To add a where clause with a logical OR, append it using the OR operator. For example, the query below returns links with either the http <b>OR</b> the https protocols. |
| <b>Example</b>     | <code>links   where protocol == http OR protocol == https</code>                                                                                                         |

|                    |                                                                                                                                                 |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | ! (exclamation point, NOT logical operator)                                                                                                     |
| <b>Description</b> | Put an exclamation point (!) before a term to negate it. For example, the query below returns links that do NOT (!) belong to 192.168.254.0/24. |
| <b>Example</b>     | <code>nodes   where ip !in_subnet? 192.168.254.0/24   count</code>                                                                              |

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | ->                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Description</b> | <p>To change a column name, select it and use the -&gt; operator followed by the new name. It is worth noting that specific suffixes are parsed and used to visualize the column content differently. For example:</p> <ul style="list-style-type: none"> <li>• <b>_time</b> data is shown in a timestamp format (1647590986549 becomes 2022-03-18 09:09:46.549)</li> <li>• <b>_bytes</b> adds KB or MB, as applicable (50 becomes 50.0 B)</li> <li>• <b>_percent</b> adds a percentage sign (50 becomes 50%)</li> <li>• <b>_speed</b> adds a throughput speed in Mb/s (189915 becomes 1.8 Mb/s)</li> <li>• <b>_date</b> converts numbers into a date format (2022-06-22 15:43:31.297 becomes 2022-06-22 14:24:09.280 becomes 2022-06-24 (current day))</li> <li>• <b>_packets</b> adds pp after the number of packets (50 becomes 50 pp)</li> </ul> |
| <b>Example 1</b>   | <code>nodes   select created_at created_at-&gt;my_integer   where my_integer &gt; 946684800000</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Example 2</b>   | <code>nodes   select created_at-&gt;my_creation_time</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

|                  |                                                                           |
|------------------|---------------------------------------------------------------------------|
| <b>Example 3</b> | <code>nodes   select tcp_retransmission.bytes-&gt;my_retrans_bytes</code> |
|------------------|---------------------------------------------------------------------------|

|                    |                                                          |
|--------------------|----------------------------------------------------------|
| <b>Operators</b>   | <code>==, =, &lt;, &gt;, &lt;=, and &gt;=</code>         |
| <b>Description</b> | Queries support the mathematical operators listed above. |

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | <code>"</code> (Quotation marks)                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Description</b> | <p>Use quotation marks (<code>"</code>) to specify an empty string. Consider these two cases where this technique is useful:</p> <ul style="list-style-type: none"> <li>Finding non-empty values. Example 1 below returns assets where the <code>os</code> field is not blank.</li> <li>Specifying that a value in the query is a string (if its type is ambiguous). Example 2 below tells <code>concat</code> to treat the <code>--</code> parameter as a fixed string to use rather than as a field from the <code>alerts</code> table.</li> </ul> |
| <b>Example 1</b>   | <code>assets   where os != ""</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Example 2</b>   | <code>alerts   select concat(id_src,"--",id_dst)</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

|                    |                                                                                                                                                                                                                                                                                                                                                 |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | <code>in?</code>                                                                                                                                                                                                                                                                                                                                |
| <b>Description</b> | <p><code>in?</code> is only used with arrays; the field <b>type</b> must be an array. The query looks for the text strings you specify using <code>in?</code> and returns arrays that match one of them.</p> <p>The example below uses <code>in?</code> to find any node having <b>computer</b> or <b>printer</b> as elements in the array.</p> |
| <b>Example</b>     | <code>assets   where type in? ["computer","printer_scanner"]</code>                                                                                                                                                                                                                                                                             |

|                    |                                                                                                                                                                                                                                                          |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Operator</b>    | <code>include?</code>                                                                                                                                                                                                                                    |
| <b>Description</b> | <p>The query looks for the text string you specify using <code>include?</code> and returns strings that match it.</p> <p>The example below uses <code>include?</code> to find assets where the <code>os</code> field contains the string <b>Win</b>.</p> |
| <b>Example</b>     | <code>assets   where os include? Win</code>                                                                                                                                                                                                              |

## Commands

|                    |                                                                                             |
|--------------------|---------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>select &lt;field1&gt; &lt;field2&gt; ... &lt;fieldN&gt;</code>                        |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>the list of field(s) to output</li> </ul>            |
| <b>Description</b> | The select command takes all the input items and outputs them with only the selected fields |

|                    |                                                                                                  |
|--------------------|--------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>exclude &lt;field1&gt; &lt;field2&gt; ... &lt;fieldN&gt;</code>                            |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>the list of field(s) to remove from the output</li> </ul> |
| <b>Description</b> | The exclude command takes all the input items and outputs them without the specified field(s)    |

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>where &lt;field&gt; &lt;== != &lt; &gt; &lt;= &gt;= in?!in?!include?!include?!exclude?!start_with?!end_with?!in_subnet?&gt; &lt;value&gt;</code>                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>field: the name of the field to which the operator will be applied</li> <li>operator</li> <li>value: the value used for the comparison. It can be a number, a string, or other data type. Advanced operators can use other data types, such as: <ul style="list-style-type: none"> <li>a list (using JSON syntax) when using the in? operator, for example: <code>nodes   where ip in? ["172.18.41.44"]</code></li> <li>another property when using the '\$' symbol, for example: <code>nodes   where ip != \$id</code></li> </ul> </li> </ul> |
| <b>Description</b> | The where command will send to the output only the items which fulfill the specified criterion, many clauses can be concatenated using the boolean <b>OR</b> operator                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Example</b>     | <ul style="list-style-type: none"> <li><code>assets   where vendor !in? ["VMware","Cisco"]</code></li> <li><code>nodes   where roles include? consumer OR zone == office</code></li> <li><code>nodes   where label != ""   where label !include? ".net"</code></li> <li><code>nodes   where ip in_subnet? 192.168.1.0/24</code></li> <li>&lt;value&gt; can also be another &lt;field&gt;, as in:<br/><code>links   where from_zone == \$to_zone   select from_zone to_zone</code></li> </ul>                                                                                          |

|               |                                            |
|---------------|--------------------------------------------|
| <b>Syntax</b> | <code>sort &lt;field&gt; [asc desc]</code> |
|---------------|--------------------------------------------|

|                    |                                                                                                                                                                |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <b>field</b>: the field used for sorting</li> <li>• <b>asc desc</b>: the sorting direction</li> </ul>                 |
| <b>Description</b> | The sort command will sort all the items according to the field and the direction specified, it automatically understands if the field is a number or a string |

|                    |                                                                                                                                                                                                                                                                                        |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>group_by &lt;field&gt; [ [avg sum] [field2] ]</code>                                                                                                                                                                                                                             |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <b>field</b>: the field used for grouping</li> <li>• <b>avg sum</b>: if specified, the relative operation will be applied on <b>field2</b></li> </ul>                                                                                         |
| <b>Description</b> | The group_by command will output a grouping of the items using the field value. By default the output will be the count of the occurrences of distinct values. If an operator and a <b>field2</b> are specified, the output will be the average or the sum of the <b>field2</b> values |

|                    |                                                                                                             |
|--------------------|-------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>head [count]</code>                                                                                   |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <b>count</b>: the number of items to output</li> </ul>             |
| <b>Description</b> | The head command will take the first <b>count</b> items, if <b>count</b> is not specified the default is 10 |

|                    |                                                                                                                     |
|--------------------|---------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>uniq [&lt;field1&gt; &lt;field2&gt; ... &lt;fieldN&gt;]</code>                                                |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• an optional list of fields on which to calculate the uniqueness</li> </ul> |
| <b>Description</b> | The uniq command will remove from the output the duplicated items                                                   |

|                    |                                                                                                                                                                                                                         |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>expand &lt;field&gt;</code>                                                                                                                                                                                       |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <b>field</b>: the field containing the list of values to be expanded</li> </ul>                                                                                                |
| <b>Description</b> | The expand command will take the list of values contained in <b>field</b> and for each of them it will duplicate the original item substituting the original <b>field</b> value with the current value of the iteration |

|                   |                                                                                                        |
|-------------------|--------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>     | <code>expand_recursive &lt;field&gt;</code>                                                            |
| <b>Parameters</b> | <ul style="list-style-type: none"> <li>• <b>field</b>: the field to be recursively expanded</li> </ul> |

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | The <code>expand_recursive</code> command will recursively parse the content of <b>field</b> , expanding each array or json structure until a scalar value is found. It generates a new row for each array element or json field. For each new row, it duplicates the original item substituting the original <b>field</b> value with the current value of the iteration and adding a new field that represents the current iteration path from the root |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                    |                                                                                                                  |
|--------------------|------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>sub &lt;field&gt;</code>                                                                                   |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>field</code>: the field containing the list of objects</li> </ul> |
| <b>Description</b> | The <code>sub</code> command will output the items contained in <b>field</b>                                     |

|                    |                                                            |
|--------------------|------------------------------------------------------------|
| <b>Syntax</b>      | <code>count</code>                                         |
| <b>Parameters</b>  |                                                            |
| <b>Description</b> | The <code>count</code> command outputs the number of items |

|                    |                                                                                                                                                                                                                           |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>pie &lt;label_field&gt; &lt;value_field&gt;</code>                                                                                                                                                                  |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>label_field</code>: the field used for each slice label</li> <li>• <code>value_field</code>: the field used for the value of the slice, must be a numeric field</li> </ul> |
| <b>Description</b> | The <code>pie</code> command will output a pie chart according to the specified parameters                                                                                                                                |

|                    |                                                                                                                                                                                                                                                                                      |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>column &lt;label_field&gt; &lt;value_field ...&gt;</code>                                                                                                                                                                                                                      |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>label_field</code>: the field used for each column label</li> <li>• <code>value_field</code>: one or more field used for the values of the columns</li> </ul>                                                                         |
| <b>Description</b> | The <code>column</code> command will output a histogram; for each label a group of columns is displayed with the value from the specified <code>value_field(s)</code> . The variant <code>column_colored_by_label</code> returns bars of different colors depending on their labels. |

|                   |                                                                                                                                                                                                             |
|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>     | <code>history &lt;count_field&gt; &lt;time_field&gt;</code>                                                                                                                                                 |
| <b>Parameters</b> | <ul style="list-style-type: none"> <li>• <code>count_field</code>: the field used to draw the Y value</li> <li>• <code>time_field</code>: the field used to draw the X points of the time series</li> </ul> |

|                    |                                                                                 |
|--------------------|---------------------------------------------------------------------------------|
| <b>Description</b> | The history command will draw a chart representing an historic series of values |
|--------------------|---------------------------------------------------------------------------------|

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>distance &lt;id_field&gt; &lt;distance_field&gt;</code>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>id_field</code>: the field used to tag the resulting distances.</li> <li>• <code>distance_field</code>: the field on which distances are computed among entries.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Description</b> | <p>The distance command calculates a series of distances (that is, differences) from the original series of <b>distance_field</b>. Each distance value is calculated as the difference between a value and its subsequent occurrence, and tagged using the <b>id_field</b>.</p> <p>For example, assuming we're working with an <b>id</b> and a <b>time</b> field, entering <b>alerts   distance id time</b> returns a table where each distance entry is characterised by the <b>from_id</b>, <b>to_id</b>, and <b>time_distance</b> fields that represent time differences between the selected alerts.</p> |

|                    |                                                                                                                                                                                                         |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>bucket &lt;field&gt; &lt;range&gt;</code>                                                                                                                                                         |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>field</code>: the field on which the buckets are calculated</li> <li>• <code>range</code>: the range of tolerance in which values are grouped</li> </ul> |
| <b>Description</b> | The bucket command will group data in different buckets, different records will be put in the same bucket when the values fall in the same multiple of <code>&lt;range&gt;</code>                       |

|                    |                                                                                                                                                                                                                                                                                                                                   |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>join &lt;other_source&gt; &lt;field&gt; &lt;other_source_field&gt;</code>                                                                                                                                                                                                                                                   |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>other_source</code>: the name of the other data source</li> <li>• <code>field</code>: the field of the original source used to match the object to join</li> <li>• <code>other_source_field</code>: the field of the other data source used to match the object to join</li> </ul> |
| <b>Description</b> | The join command will take two records and will join them in one record when <code>&lt;field&gt;</code> and <code>&lt;other_source_field&gt;</code> have the same value                                                                                                                                                           |

|                    |                                                                                                                                                                                                                                             |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>gauge &lt;field&gt; [min] [max]</code>                                                                                                                                                                                                |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>field</code>: the value to draw</li> <li>• <code>min</code>: the minimum value to put on the gauge scale</li> <li>• <code>max</code>: the maximum value to put on the gauge scale</li> </ul> |
| <b>Description</b> | The gauge command will take a value and represent it in a graphical way                                                                                                                                                                     |

|                    |                                                                            |
|--------------------|----------------------------------------------------------------------------|
| <b>Syntax</b>      | value <field>                                                              |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>field: the value to draw</li> </ul> |
| <b>Description</b> | The value command will take a value and represent it in a textual way      |

|                    |                                                                                                                                                                                              |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | reduce <field> [sum avg]                                                                                                                                                                     |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>field: the field on which the reduction will be performed</li> <li>sum or avg: the reduce operation to perform, it is sum if not specified</li> </ul> |
| <b>Description</b> | The reduce command will take a series of values and calculate a single value                                                                                                                 |

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | size()                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>field: the field to calculate the size of</li> </ul>                                                                                                                                                                                                                                                                                                                                                    |
| <b>Description</b> | <p>If the field is an array, then the size function returns the number of entries in the array. If the field contains a string, then the size function returns the number of characters in the string.</p> <p><b>Note:</b> The size function may only be used on the following data sources: alerts, assets, captured_files, links, nodes, packet_rules, sessions, stix_indicators, subnets, variables, yara_rules, zones, and zone_links.</p> |
| <b>Example:</b>    | assets   where size(ip) > 1                                                                                                                                                                                                                                                                                                                                                                                                                    |



## Nodes-specific commands reference

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>where_node &lt;field&gt; &lt; == != &lt; &gt; &lt;= &gt;= in? include? exclude? start_with? end_with? &gt; &lt;value&gt;</code>                                                                                                                                                                                                                                                                                            |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• field: the name of the field to which the operator will be applied</li> <li>• operator</li> <li>• value: the value used for the comparison. It can be a number, a string or a list (using JSON syntax), the query engine will understand the semantics.</li> </ul>                                                                                                                      |
| <b>Description</b> | <p>The where_node command will send to the output only the items which fulfill the specified criterion, many clauses can be concatenated using the boolean <b>OR</b> operator. The where_node command is similar to the where command, but the output will also include all the nodes that are communicating directly with the result of the search.</p> <p><b>Note:</b> This command is only applicable to the nodes table.</p> |

|                    |                                                                                                                                                                                                                                                                                                                           |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>where_link &lt;field&gt; &lt; == != &lt; &gt; &lt;= &gt;= in? include? exclude? start_with? end_with? &gt; &lt;value&gt;</code>                                                                                                                                                                                     |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• field: the name of the links table's field to which the operator will be applied.</li> <li>• operator</li> <li>• value: the value used for the comparison. It can be a number, a string or a list (using JSON syntax) the query engine will understand the semantics.</li> </ul> |
| <b>Description</b> | <p>The where_link command will send to the output only the nodes which are connected by a link fulfilling the specified criterion. Many clauses can be concatenated using the boolean <b>OR</b> operator.</p> <p><b>Note:</b> This command is only applicable to the nodes table.</p>                                     |

|               |                                                                                                                                                                            |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b> | <code>graph [node_label:&lt;node_field&gt;]</code><br><code>[node_perspective:&lt;perspective_name&gt;]</code><br><code>[link_perspective:&lt;perspective_name&gt;]</code> |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b>  | <ul style="list-style-type: none"><li>• node_label: add a label to the node, the label will be the content of the specified node field</li><li>• node_perspective: apply the specified node perspective to the resulting graph. Valid node perspective values are:<ul style="list-style-type: none"><li>◦ roles</li><li>◦ zones</li><li>◦ transferred_bytes</li><li>◦ not_learned</li><li>◦ public_nodes</li><li>◦ reputation</li><li>◦ appliance_host</li></ul></li><li>• link_perspective: apply the specified link perspective to the resulting graph. Valid link perspectives are:<ul style="list-style-type: none"><li>◦ transferred_bytes</li><li>◦ tcp_firewalled</li><li>◦ tcp_handshaked_connections</li><li>◦ tcp_connection_attempts</li><li>◦ tcp_retransmitted_bytes</li><li>◦ throughput</li><li>◦ interzones</li><li>◦ not_learned</li></ul></li></ul> |
| <b>Description</b> | The graph command renders a network graph by taking some nodes as input.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

## Link-events-specific commands reference

|                    |                                                                                                                                                            |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | availability                                                                                                                                               |
| <b>Parameters</b>  |                                                                                                                                                            |
| <b>Description</b> | The availability command computes the percentage of time a link is UP. The computation is based on the link events UP and DOWN that are seen for the link. |

|                    |                                                                                                                                                                                                                           |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | availability_history <range>                                                                                                                                                                                              |
| <b>Parameters</b>  | <ul style="list-style-type: none"><li>• range: the temporal window in milliseconds to use to group the link events</li></ul>                                                                                              |
| <b>Description</b> | The availability_history command computes the percentage of time a link is UP by grouping the link events into many buckets. Each bucket will include the events of the temporal window specified by the range parameter. |

|                    |                                                                                                                                                                                                                                       |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | availability_history_month <months_back> <range>                                                                                                                                                                                      |
| <b>Parameters</b>  | <ul style="list-style-type: none"><li>• months_back: number of months to go back in regards to the current month to group the link events</li><li>• range: the temporal window in seconds to use to group the link events</li></ul>   |
| <b>Description</b> | The availability_history command computes the percentage of time a link is UP by grouping the link events into many buckets. Each bucket will include the events of the temporal window specified by the range and months parameters. |

## Functions

Functions are always used in conjunction with other commands, such as **select**. In the following examples, functions are shown in **bold**:

- Combining functions with **select**: `nodes | select id type color(type)`
- Combining functions with **where**: `nodes | where size(label) > 10`
- Combining functions with **group\_by**: `nodes | group_by size(protocols)`

Here is the complete list of functions:

|                    |                                                                                                        |
|--------------------|--------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>abs(&lt;field&gt;)</code>                                                                        |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• the field on which to calculate the absolute value</li> </ul> |
| <b>Description</b> | The abs function returns the absolute value of the field                                               |

|                    |                                                                                                                                                                                                         |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>bitwise_and(&lt;numeric_field&gt;, &lt;mask&gt;)</code>                                                                                                                                           |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>numeric_field</code>: the numeric field on which apply the mask</li> <li>• <code>mask</code>: a number that will be interpreted as a bit mask</li> </ul> |
| <b>Description</b> | The bitwise_and function calculates the bitwise & operator between the <code>numeric_field</code> and the mask entered by the user                                                                      |

|                    |                                                                                                                       |
|--------------------|-----------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>coalesce(&lt;field1&gt;, &lt;field2&gt;, ...)</code>                                                            |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• a list of fields or string literals in the format "&lt;chars&gt;"</li> </ul> |
| <b>Description</b> | The coalesce function will output the first value that is not null                                                    |

|                    |                                                                                                                   |
|--------------------|-------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>color(&lt;field&gt;)</code>                                                                                 |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• <code>field</code>: the field on which to calculate the color</li> </ul> |
| <b>Description</b> | The color function generates a color in the rgb hex format from a value                                           |
| <b>Note</b>        | Only available for nodes, links, variables and function_codes                                                     |

|                   |                                                                                                                       |
|-------------------|-----------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>     | <code>concat(&lt;field1&gt;, &lt;field2&gt;, ...)</code>                                                              |
| <b>Parameters</b> | <ul style="list-style-type: none"> <li>• a list of fields or string literals in the format "&lt;chars&gt;"</li> </ul> |

|                    |                                                                                 |
|--------------------|---------------------------------------------------------------------------------|
| <b>Description</b> | The concat function will output the concatenation of the input fields or values |
|--------------------|---------------------------------------------------------------------------------|

|                    |                                                                              |
|--------------------|------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>date(&lt;time&gt;)</code>                                              |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time defined as unix epoch</li> </ul> |
| <b>Description</b> | The date function returns a date from a raw time                             |

|                    |                                                                                                                                                                                                                                                         |
|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>day_hour(&lt;time_field&gt;)</code>                                                                                                                                                                                                               |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time_field: the field representing a time</li> </ul>                                                                                                                                                             |
| <b>Description</b> | The day_hour function returns the hour of the day plus the sensor's local time offset from UTC, i.e. a value in the range 0 through 23. Be careful when accounting for daylight saving time. Use <b>day_hour_utc</b> when absolute precision is desired |

|                    |                                                                                                                                                  |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>day_hour_utc(&lt;time_field&gt;)</code>                                                                                                    |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time_field: the field representing a time</li> </ul>                                                      |
| <b>Description</b> | The <b>day_hour_utc</b> function returns the hour of the day expressed in UTC for the current time field, i.e. a value in the range 0 through 23 |

|                    |                                                                                                           |
|--------------------|-----------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>days_ago(&lt;time_field&gt;)</code>                                                                 |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time_field: the field representing a time</li> </ul>               |
| <b>Description</b> | The days_ago function returns the amount of days passed between the current time and the time field value |

|                    |                                                                                                                   |
|--------------------|-------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>dist(&lt;field1&gt;,&lt;field2&gt;)</code>                                                                  |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>the two fields to compute the distance on</li> </ul>                       |
| <b>Description</b> | The dist function returns the distance between field1 and field2, which is the absolute value of their difference |

|               |                                                 |
|---------------|-------------------------------------------------|
| <b>Syntax</b> | <code>div(&lt;field1&gt;,&lt;field2&gt;)</code> |
|---------------|-------------------------------------------------|

|                    |                                                                                              |
|--------------------|----------------------------------------------------------------------------------------------|
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>field1 and field2: the two field to divide</li> </ul> |
| <b>Description</b> | The div function will calculate the division field1/field2                                   |

|                    |                                                                                                             |
|--------------------|-------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>hours_ago(&lt;time_field&gt;)</code>                                                                  |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time_field: the field representing a time</li> </ul>                 |
| <b>Description</b> | The hours_ago function returns the amount of hours passed between the current time and the time field value |

|                    |                                                                                                                    |
|--------------------|--------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>is_empty(field) == true   false</code>                                                                       |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>field: the field to check to evaluate whether it is empty or not</li> </ul> |
| <b>Description</b> | The is_empty command takes a field as input and returns only the entries that are either empty / not empty.        |
| <b>Example</b>     | <code>nodes   where is_empty(label) == false</code>                                                                |

|                    |                                                                                                       |
|--------------------|-------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>is_recent(&lt;time_field&gt;)</code>                                                            |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time_field: the field representing a time</li> </ul>           |
| <b>Description</b> | The is_recent function takes a time field and returns true if the time is not farther than 30 minutes |

|                    |                                                                                                                 |
|--------------------|-----------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>minutes_ago(&lt;time_field&gt;)</code>                                                                    |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>time_field: the field representing a time</li> </ul>                     |
| <b>Description</b> | The minutes_ago function returns the amount of minutes passed between the current time and the time field value |

|                    |                                                                                |
|--------------------|--------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>mult(&lt;field1&gt;, &lt;field2&gt;, ...)</code>                         |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>a list of fields to multiply</li> </ul> |
| <b>Description</b> | The mult function returns the product of the fields passed as arguments        |

|               |                                                |
|---------------|------------------------------------------------|
| <b>Syntax</b> | <code>round(&lt;field&gt;, [precision])</code> |
|---------------|------------------------------------------------|

|                    |                                                                                                                                          |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• field: the numeric field to round</li> <li>• precision: the number of decimal places</li> </ul> |
| <b>Description</b> | The round function takes a number and outputs the rounded value                                                                          |

|                    |                                                                                                                 |
|--------------------|-----------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>seconds_ago(&lt;time_field&gt;)</code>                                                                    |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• time_field: the field representing a time</li> </ul>                   |
| <b>Description</b> | The seconds_ago function returns the amount of seconds passed between the current time and the time field value |

|                    |                                                                                                                                                                                                                                |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>split(&lt;field&gt;, &lt;splitter&gt;, &lt;index&gt;)</code>                                                                                                                                                             |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• field: the field to split</li> <li>• splitter: the character used to separate the string and produce the tokens</li> <li>• index: the 0 based index of the token to output</li> </ul> |
| <b>Description</b> | The split function takes a string, separates it and outputs the token at the <index> position                                                                                                                                  |

|                    |                                                                             |
|--------------------|-----------------------------------------------------------------------------|
| <b>Syntax</b>      | <code>sum(&lt;field&gt;, ...)</code>                                        |
| <b>Parameters</b>  | <ul style="list-style-type: none"> <li>• a list of fields to sum</li> </ul> |
| <b>Description</b> | The sum function returns the sum of the fields passed as arguments          |

## Examples

### Pie chart

An example on how to create a pie chart to understand the media access control (MAC) vendor distribution in a network.

We choose nodes as our query source and we start to group the nodes by mac\_vendor:

```
nodes | group_by mac_vendor
```

We can see the list of the vendors in our network associated with the occurrences count. To better understand our data we can use the sort command, so the query becomes:

```
nodes | group_by mac_vendor | sort count desc
```

In the last step we use the pie command to draw the chart with the mac\_vendor as a label and the count as the value.

```
nodes | group_by mac_vendor | sort count desc | pie mac_vendor count
```




Figure 30. Pie chart example

### Column chart

An example on how to create a column chart with the top nodes by traffic.

To start, you need to get the nodes and select the:

- id
- sent.bytes
- received.bytes
- sent.bytes
- received.bytes

To calculate the sum, you need to use the **sum** function. The query is:

```
nodes | select id sent.bytes received.bytes  
sum(sent.bytes, received.bytes)
```

When you execute this query, the sum field has a very long name. You can rename it to be more comfortable with these commands:



```
nodes | select id sent.bytes received.bytes
sum(sent.bytes,received.bytes)->sum
```

To obtain the top nodes by traffic, you can sort and take the first 10:

```
nodes | select id sent.bytes received.bytes
sum(sent.bytes,received.bytes)->sum | sort sum desc | head 10
```

Finally, to display the data in a graphical way, you can use the **column** command:

```
nodes | select id sent.bytes received.bytes
sum(sent.bytes,received.bytes)->sum | sort sum desc | head 10 | column
id sum sent_bytes received_bytes
```



#### Note:

You can access an inner field of a complex type with the dot syntax, in the example the dot syntax is used on the fields **sent** and **received** to access their bytes sub field.



#### Note:

After accessing a field with the dot syntax, it will gain a new name to avoid ambiguity; the dot is replaced by an underscore. In the example **sent.bytes** become **sent\_bytes**




Figure 31. Column chart example

## Where with multiple conditions in OR

An example of a query to get all the nodes with a specific role, in particular all the nodes which are web or domain name server (DNS) servers.

With the **where** command, you can separate many conditions with **OR**



#### Note:

Because the roles field contains a list of values, you can use the **include?** operator to check if a value was contained in the list.

```
nodes | where roles include? web_server OR roles include? dns_server |
select id roles
```



The screenshot shows a query result table with the title "nodes | where roles include? web\_server OR roles include? dns\_server | select id roles". The table has two columns: "id" and "roles". There are two rows of data, each with a "JSON View" link.

| id          | roles          |
|-------------|----------------|
| 192.168.1.1 | ["dns_server"] |
| 172.16.0.1  | ["dns_server"] |

Figure 32. Where with multiple conditions in OR example

## Bucket and history

An example of a query to calculate the distribution of link events towards an internet protocol (IP) address.

You can filter all the **link\_events** with **id\_dst** equal to **192.168.1.11**. After this you can sort by time, this is a very important step because bucket and history depend on how the data are sorted.

Then you can use **bucket** to group the data by time. The final step is to use the **history** command to draw a chart, we pass **count** as a value for the Y axis and **time** for the X axis.

The **history** command is particularly suited for displaying a big amount of data, in the image below we can see that there are many hours of data to analyze.

```
link_events | where id_dst == 192.168.1.11 | sort time asc | bucket time
36000 | history count time
```




Figure 33. Bucket and history example

## Join

An example query to join two data sources to obtain a new data source with more information. In particular, how to list the links with the labels for the source and destination nodes.

You can match the **from** field of the links with the **id** field of the nodes to ask for the links, and join them with the nodes:

```
links | join nodes from id
```


After executing the query above you will get all the links fields, plus a new field called **joined\_node\_from\_id**, it contains the node which satisfies the **link.from == node.id** condition. You can use the dot syntax to access the sub fields of **joined\_node\_from\_id**

Because we also want to get the labels for the **to** field of the **links** you add another **join** and exclude the empty labels of the node referred by **to** to get more interesting data:

```
links | join nodes from id | join nodes to id | where
  joined_node_to_id.label != ""
```

This will obtain a huge amount of data, which is difficult to understand. To only get the relevant information, you can use a **select**:

```
links | join nodes from id | join nodes to id | where
  joined_node_to_id.label != "" | select from joined_node_from_id.label to
  joined_node_to_id.label protocol
```



The screenshot shows a query execution interface with a table of results. The query is: `links | join nodes from id | join nodes to id | where joined_node_to_id.label != "" | select from joined_node_from_id.label to joined_node_to_id.label protocol`. The table has columns: **from**, **joined\_node\_from\_id.label**, **to**, **joined\_node\_to\_id.label**, and **protocol**. The data shows multiple rows of IP addresses and Modicon M340 BMX P34 2020 nodes connected via modbus protocol.

| from         | joined_node_from_id.label | to           | joined_node_to_id.label   | protocol |
|--------------|---------------------------|--------------|---------------------------|----------|
| 172.16.0.253 |                           | 172.16.0.148 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.0.253 |                           | 172.16.0.149 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.1.253 |                           | 172.16.1.149 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.0.253 |                           | 172.16.0.156 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.1.253 |                           | 172.16.1.156 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.0.253 |                           | 172.16.0.146 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.1.253 |                           | 172.16.1.146 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.0.253 |                           | 172.16.0.153 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.1.253 |                           | 172.16.1.153 | Modicon M340 BMX P34 2020 | modbus   |
| 172.16.0.253 |                           | 172.16.0.143 | Modicon M340 BMX P34 2020 | modbus   |

Figure 34. Join example

## Compute the availability history

*An example query to compute the availability history for a link.*

In order to achieve a reliable availability, it is recommended to enable the **Track availability** feature on the desired link.

Start from the **link\_events** data source, filtered by source and destination ip in order to precisely identify the target link. Consider also filtering by protocol to achieve a higher degree of precision.

```
link_events | where id_src == 10.254.3.9 | where id_dst == 172.31.50.2
```

The next step is to sort the events by ascending time of creation. Without this step the **availability\_history** might produce meaningless results, such as negative values. Then, to compute the **availability\_history** with a bucket of 1 minute (60000 milliseconds), you can complete query as follows:

```
link_events | where id_src == 10.254.3.9 | where id_dst == 172.31.50.2 |
  sort time asc | availability_history 60000
```

| Queries                                                                                                                                                                          |              |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------|
| link_events   where id_src == 10.254.3.9   where id_dst == 172.31.50.2   sort time asc   availability_history 60000                                                              |              |
| Result (link_events   where id_src == 10.254.3.9   where id_dst == 172.31.50.2   sort time asc   availa: <a href="#">To assertion</a> <a href="#">Excel</a> <a href="#">Copy</a> |              |
| availability                                                                                                                                                                     | time         |
| 100                                                                                                                                                                              | 09:01:00.000 |
| 34.075                                                                                                                                                                           | 09:02:00.000 |
| 21.41167                                                                                                                                                                         | 09:04:00.000 |
| 79.805                                                                                                                                                                           | 09:05:00.000 |
| 0                                                                                                                                                                                | 09:06:00.000 |
| 74.47167                                                                                                                                                                         | 09:08:00.000 |
| 25.78833                                                                                                                                                                         | 09:09:00.000 |
| 0                                                                                                                                                                                | 09:10:00.000 |
| 29.11167                                                                                                                                                                         | 09:11:00.000 |
| 71.36167                                                                                                                                                                         | 09:12:00.000 |

Figure 35. Availability history example

**Note:**

By default, `link_events` generation is disabled. To enable it, you can use the configuration rule described in **Configure links**.

## Complex field types

### Single scalar values

To query single scalar values, apply the commands that are explained in this section.

### Objects

Objects show in braces: {object}

```
{
  "source": "ARP",
  "likelihood": 1,
  "likelihood_level": "confirmed"
}
```

An example on how to query only **confirmed** **MAC** addresses.

**Note:**

Possible values are:

- **confirmed**
- **likely**
- **not confirmed**

Since `mac_address:info` is an object, you can access subfields like `mac_address:info.likelihood_level` to apply the **where** condition:

```
nodes | select mac_address:info mac_address:info.likelihood_level | where
mac_address:info.likelihood_level == confirmed
```

Since N2OS 24.1 is possible to access complex objects with a different syntax that is compatible with Vantage, using the `/` operator, the query specified above becomes:

```
nodes | select mac_address:info/likelihood_level | where
mac_address:info.likelihood_level == "confirmed"
```

Note that also the **"confirmed"** literal can now be quoted and the query can be executed in Vantage without any change.

## Arrays

**Note:**

For example, a **parent** in the alerts table.

Arrays show in braces: {array}

```
[
"5b867836-2b41-4c15-ab6f-4ae5f0251e30"
]
```

An example on how to only query alerts that have a parent incident, with a known incident id with the value: **d36d0**

Since the **parents** field is an array, you can use **expand** first to get an entry for each parent, then apply your condition:

```
alerts | expand parents | where expanded_parents include? d36d0
```

## Object arrays

**Note:**

For example, **function\_codes** in the links table.

Object arrays are a combination of the above examples. Therefore, they show an object included in a `[{..},{..},... ]` :

```
[
{
  "name": "M-SEARCH",
  "is_learned": true,
  "is_fully_learned": true
}
```

An example on how to query learned function codes.

Since `function_codes` is an object array, you can use `expand` first, to get an entry for each function code, then use the `.` operator (`function_code.is_learned`) to apply your `where` condition:

```
links | select from to protocol function_codes | expand function_codes |
where expanded_function_codes.is_learned == true
```

## Chapter 6. Smart Polling in Guardian





The **Smart Polling** page lets you view and manage Smart Polling.

Smart Polling has these tabs:

- [Plans \(on page 110\)](#)
- [Node points \(on page 111\)](#)
- [Settings \(on page 112\)](#)
- [Health \(on page 113\)](#)

# Plans

The **Plans** page shows a list of Smart Polling plans and lets you manage plans and add new ones.




Figure 36. Plans page

## Filter by node ID

The Filter by node ID field lets you use the node *ID* to filter the results.

## Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## New plan

The  **New plan** icon lets you add a new plan.

## Node points

The **Node points** page shows all of the node points.




Figure 37. Node points page

## Settings

The **Settings** page lets you configure the Smart Polling settings.




Figure 38. Settings page

### Disable progressive mode

You can select this to disable all progressive mode and pause all progressive plans.

### Enable progressive mode

You can select this to enable progressive mode for selected strategies.

### Strategy

This dropdown is only enabled when the Enable progressive mode checkbox is selected. The dropdown lets you select from a list of strategies.

## Health

The **Health** page lets you monitor the status of the **CPU** threads that Smart Polling is using, as well as queued jobs.




Figure 39. Health page

## Create a Smart Polling plan

The **Plans** page lets you create a new Smart Polling plan.

### About this task

Some of the options that follow depend on which strategy that you choose. Not all options apply to all strategies.

### Procedure

1. In the top navigation bar, select **Smart Polling**.

**Result:** The **Smart Polling** page opens.


2. In the top right, select **Plans**.

**Result:** The **Plans** page opens.

3. In the top right, select **New plan**.

**Result:** A dialog shows.

4. In the **Label** field, enter a name for the plan.



The screenshot shows a 'Plan configuration' dialog box with a close button (X) in the top right corner. The dialog has a title bar with the text 'Plan configuration' and a 'Label' input field. Below the title bar, there are four sections: 'Strategy' with a dropdown menu labeled 'Choose a strategy', 'Host to test' with an input field containing 'e.g. 192.168.1.1' and a 'Check connection' button, 'Schedule' with an input field labeled 'Run interval in seconds', and 'Query' with an input field labeled 'Query'. At the bottom right of the dialog, there are two buttons: 'New plan' (blue) and 'Cancel' (white).

5. In the **Strategy** dropdown, select a strategy.



#### Note:

You can use the **Credentials manager** to add credentials to the nodes that the plan targets.

6. In the **Schedule** field, enter a value (seconds) for the run interval.

7. If applicable, in the **Target** section, select an option:

**Choose from:**

- **Use identities**
  - **Use query**
  - a. **Optional:** If you chose **Use identities**, choose the applicable credentials. To do this, select them from the list on the left and add them to the list on the right.
  - b. **Optional:** If you chose **Use query**, the result of the query determines the list of node points. If necessary, use the **Credentials manager** to add credentials to the nodes targeted by the plan.
8. If applicable, from the **Data to be collected** dropdown, select the specific items to collect for the selected strategy.



**Note:**

The items shown are a generic list. The options available will vary depending on the specific target [OS](#) version, or the local configuration.

9. Verify that Smart Polling can connect correctly to a given node.

- a. In the **Host to test** field, enter an [IP](#) address of the node that you want to check.
- b. Select **Check connection**.

**Result:** If the connection check is successful, a green tick will show.

10. View the results to determine if the Smart Polling plan is correct. You can also troubleshoot potential problems, such as incorrect credentials, or Guardian being unable to reach plan nodes.

## Edit a Smart Polling plan

*It is possible to edit a Smart Polling plan that already exists.*

### Procedure

1. In the top navigation bar, select **Smart Polling**.

**Result:** The **Smart Polling** page opens.

2. In the top right, select **Plans**.

**Result:** The **Plans** page opens.

3. To the left of the name of the applicable plan, select the  icon.

**Result:** A dialog shows.

4. In the **Strategy** field, note the existing strategy.



**Note:**

When you edit a plan, you cannot change its strategy. For strategies that require credentials, you will need to use the **Credentials manager** to add credentials to the set of nodes to be polled when using a query.

5. In the **Schedule** field, enter a value in seconds.

6. In the **Target** section, select an option:

**Choose from:**

- **Use identities**
- **Use query**

7. **Optional:** If you chose **Use identities**, choose the identities corresponding to the targeted nodes from the list on the left.

8. **Optional:** If you chose **Use query**, the result of the query determines the list of node points. Use the **Credentials manager** to add credentials to the nodes targeted by the plan.

9. Select **Edit plan**.



## Add a network node to a Smart Polling plan

*After you have created a plan, you can add a node, or multiple nodes, to it.*

### Procedure

1. In the top navigation bar, select **Smart Polling**.

**Result:** The **Smart Polling** page opens.

2. In the top right, select **Plans**.

**Result:** The **Plans** page opens.


3. To the left of the name of the applicable plan, select the **>** icon.

**Result:** The details for the plan show.

4. Select **+** **Add nodes to plan**.

**Result:** A dialog shows.

5. In the dialog, enter an *IP* address. If you want to add more than one *IP* address, enter each one on a new line.



The screenshot shows a dialog box titled "Add nodes to plan" with a close button (X) in the top right corner. Below the title, it says "Add one address per line:". There is a large, empty text input area with a light gray border. At the bottom right of the dialog, there are two buttons: a blue "Add" button and a white "Cancel" button with a gray border.

6. Select **Add**.

## Results

The node(s) has (have) been added to the Smart Polling plan.

## Add a node from the Network page

Once you have created a Smart Polling plan, you can add arbitrary nodes to the target from the Network page. The Smart Polling plan will poll these nodes even if the plan's query does not return them.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. In the top right, select **Nodes**.

**Result:** The **Nodes** page opens.

3. To the left of the name of the applicable plan, select the  icon.

**Result:** A dialog shows.

4. From the **Select an existing plan to add the node to** dropdown, select the plan you want to add the selected node to.



**Note:**

Fields that are not modified in this dialog are automatically populated with the plan-configured values.

**Result:** A dialog shows.

5. Edit the field(s) as necessary to change the parameter(s) of the existing plan.
6. Select **Add**.

### Results

The node(s) has (have) been added to the Smart Polling plan.

## Edit the run interval of a progressive Smart Polling plan

*You can manually adjust some aspects of Progressive mode plans. By default, each plan runs every 24 hours, but you can manually adjust this interval.*

### Procedure

1. In the top navigation bar, select **Smart Polling**.

**Result:** The **Smart Polling** page opens.

2. In the top right, select **Plans**.

**Result:** The **Plans** page opens.

3. To the left of the title of the plan that you would like to edit, select the  icon.

**Result:** A dialog opens.

4. In the **Schedule** field, edit the value (seconds) as necessary.



**Note:**

The default value is 86400 (seconds) or 24 hours.

5. To save your changes, select **Edit plan**.

## Progressive enablement

*You can enable progressive mode to increase visibility.*

Progressive mode is a Smart Polling option that increases visibility. To do this it automates plan creation and execution, and polls the correct nodes with the correct parameters based on asset information that has been detected passively.

Smart Polling automatically identifies the optimal target for polling. For example, only nodes that the query in the related strategy identifies will be polled.

You can select the Smart Polling strategies that you want to create a Progressive Smart Polling plan. Enabled Progressive Smart Polling plans show in the **Plans** tab.

## Enable progressive mode

You can enable *Progressive mode* to increase visibility.

### Procedure

1. In the top navigation bar, select **Smart Polling**.

**Result:** The **Smart Polling** page opens.

2. In the top right, select **Settings**.

**Result:** The **Settings** page opens.

3. In the **Smart Polling Progressive Mode Settings** section, select **Enable progressive mode**.

**Smart Polling Progressive Mode Settings**

☐ **Disable progressive mode**  
Disable progressive mode and pause all progressive plans

☒ **Enable progressive mode**  
Enable progressive mode for the selected strategies

---

**Strategy**

8 selected ▼

All None

- BACNet
- Dahua DHIP/DVRIP devices
- EthernetIP
- MELSOFT
- Modicon Modbus
- S7



#### Note:

If you select **Disable progressive mode** the progressive mode Smart Polling plans that have been newly created, will stop executing. Also, they will be, grayed-out in the **Plans** tab.

### Results

Progressive mode has been enabled.

## Log level customization

*Smart Polling logs self-diagnostic information about its operations and activities during execution.*

When Smart Polling logs self-diagnostic information, the logs are collected in these files:

- `/data/log/n2os/n2ossp.log`
- `/data/log/n2os/n2os_strategist.log`

To change the level of detail in the logs, you can run this command in the [CLI](#):

```
conf.user configure sp log_level <LEVEL>
```

where `<LEVEL>` is one of the following values (in increasing order of verbosity):

- `FATAL`
- `ERROR`
- `WARN`
- `INFO`
- `DEBUG`

**Note:**

The default value is `INFO`.

**Note:**

The values are ordered from the most to the least important, and the configured level is the minimum to be printed. For example:

- `ERROR` will print log lines for both `ERROR` and `FATAL` messages
- `FATAL` will print log lines only for `FATAL` messages

After you have changed and saved the file, you can restart Smart Polling with the command:

```
service n2ossp stop
```

**Note:**

The service automatically restarts after the execution of this command.

To configure the file to see only `ERROR` and `FATAL` messages, in the `/data/cfg/n2os.conf.user` file, you can add this rule:

```
sp log_level ERROR
```

then restart the process with the command:


```
service n2ossp stop
```

# View the enriched information history for a node

The **Node points** page lets you view the enriched information history for a node.

## Procedure

- 1. In the top navigation bar, select **Smart Polling**.  
**Result:** The **Smart Polling** page opens.
- 2. In the top right, select **Node points**.  
**Result:** The **Node points** page opens.
- 3. In the left column, select a node point.



**Result:** The second and third columns show an increased level of detail for the extracted information for that node point



## Chapter 7. Arc overview



**Arc™** is a host-based sensor that detects and defends against malicious or compromised endpoints, and insider attacks. You can use Arc sensors to aggregate data for analysis and reports, either on-premises, or in the Vantage cloud.

## General

When detecting cyberthreats, identifying vulnerabilities, or analyzing anomalies in your processes, it is critical to have as much detailed network and system information as possible. More accurate and timely access to data leads to better diagnostics and a faster time to repair.

Arc gives you enhanced endpoint data collection and asset visibility for your networks. This enhanced visibility gives you more:

- Vulnerability assessment capabilities
- Endpoint protection
- Traffic analysis capabilities
- Accurate diagnostics of in-progress threats and anomalies

Arc lets you easily identify compromised hosts that have:

- Malware
- Rogue applications
- Unauthorized [USB](#) devices
- Suspicious user activity

## Operating Systems (OS)

Arc sensors are endpoint executables that run on hosts on these [OSs](#):

- Microsoft Windows
- Linux
- Apple macOS

The data that is collected can be sent to either Guardian or Vantage.

## Use cases and deployment scenarios

Arc lets you:

- Incorporate air-gapped devices into the analysis and reporting system
- Gain deeper intelligence or insight on critical endpoint devices
- Continuously monitor and protect endpoints
- Automatically deploy sensors across thousands of devices
- Use a low-impact process to scan air-gapped networks
- Deploy with solutions

## Continuous monitoring

Because the Arc sensor is on the host, it can monitor traffic continuously, even when the device is not sending or receiving traffic.

## User-specific activity monitoring

With more access to endpoint data, Arc lets you connect network traffic and anomalies with specific users. This helps to identify potential insider threats and makes corrective actions both easier and quicker.

## Local behavioral analysis (Sigma rules)

Sigma is a common open-source standard that lets you analyze log files to identify malicious events. They are not necessarily related to network artifacts, and as such, would not be detected without residing on a machine. Nozomi Networks Labs curates all the Sigma rules that are loaded into Arc. A [Threat Intelligence \(TI\)](#) active license is needed to receive curated rules from the upstream Nozomi Networks endpoint.

## Temporary deployment

It is not necessary to keep the Arc executable on a host after you have collected information. This means that you can remove it after data has been collected to conserve host resources, and maintain a clean host environment.

## Threat prevention

Starting with v2.0, Arc enforces actions to prevent threats in addition to monitoring.

# Architecture

*It is important to understand the different architecture possibilities that are available with Arc.*

You can connect Arc:

- To Guardian
- To Vantage




Figure 40. Arc architecture example

## Arc in Guardian

The **Arc** button in the Guardian Web UI lets you access the different pages for Arc.



Figure 41. Arc button in Guardian Web UI



Figure 42. Arc button in Guardian Web UI (not connected to Vantage)

When you select **Arc** in the Guardian Web *user interface (UI)*, you get access to these pages:

- **Deployment**
- **Deployment settings**
- **Node points**
- **Dependencies** (only for Guardians that are not connected to Vantage)

### Configure an Arc sensor





Figure 43. Configure an Arc sensor

You can configure an individual Arc sensor directly from Guardian. To do this, you can select the applicable Arc sensor from the **Sensors** list, and select the  icon.

# Deployment

The **Deployment** page shows a table of all the devices available for Arc deployment. The table only shows machines which have an **OS** that matches one that Arc supports. As Guardian detects the installed **OS**, the correct Arc package will be automatically deployed.



| Actions                  | Deployed version | Operating system         | Name                    | IP                           | Vendor                  | Product name             | Type     |
|--------------------------|------------------|--------------------------|-------------------------|------------------------------|-------------------------|--------------------------|----------|
| <input type="checkbox"/> |                  | Windows 7                | 172.18.235.34           | 172.18.235.34                |                         |                          | computer |
| <input type="checkbox"/> |                  | Windows 7                | 172.16.44.92            | 172.16.44.92                 |                         |                          | computer |
| <input type="checkbox"/> |                  | Windows 7                | 172.16.44.134           | 172.16.44.134                |                         |                          | computer |
| <input type="checkbox"/> |                  | Windows 7                | 172.16.45.255           | 172.16.45.255                |                         |                          | computer |
| <input type="checkbox"/> |                  | macOS                    | Mac Series              | 192.168.179.198              | Apple                   | Mac Series               | computer |
| <input type="checkbox"/> | v1.710           | Windows 8.1 Update 1     | LSPW8                   | 10.41.50.18, fe80::5efea3... | VMware                  | Virtual Machine          | computer |
| <input type="checkbox"/> |                  | macOS                    | Apple M1-based Computr  | 192.168.180.73               | Apple                   | Apple M1-based Comput... | computer |
| <input type="checkbox"/> |                  | Windows 8.1 Update 1     | ENG-WMI-TEST            | 192.168.45.212, 192.168.4... | VMware                  | Virtual Machine          | computer |
| <input type="checkbox"/> |                  | Windows 10               | NUC                     | 169.254.23.208               |                         | Intel(R) Client Systems  | computer |
| <input type="checkbox"/> |                  | Windows Server 2022      | LSPW2022                | 10.41.50.17, fe80::4259fc... | VMware                  | Virtual Machine          | computer |
| <input type="checkbox"/> |                  | Windows 7 SPI            | LSPW7                   | 10.41.50.23, fe80::100:7f... | VMware                  | Virtual Machine          | computer |
| <input type="checkbox"/> |                  | Windows 7                | 172.30.68.31            | 172.30.68.31                 |                         |                          | computer |
| <input type="checkbox"/> |                  | Windows 7 SPI / Serve... | 172.16.46.69            | 172.16.46.69                 |                         |                          | computer |
| <input type="checkbox"/> | v1.4.2           | Ubuntu Linux 22.04       | ch-int-snmp-ubuntu-22.0 | 10.41.48.102, fe80::2505...  | VMware                  | Virtual Machine          | computer |
| <input type="checkbox"/> |                  | Ubuntu Linux 21.04       | ch-lab-raspdocker02     | 10.41.43.55, fe80::dea63...  | Raspberry Pi Foundation | Raspberry Pi SBC         | computer |
| <input type="checkbox"/> |                  | macOS                    | Apple M1-based Computr  | 192.168.178.129              | Apple                   | Apple M1-based Comput... | computer |
| <input type="checkbox"/> |                  | macOS                    | Apple M1-based Computr  | 192.168.175.25               | Apple                   | Apple M1-based Comput... | computer |
| <input type="checkbox"/> |                  | Windows 10               | NUC                     | 169.254.181.84               | Intel                   | Intel(R) Client Systems  | computer |

Figure 44. Deployment page

## Advanced

The **Advanced** button lets you access the **Advanced** page. For more details, see [Advanced \(on page 131\)](#).

## Execution details

The **Execution details** lets you access the **Activity Log**. For more details, see [Execution details \(on page 133\)](#).

## Live toggle

The **Live** toggle lets you change live view on, or off. When live mode is on, the page will refresh periodically.

## Refresh

The  icon lets you immediately refresh the current view.

## Actions

The **ACTIONS** column has a checkbox for each row in the table. This lets you select multiple nodes before you then apply an action to them.

The **ACTIONS** menu icon  gives you access to these options:

- Select all in current page
- Select none in current page
- Invert selection in current page
- Deploy Service mode: this installs Arc in Service mode for the selected devices
- Remove Service mode: this removes the Arc previously installed in Service mode for the selected devices

## Operating System

The **OPERATING SYSTEM** column shows the [OS](#) for each of the Arc sensors in the table. The field at the top of the column lets you use the [OS](#) to filter the table.

## IP

The **IP** column shows the *IP* for each of the Arc sensors in the table. The field at the top of the column lets you use the *IP* to filter the table.

## Vendor

The **VENDOR** column shows the vendor name for each of the Arc sensors in the table. The field at the top of the column lets you use the vendor name to filter the table.

## Product name

The **PRODUCT NAME** column shows the product name for each of the Arc sensors in the table. The field at the top of the column lets you use the product name to filter the table.

## Type

The **TYPE** column shows the device type for each of the Arc sensors in the table. The field at the top of the column lets you use the device type to filter the table.

## Advanced

The **Advanced** page lets you interact with nodes that have no operating system (OS) detected, or do not show on the same page in the table.

The default table view only shows nodes that have had their **OS** detected. Also, if you select multiple nodes, actions will only be applied to a single page of nodes. To overcome these limitations, you can use the **Advanced** button to go to the **Advanced** page. This will let you interact with a:

- Set of nodes that cannot be shown on a single page
- Set of nodes that have no OS detected

Strategy

Automatic \*

☐ Dynamic strategy based on existing OS information. It uses WinRM (Windows Remote Management, port 5985/5986) and SSH (Server Message Block, port 445) on Windows hosts and Ssh or Unix hosts. Hosts without any OS information will be ignored.

Dynamic

Remove

Query

{successful queries} {failed queries}

☒

nodes | where ip in (\$CLAMRIP) &where no include? windows OR no include? linux OR no include? macos |include links

☐

Credentials are read from the Credential Manager. If identities for the nodes in scope are already present, no further action is needed.

Timeout (seconds)

30

### Figure 45. Advanced page

### Strategy

**Automatic:** This selection will use the [OS](#) that has been detected on the node to automatically choose a deployment strategy. You can select multiple nodes that have a different [OS](#). This strategy will ignore a host if it has no [OS](#).

**SSH (Linux):** This selection will force the [secure shell \(SSH\)](#) strategy, regardless of the [OS](#), and deploy the correct Arc package for Linux.

### Query

This field lets you create and execute queries on the nodes. This lets you filter and selectively install packages.

### Timeout (seconds)

The **Timeout** dropdown lets you set the amount of time that Arc will try to communicate with a host machine before it skips it and goes to the next one.



## Execution details

The **Execution details** button gives you access to the **Activity Log**.

The **Activity Log** lets you troubleshoot the results of the executed deployments. When you select an execution on the left side of the page, you can analyze the selection.

You can use the **Filter by node ID** to focus on a single issue, such as:

- Credential missing, or
- Wrong credentials

Activity Log - Arc operations Live 

5 executions of the plan

|                         |         |
|-------------------------|---------|
| 2023-03-21 13:02:07.337 | 1 nodes |
| 2023-03-21 13:01:36.990 | 1 nodes |
| 2023-03-21 13:00:21.120 | 1 nodes |
| 2023-03-21 12:58:56.541 | 1 nodes |
| 2023-03-21 12:58:35.902 | 1 nodes |

Filter by node ID

**Execution details**

Started at: 2023-03-21 13:02:07.337.  
Lasted 7195 milliseconds.  
1 nodes polled.

10.41.48.16 7149 ms

| Steps                                                                | Node points |
|----------------------------------------------------------------------|-------------|
| ✓ Fetching credentials                                               |             |
| ✓ Using credentials from Credentials Manager for node: [10.41.48.16] |             |
| ✓ Establishing connection                                            |             |
| ✓ Fetching remote host architecture                                  |             |
| ✓ Fetching Arc status                                                |             |
| ✓ Arc uninstalled                                                    |             |

## Live toggle

The **Live** toggle lets you change live view on, or off. When live mode is on, the page will refresh periodically.

## Refresh

The  icon lets you immediately refresh the current view.

## Node points

The **Node points** page shows data points that are collected over time, and represent the state of the target machine.




Figure 46. Node points page in Guardian

### Node points count

This shows the number of the nodes polled.

### Filter by node ID

This field lets you use the node *ID* to filter the nodes.

### Live toggle

The **Live** toggle lets you change live view on, or off. When live mode is on, the page will refresh periodically.

### Refresh

The  icon lets you immediately refresh the current view.


### Nodes

The list of nodes that show at least one node point.

## Chapter 8. Network



The **Network** page gives you access to multiple pages that show nodes, links, sessions in tabular format and graphs and traffic in a graphical format.



**Figure 47. Network page**

The **Network** page has these tabs:

- [Nodes \(on page 138\)](#)
- [Links \(on page 148\)](#)
- [Physical links \(on page 158\)](#)
- [Sessions \(on page 159\)](#)
- [Traffic \(on page 164\)](#)

# Nodes

The **Nodes** page lets you view all the network nodes in your environment and perform actions on them.

Network

NodesLinksPhysical linksSessionsTraffic

Page 1 of 471 11757 entries

ExportLive9 selected

| Actions | Address       | Roles      | MAC address       | Sent byte... | Received byte... | TCP retrans... | # Links... | Protocols            |
|---------|---------------|------------|-------------------|--------------|------------------|----------------|------------|----------------------|
|         | 10.43.1.201   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | mms                  |
|         | 10.43.1.202   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 0          |                      |
|         | 10.43.1.203   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | mms                  |
|         | 10.43.1.224   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | mms                  |
|         | 10.43.1.223   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 0          |                      |
|         | 10.16.1.214   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | mms                  |
|         | 10.43.1.1     | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 0          |                      |
|         | 10.30.1.1     | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 0          |                      |
|         | 172.17.229.31 | other      | 00:08:a3:f1:d9:0  | 1.3 MB       | 0.0 B            | 0.0%           | 0          |                      |
|         | 10.16.1.102   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 0          |                      |
|         | 10.16.1.101   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 3          | http, modbus         |
|         | 10.16.1.1     | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | http                 |
|         | 10.16.1.103   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | http                 |
|         | 10.16.1.114   | other      | -                 | 0.0 B        | 0.0 B            | 0.0%           | 1          | modbus               |
|         | 172.16.39.113 | other      | 00:50:56:94:78:00 | 60.1 MB      | 23.5 MB          | 8.1%           | 1          | ms-sql-server        |
|         | 172.30.147.75 | other      | 00:08:a3:f1:e0:8  | 267.3 MB     | 301.6 MB         | 28.7%          | 2          | other                |
|         | 172.17.73.36  | other      | 00:08:a3:f1:d9:0  | 4.8 MB       | 0.0 B            | 8.5%           | 1          | https                |
|         | 172.22.1.32   | web_server | 38:0e:4d:29:22:6e | 119.0 MB     | 25.2 MB          | 40.8%          | 1          | http                 |
|         | 10.64.45.23   | other      | 00:08:a3:f1:#20   | 12.6 MB      | 22.6 MB          | 0.0%           | 0          |                      |
|         | 172.22.2.223  | web_server | 38:0e:4d:29:22:6e | 22.4 MB      | 11.3 MB          | 11.1%          | 1          | http                 |
|         | 34.237.73.95  | web_server | 38:0e:4d:29:22:6e | 12.6 MB      | 9.2 MB           | 2.7%           | 5          | https, ssh, telnet   |
|         | 172.28.1.8    | other      | 00:26:99:a6:e2:f9 | 2.1 MB       | 0.0 B            | 0.0%           | 1          | dns                  |
|         | 74.6.34.27    | web_server | 38:0e:4d:29:22:6e | 7.6 MB       | 24.0 MB          | 15.9%          | 3          | https                |
|         | 172.16.38.170 | db_server  | 00:50:56:94:22:b4 | 51.3 MB      | 41.4 MB          | 19.0%          | 2          | https, ms-sql-server |
|         | 172.30.1.54   | other      | 00:08:a3:f1:d9:0  | 2.1 MB       | 0.0 B            | 0.0%           | 0          |                      |

1234567... 471

Figure 48. Nodes page

## Export

The **Export** icon lets you export the current list in either **CSV** or Microsoft Excel format.

## Live / refresh

The **Live** icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## Column selection

The columns selection icon lets you choose which columns to show or hide.

## Configure a node

The **Nodes** page lets you configure nodes.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Nodes**.


**Result:** The **Nodes** page opens.

3. To the left of the applicable node, select the configure  icon.

**Result:** A dialog shows.

4. **Optional:**

To make the node(s) invisible in network graph view, select **Is disabled**.



Configure ea:be:af:86:54:d8

☐ **Is disabled**  
When a node is disabled it becomes invisible in the network graph view

**Label**

**Level**

**Device ID override**

Enter a name or click on the arrow on the right to choose between available assets

**Save** **Cancel**

5. From the **Label** dropdown, select an asset and assign the node to it.
6. In the **Level** field, enter a level in accordance with the Purdue model classification.
7. From the **Device ID override** dropdown, remove or re-assign Device ID to overwrite the automatically assigned **Device ID**.
8. Select **Save**.

## Results

The node has been configured.

## Show alerts for a node

The **Nodes** page lets you show alerts for a selected node.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Nodes**.

**Result:** The **Nodes** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A list of all the requested traces for the node shows.

## Show requested traces for a node

The **Nodes** page lets you show requested traces for a selected node.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Nodes**.

**Result:** The **Nodes** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A list of all the requested traces for the node shows.



## Request a trace for a node

The **Nodes** page lets you request a trace for a selected node.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Nodes**.

**Result:** The **Nodes** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A dialog shows.

4. To set the maximum packet size, in the **Trace max size (packets)** field, enter a value.

Request a trace

Trace max size (packets)

5000

Trace max duration (seconds)

60

Packet filter

[BPF syntax help](#) [BPF examples](#) ▾

ip host 192.168.68.65

Send trace request

Cancel

**Note:**

The default size is 5000 packets.

5. To set the maximum duration of the trace, in the **Trace max duration (seconds)** field, enter a value.

**Note:**

The default value is 60 seconds.

6.

**Note:**

The **Packet filter** field is automatically populated with a [Berkeley Packet Filter \(BPF\)](#) that captures the packets to/from the selected node, but you can customize this.

If necessary, customize this field.

**Note:**

You can select **BPF syntax help** to show more information on [BPF](#) syntax.

**Note:**

You can select **BPF examples** to see some examples.

7. Select **Send trace request**.

## Results

The trace has been requested.

## Manage learning for a node

The **Nodes** page lets you manage the learning for a selected node.

### About this task

The **Manage Learning** dialog lets you learn and delete the entire node and its individual details, such as [IP](#) or [MAC](#) address.

**Note:**

The icon adjacent to the node shows its status. When the node details are:

- A green icon shows when the node details have been entirely learned
- An orange icon shows when the node details are only partially learned
- A red icon shows when the node details have not been learned

Individual details have either a green or red icon, depending on whether they are learned or not. When you learn, or delete a node, all of its details are affected in the same way. When you learn, or delete, an individual detail, only that detail's learning status changes.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Nodes**.

**Result:** The **Nodes** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A dialog shows.

#### 4. Optional:

Select an item(s) to delete.

Manage Learning 192.168.68.65

Delete

Learn

Save

Discard

Nodes

192.168.68.65

IP: 192.168.68.65

MAC Address: 84:e3:42:dd:29:5f

#### Choose from:

- To delete the **IP** address, select the checkbox to the left.
- To delete the **MAC** address, select the checkbox to the left.
- To delete the node, and both the **IP** and **MAC** addresses, select the checkbox to the left.

- Select  **Delete** to delete the selected item(s).

#### 5. Optional: Select an item(s) to learn.

#### Choose from:

- To learn the **IP** address, select the checkbox to the left.
- To learn the **MAC** address, select the checkbox to the left.
- To learn the node, and both the **IP** and **MAC** addresses, select the checkbox to the left.

- Select  **Learn** to learn the selected item(s).

#### 6. Select **Save**.

## Navigate from a node

The **Nodes** page lets you navigate to related entities from a selected node.

### Procedure

- In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

- Select **Nodes**.

**Result:** The **Nodes** page opens.

144

guardian-user v25.6.0 2025-11-03

3. In the Actions column, to the left of the applicable node, select the  icon.

**Result:** A list of related entities shows.

4. Select the hyperlink that you want to navigate to.

Go to [fe80::14ab:4e17:4c9d:84e9](#) [Node]  
Go to [mdns](#) [Protocol]  
Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Link]  
Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Link]  
Go to [fe80::14ab:4e17:4c9d:84e9](#) [Vulnerabilities]  
Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Sessions]  
Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Sessions]

## Results

The entity shows in the applicable page.

## Add a node to a Smart Polling plan

The **Nodes** page lets you add a node to an existing Smart Polling plan.

### About this task

The Smart Polling icon only shows if Smart Polling is present.

## Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Nodes**.

**Result:** The **Nodes** page opens.

3. To add a node to a plan with an optionally different configuration from the plan's original one, in the Actions column, to the left of the applicable node, select the  icon.

**Result:** A dialog shows.

4. From the **Select an existing plan to add the node to** dropdown, select an existing plan to that you would like to add the node to.

### Smart polling configuration for **172.18.249.104** ✕

**Select an existing plan to add the node to**

My WinRM Plan ▼

**Data to be collected**

15 selected ▼

Specific Vulnerabilities Detection ▼

**Username**

nozomi

**Password**

Password

**Timeout (seconds)**

30

☐ Use SSL

**i** Fill in the fields for which you want to override the plan's configuration

Poll node immediately ☒

**Add** **Cancel**

5. **Optional:** In the **Timeout (seconds)** field, enter a value to override the value in the current plan.
6. **Optional:** To poll the node immediately, set the **Poll node immediately** toggle to on.

**Note:**

If you do not set the **Poll node immediately** toggle to on, the node will be polled at the next execution of the selected plan.

# Links

The **Links** page shows all the links in your environment.

Network

NodesLinksPhysical linksSessionsTraffic

Page 1 of 431 10762 entries

ExportLive11 selected

| Actions | From             | To            | Proto... | Last activi...   | # Alerts | Throughput | Transferred bytes | Transferred packets | TCP retrans. % | Is learned |
|---------|------------------|---------------|----------|------------------|----------|------------|-------------------|---------------------|----------------|------------|
|         | 772.24.77176     | 772.16.39.52  | https    | 11:22:24.891     | 0        | 0.0 b/s    | 39.3 MB           | 154 Kpp             | 76.4%          | true       |
|         | 10.161.101       | 10.161.103    | http     | never            | 0        | 0.0 b/s    | 0.0 B             | 0 pp                | 0.0%           | true       |
|         | 10.161.101       | 10.161.1      | http     | never            | 0        | 0.0 b/s    | 0.0 B             | 0 pp                | 0.0%           | true       |
|         | 10.161.101       | 10.161.134    | modbus   | never            | 0        | 0.0 b/s    | 0.0 B             | 0 pp                | 0.0%           | true       |
|         | 10.161.214       | 10.431.203    | mms      | never            | 0        | 0.0 b/s    | 0.0 B             | 0 pp                | 0.0%           | true       |
|         | 10.431.201       | 10.431.224    | mms      | never            | 0        | 0.0 b/s    | 0.0 B             | 0 pp                | 0.0%           | true       |
|         | 0008x3f7f990g172 | 10.119.32     | other    | 2025-06-06 21:12 | 0        | 0.0 b/s    | 58.0 B            | 1 pp                | 0.0%           | true       |
|         | 772.1717.47      | 52.96.8.778   | https    | 11:23:12.006     | 0        | 0.0 b/s    | 4.8 MB            | 35 Kpp              | 46.7%          | true       |
|         | 772.30.12.86     | 772.29.6.8    | smb      | 11:26:28.647     | 0        | 0.0 b/s    | 4.0 MB            | 31 Kpp              | 31.1%          | true       |
|         | 10.36.0.50       | 224.0.0.10    | other    | 11:24:41.052     | 0        | 0.0 b/s    | 7.3 MB            | 98 Kpp              | 0.0%           | true       |
|         | 772.24.77176     | 23.54.162.210 | http     | 11:12:47.172     | 0        | 0.0 b/s    | 106.3 MB          | 180 Kpp             | 75.1%          | true       |
|         | 772.24.77176     | 772.16.36.79  | smb      | 11:26:03.783     | 0        | 0.0 b/s    | 37.8 MB           | 262 Kpp             | 44.7%          | true       |
|         | 772.24.77176     | 772.16.51.10  | dns      | 11:12:10.673     | 0        | 0.0 b/s    | 7.5 MB            | 39 Kpp              | 0.0%           | true       |
|         | 135.89.151.245   | 10.34.77.2    | snmp     | 11:26:32.066     | 0        | 0.0 b/s    | 175.0 B           | 1 pp                | 0.0%           | true       |
|         | 10.3.3.233       | 10.5.6.4      | snmp     | 11:26:37.493     | 0        | 0.0 b/s    | 1.8 KB            | 21 pp               | 0.0%           | true       |
|         | 772.1795.77      | 191.101.194.2 | tcp443   | 11:26:28.893     | 0        | 0.0 b/s    | 66.0 B            | 1 pp                | 0.0%           | true       |
|         | 10.41.43.187     | 191.101.194.2 | tcp443   | 11:26:29.417     | 0        | 0.0 b/s    | 66.0 B            | 1 pp                | 0.0%           | true       |
|         | 772.18.161.68    | 772.16.161.90 | other    | 11:26:11.625     | 0        | 0.0 b/s    | 66.0 B            | 1 pp                | 0.0%           | true       |
|         | 772.16.711       | 10.8.18.182   | http     | 11:26:23.984     | 0        | 0.0 b/s    | 58.0 B            | 1 pp                | 0.0%           | true       |
|         | 772.16.39.62     | 772.17.81.27  | other    | 11:26:10.913     | 0        | 0.0 b/s    | 66.0 B            | 1 pp                | 0.0%           | true       |
|         | 772.16.37.102    | 772.17.109.39 | other    | 11:26:22.422     | 0        | 0.0 b/s    | 132.0 B           | 2 pp                | 0.0%           | true       |
|         | 772.19.25.29     | 772.16.36.101 | other    | 11:20:35.098     | 0        | 0.0 b/s    | 18.4 KB           | 371 pp              | 0.0%           | true       |
|         | 772.16.36.117    | 772.22.3.53   | http     | 11:26:17.843     | 0        | 0.0 b/s    | 62.0 B            | 1 pp                | 0.0%           | true       |
|         | 772.30.23.172    | 209.53.113.5  | http     | 11:26:29.658     | 0        | 0.0 b/s    | 132.0 B           | 2 pp                | 0.0%           | true       |
|         | 772.16.711       | 772.21.13.21  | dce-rpc  | 11:26:08.544     | 0        | 0.0 b/s    | 216.0 B           | 4 pp                | 0.0%           | true       |


2 3 4 5 6 7 ... 431

Figure 49. Links page

## Export

The **Export**  icon lets you export the current list in either **CSV** or Microsoft Excel format.

## Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Link events

Link events are shown in a graphical format.






Figure 50. Link events

## Availability

Link availability is based on UP and DOWN events.

## Time span

You can use the time span control to view only the events in the specified time range. The available options are:

- Zoom
- 1m(inute)
- 5m
- 30m
- 1h(our)
- 6h
- 12h
- 1d(ay)
- All

## Graphical history

A point with a value of 1 represents an UP event, a value -1 represents a DOWN event.

## Link availability

*A history of events is stored for each link.*

Two events are of particular interest for computing availability:

- UP - This occurs when an activity is detected on an inactive link
- DOWN - This occurs when an active link stops its activity

Each event has a timestamp to track the precise moment of its occurrence.

Guardian computes the total downtime of a link by taking into consideration the history of events within a finite time window. Then, it sums the time spans of all events starting with a DOWN event and ending with an UP event. All links are considered active by default. Therefore, the availability of the link is 100% minus the percentage of the total downtime.

### Track availability

The **Track availability** feature allows an accurate computation of availability. It enables the monitoring of activity on a link at regular intervals, generating extra UP and DOWN events, depending on the detected activity on both sides of the link during the last interval.

We recommend that you select a value greater than the expected link polling time to avoid checks that are too frequent and are likely to produce spurious DOWN events.

**link\_events** generation is disabled by default. To enable it, see the configuration rule shown in **Configuration**.

## Configure a link

The **Links** page lets you configure links.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Links**.

**Result:** The **Links** page opens.

3. To the left of the applicable link, select the configure  icon.

**Result:** A dialog shows.

4. **Optional:**

To raise an alert when a new **TCP** handshake is detected on the link, select **Is persistent**.

Configure 172.20.10.1-224.0.0.251/mdns 

☐ **Is persistent**

Raise an alert when a new TCP handshake is detected on this link

☐ **Alert on SYN**

Raise an alert when a TCP SYN packet is detected on this link

☐ **Track availability (seconds)**

Notify the link events when the link communication is interrupted or resumed

☐ **Last activity check (seconds)**

Raise an alert when the link become inactive for more than the specified amount of seconds

Save

Cancel

5. **Optional:** To raise an alert when a **TCP** SYN packet is detected on the link, select **Alert on SYN**.
6. **Optional:** To notify the link events when the link communication is interrupted or resumed., select **Track availability (seconds)** and enter a value.

7. **Optional:** To raise an alert when the link becomes inactive for more than the specified number of seconds, select **Last activity check (seconds)** and enter a value.
8. Select **Save**.

## Results

The link has been configured.

## Show alerts for a link

The **Links** page lets you show alerts for a selected link.

### Procedure

1. In the top navigation bar, select  **icon > Network**.  
**Result:** The **Network** page opens.
2. Select **Links**.  
**Result:** The **Links** page opens.
3. To the left of the applicable link, select the  icon.  
**Result:** A list of all the requested traces for the link shows.

## Show requested traces for a link

The **Links** page lets you show requested traces for a selected link.

### Procedure

1. In the top navigation bar, select  **icon > Network**.  
**Result:** The **Network** page opens.
2. Select **Links**.  
**Result:** The **Links** page opens.
3. To the left of the applicable link, select the  icon.  
**Result:** A list of all the requested traces for the link shows.

## Request a trace for a link

The **Links** page lets you request a trace for a selected link.

## Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.


2. Select **Links**.

**Result:** The **Links** page opens.

3. To the left of the applicable link, select the  icon.

**Result:** A dialog shows.

4. To set the maximum packet size, in the **Trace max size (packets)** field, enter a value.



Request a trace ×

**Trace max size (packets)**

5000

**Trace max duration (seconds)**

60

**Packet filter** [BPF syntax help](#) [BPF examples](#) ▼

ip host 192.168.68.65

**Send trace request** **Cancel**



**Note:**

The default size is 5000 packets.

5. To set the maximum duration of the trace, in the **Trace max duration (seconds)** field, enter a value.



**Note:**

The default value is 60 seconds.

6.  **Note:**  
The **Packet filter** field is automatically populated with a **BPF** that captures the packets to/from the selected link, but you can customize this.

If necessary, customize this field.

-  **Note:**  
You can select **BPF syntax help** to show more information on **BPF** syntax.

-  **Note:**  
You can select **BPF examples** to see some examples.

7. Select **Send trace request**.

## Results

The trace has been requested.

## Show events for a link

The **Links** page lets you show requested traces for a selected link.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Links**.

**Result:** The **Links** page opens.

3. To the left of the applicable link, select the  icon.

**Result:** A list of all the events for the link shows.

## Show captured URLs for a link

The **Links** page lets you show captured URLs for a selected link.

## Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Links**.

**Result:** The **Links** page opens.

3. To the left of the applicable link, select the  icon.

**Result:** A list of all the captured *uniform resource locator (URL)*s from the analyzed traffic for the link shows.

## Manage learning for a link

The **Links** page lets you manage the learning for a selected node.

### About this task

The **Manage Learning** dialog lets you learn and delete the entire node and its individual details, such as *IP* or *MAC* address.



#### Note:

The icon adjacent to the node shows its status. When the node details are:

- A green icon shows when the node details have been entirely learned
- An orange icon shows when the node details are only partially learned
- A red icon shows when the node details have not been learned

Individual details have either a green or red icon, depending on whether they are learned or not. When you learn, or delete a node, all of its details are affected in the same way. When you learn, or delete, an individual detail, only that detail's learning status changes.

## Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Links**.

**Result:** The **Links** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A dialog shows.

#### 4. Optional:

If necessary, select one, or more, items and select  **Delete**.

Manage Learning 192.168.68.65 ×

 Delete
  Learn
 Save Discard

☐  Nodes

☐  192.168.68.65
 

☐  IP: 192.168.68.65
 ☐  MAC Address: 84:e3:42:dd:29:5f

5. **Optional:** If necessary, select one, or more, items and select  **Learn**.

6. Select **Save**.

## Navigate from a link

The **Links** page lets you navigate to related entities from a selected node.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Links**.

**Result:** The **Links** page opens.



3. In the Actions column, to the left of the applicable node, select the  icon.

**Result:** A list of related entities shows.

4. Select the hyperlink that you want to navigate to.

Go to [fe80::14ab:4e17:4c9d:84e9](#) [Node]  
Go to [mdns](#) [Protocol]  
Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Link]  
Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Link]  
Go to [fe80::14ab:4e17:4c9d:84e9](#) [Vulnerabilities]  
Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Sessions]  
Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Sessions]

### Results

The entity shows in the applicable page.

# Physical links

The **Physical links** page lets you view all the physical links in your environment and perform actions on them. Smart Polling captures and displays the physical connections between the nodes in the physical graph. For switches, the graph also shows the physical port that maps each connection.

Network

NodesLinksPhysical linksSessionsTraffic

Page 1 of 240 entries

ExportLive8 selected

| Act...        | Node 1  | Port 1       | Node 2  | Port 2                         | Terminations            | First seen              | Last seen |
|---------------|---------|--------------|---------|--------------------------------|-------------------------|-------------------------|-----------|
|               |         |              |         |                                |                         |                         |           |
| 4.4.4.2       | 0       | 4.4.4.0      | 4       | 4.4.4.20-4.4.4.0.4             | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.16.1114    | unknown | 10.16.11     | 203     | 10.16.1114-unknown-10.16.11203 | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 2.2.2.0       | 0       | 11.1.0       | 0       | 2.2.2.0-11.1.0.0               | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 777.5         | 0       | 777.0        | 6       | 777.5-0-777.0.6                | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 172.20.65.25  | 0       | 11.1.0       | 10      | 172.20.65.25-0-11.1.0.10       | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.16.11      | 204     | 10.16.1214   | unknown | 10.16.11204-10.16.1214-unknown | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.43.11      | 200     | 10.43.1201   | unknown | 10.43.11200-10.43.1201-unknown | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 6.6.6.0       | 2       | 6.6.6.1      | 0       | 6.6.6.0-2-6.6.6.1.0            | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 2.2.2.0       | 3       | 4.4.4.0      | 0       | 2.2.2.0-3-4.4.4.0.0            | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 777.2         | 0       | 777.0        | 3       | 777.2-0-777.0.3                | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 5.5.5.0       | 0       | 4.4.4.0      | 1       | 5.5.5.0-0-4.4.4.0.1            | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.41.252.103 | 6       | 10.41.43.53  | 2       | 10.41.252.103-6-10.41.43.53.2  | 2025-06-23 13:38:16.067 | 2025-06-23 13:38:31.066 |           |
| 10.43.11      | 201     | 10.43.1202   | unknown | 10.43.11201-10.43.1202-unknown | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.30.11      | aa      | 10.16.11     | a       | 10.30.11aa-10.16.11a           | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 777.6         | 0       | 777.0        | 7       | 777.6-0-777.0.7                | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.43.11      | 204     | 10.43.1223   | unknown | 10.43.11204-10.43.1223-unknown | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 4.4.4.1       | 0       | 4.4.4.0      | 3       | 4.4.4.1-0-4.4.4.0.3            | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.43.11      | 202     | 10.43.1203   | unknown | 10.43.11202-10.43.1203-unknown | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 777.0         | 10      | 192.168.1.88 | 0       | 777.0-10-192.168.1.88.0        | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 777.0         | 5       | 777.4        | 0       | 777.0-5-777.4.0                | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 5.5.5.0       | 2       | 5.5.5.1      | 0       | 5.5.5.0-2-5.5.5.1.0            | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 6.6.6.0       | 1       | 777.0        | 1       | 6.6.6.0-1-777.0.1              | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 2.2.2.0       | 4       | 2.2.2.1      | 0       | 2.2.2.0-4-2.2.2.1.0            | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 10.16.11      | 202     | 10.16.1103   | unknown | 10.16.11202-10.16.1103-unknown | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |
| 11.1.0        | 1       | 11.1.1       | 0       | 11.1.0-1-11.1.1.0              | 2025-06-30 08:54:14.000 | 2025-06-30 08:54:14.000 |           |

Figure 51. Physical links page

## Export

The **Export** icon lets you export the current list in either **CSV** or Microsoft Excel format.

## Live / refresh

The **Live** icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## Column selection

The columns selection icon lets you choose which columns to show or hide.

## Sessions

A session is established at a certain point in time, and later turned down. An established communication session might involve more than one message in each direction.

| Network                                     |        |                 |                |            |                    |             |            |              |                     |                       |
|---------------------------------------------|--------|-----------------|----------------|------------|--------------------|-------------|------------|--------------|---------------------|-----------------------|
| Nodes Links Physical links Sessions Traffic |        |                 |                |            |                    |             |            |              |                     |                       |
| Page 1 of 923 23052 entries                 |        |                 |                |            |                    |             |            |              |                     |                       |
| Export Live 13 selected                     |        |                 |                |            |                    |             |            |              |                     |                       |
| Actions                                     | Status | From            | To             | Protocol   | Transport proto... | From por... | To port... | Throughpu... | Transferred byte... | Transferred packet... |
|                                             |        |                 |                |            |                    |             |            |              |                     |                       |
| ⚙️                                          | ACTIVE | 172.17.39.132   | 172.16.36.37   | other      | tcp                | 49282       | 445        | 0.0 b/s      | 66.0 B              | 1 pp                  |
| ⚙️                                          | ACTIVE | 166.159.61.11   | 172.16.153.54  | http       | tcp                | 80          | 52940      | 0.0 b/s      | 15.0 MB             | 14 Kpp                |
| ⚙️                                          | ACTIVE | 172.16.45.3     | 52.22.248.114  | https      | tcp                | 52204       | 443        | 0.0 b/s      | 8.8 KB              | 21 pp                 |
| ⚙️                                          | ACTIVE | 172.17.239.111  | 172.16.51.10   | dns        | tcp                | 53950       | 53         | 0.0 b/s      | 330.0 B             | 5 pp                  |
| ⚙️                                          | ACTIVE | 172.16.137.48   | 40.97.120.242  | http       | tcp                | 55750       | 80         | 0.0 b/s      | 372.0 B             | 6 pp                  |
| ⚙️                                          | ACTIVE | 172.16.66.90    | 172.16.36.30   | netbios-ns | udp                | 137         | 137        | 0.0 b/s      | 110.0 B             | 1 pp                  |
| ⚙️                                          | ACTIVE | 172.16.36.30    | 172.16.66.90   | icmp       | icmp               |             |            | 0.0 b/s      | 404.0 B             | 3 pp                  |
| ⚙️                                          | ACTIVE | 10.36.26.34     | 10.3.19.32     | other      | tcp                | 50206       | 2000       | 0.0 b/s      | 58.0 B              | 1 pp                  |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 43015       | 4789       | 0.0 b/s      | 853.0 B             | 1 pp                  |
| ⚙️                                          | ACTIVE | 192.168.179.116 | 184.24.102.94  | https      | tcp                | 62090       | 443        | 0.0 b/s      | 3.2 KB              | 12 pp                 |
| ⚙️                                          | ACTIVE | 172.16.40.4     | 172.30.34.33   | other      | tcp                | 53579       | 50000      | 0.0 b/s      | 7.5 KB              | 15 pp                 |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 44092       | 4789       | 0.0 b/s      | 582.0 B             | 1 pp                  |
| ⚙️                                          | ACTIVE | 172.30.9.58     | 172.16.44.254  | other      | udp                | 4172        | 4172       | 0.0 b/s      | 240.0 KB            | 2 Kpp                 |
| ⚙️                                          | ACTIVE | 172.17.108.177  | 52.113.194.131 | other      | tcp                | 63528       | 443        | 116.0 b/s    | 58.0 B              | 1 pp                  |
| ⚙️                                          | ACTIVE | 172.16.36.90    | 172.16.56.43   | oracle-tns | tcp                | 62841       | 1521       | 0.0 b/s      | 497.0 B             | 2 pp                  |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 42745       | 4789       | 1.5 kb/s     | 1.7 KB              | 7 pp                  |
| ⚙️                                          | ACTIVE | 10.64.89.21     | 10.24.0.34     | capwap     | udp                | 64993       | 5247       | 0.0 b/s      | 2.3 KB              | 11 pp                 |
| ⚙️                                          | ACTIVE | 172.16.67.69    | 172.22.0.82    | http       | tcp                | 57513       | 80         | 0.0 b/s      | 3.5 KB              | 5 pp                  |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 39839       | 4789       | 0.0 b/s      | 365.6 KB            | 1 Kpp                 |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 45265       | 4789       | 0.0 b/s      | 1.2 KB              | 3 pp                  |
| ⚙️                                          | ACTIVE | 172.17.18.49    | 40.97.120.194  | other      | tcp                | 53776       | 443        | 0.0 b/s      | 54.0 B              | 1 pp                  |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 51570       | 4789       | 0.0 b/s      | 208.0 B             | 2 pp                  |
| ⚙️                                          | ACTIVE | 172.16.7.11     | 172.24.1.113   | icmp       | icmp               |             |            | 0.0 b/s      | 60.0 B              | 1 pp                  |
| ⚙️                                          | ACTIVE | 10.41.43.197    | 172.16.134.64  | smb        | tcp                | 64770       | 445        | 0.0 b/s      | 55.0 B              | 1 pp                  |
| ⚙️                                          | ACTIVE | 172.16.8.191    | 239.11.1       | vlan       | udp                | 36091       | 4789       | 0.0 b/s      | 251.0 B             | 1 pp                  |

Figure 52. Sessions page

### Export

The **Export**  icon lets you export the current list in either *CSV* or Microsoft Excel format.

### Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Show requested traces for a session

The **Sessions** page lets you show requested traces for a selected node.

## Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Sessions**.

**Result:** The **Sessions** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A list of all the requested traces for the session shows.

## Request a trace for a session

*The **Sessions** page lets you request a trace for a selected node.*

## Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Sessions**.

**Result:** The **Sessions** page opens.

3. To the left of the applicable node, select the  icon.

**Result:** A dialog shows.

4. To set the maximum packet size, in the **Trace max size (packets)** field, enter a value.

Request a trace

Trace max size (packets)

5000

Trace max duration (seconds)

60

Packet filter

[BPF syntax help](#) [BPF examples](#)

ip host 192.168.68.65

Send trace request

Cancel

**Note:**

The default size is 5000 packets.

5. To set the maximum duration of the trace, in the **Trace max duration (seconds)** field, enter a value.

**Note:**

The default value is 60 seconds.

6.  **Note:**  
The **Packet filter** field is automatically populated with a [BPF](#) that captures the packets to/from the selected node, but you can customize this.

If necessary, customize this field.

-  **Note:**  
You can select **BPF syntax help** to show more information on [BPF](#) syntax.

-  **Note:**  
You can select **BPF examples** to see some examples.

7. Select **Send trace request**.

## Results

The trace has been requested.

## Navigate from a session

The **Sessions** page lets you navigate to related entities from a selected node.

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Sessions**.

**Result:** The **Sessions** page opens.

3. In the Actions column, to the left of the applicable node, select the  icon.

**Result:** A list of related entities shows.

4. Select the hyperlink that you want to navigate to.

Go to [fe80::14ab:4e17:4c9d:84e9](#) [Node]

Go to [mdns](#) [Protocol]

Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Link]

Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Link]

Go to [fe80::14ab:4e17:4c9d:84e9](#) [Vulnerabilities]

Go to [fe80::14ab:4e17:4c9d:84e9 / Any / Any](#) [Sessions]


Go to [Any / fe80::14ab:4e17:4c9d:84e9 / Any](#) [Sessions]

### Results

The entity shows in the applicable page.

# Traffic

The **Traffic** page shows charts with information about throughput, protocols, and open transmission control protocol (TCP) connections.



## Throughput by type

This section shows traffic by macro category.

## Throughput by protocol

This section shows traffic by protocol.

## Protocols by data size

This section shows the proportion of packets sent by protocol, in pie chart format.

## Protocols by packets count

This section shows the proportion of traffic generated by protocol, in pie chart format.

## TCP connections

This section shows the number of open **TCP** connections.



## Details page

The details page lets you view more detailed information for a network.




Figure 53. Network details page

This details page shows more details for a network.

The top section of the screen contains generic data. You can hover your mouse over the information **i** icon to display the source, granularity and confidence of the corresponding piece of data. Data includes:

- IP (address)
- Roles
- Vendor
- MAC address
- MAC vendor

The details window has these tabs:


- Overview (on page 68)
- Sessions (on page 69)
- Alerts (on page 70)
- Software (on page 71)
- Vulnerabilities (on page 72)
- Variables (on page 73)
- Network graph (on page 74)
- Physical graph (on page 75)
- Hardware components (on page 76)



## Chapter 9. Graph



The **Graph** pages gives a graphical representation of the nodes in the environment.



**Figure 54. Graph page**

The **Graph** page has these tabs:

- [Network \(on page 170\)](#)
- [Assets \(on page 173\)](#)
- [Physical \(on page 177\)](#)

# Network

The **Network** page displays a live graph of connected assets, links, and filters in your network. You can apply filters, adjust the layout, and select node and link perspectives. Interactive options let you customize the visualization and export reports.




Figure 55. Network page

## Generate PDF report

The generate PDF  icon lets you create a **PDF** report of the selected item, which will show in the **Reports** page when it is ready.

## Filters

This indicates active graph filtering, when present. Filters can be from the filter bar (see R and S below), or activated from the zone/topology graph when you select a link/node in the zone/topology graphs. Once a filter is enabled with a value, the graph is automatically updated. If more than one filter is enabled, then a logical and criteria is applied. Only nodes that satisfy all of the specified filters are shown.

**Note:**

If a node passes the filters, then all of the directly connected nodes are shown in the graph. For example if a specific **IP** filter is used, then the specified node is shown along with all the nodes connected to it.

## Reset


This resets customizations and reloads the data.

### Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Time

These icons let you select an activity time range.



For more details, [Magic wand \(on page 183\)](#).

### Nodes

This dropdown lets you select node visualization configuration options.

Nodes ▾

**Perspective:**

Roles ▾

**Roles:**

Choose a role ▾

**Exclude IDs:**

192.168.1.1,192.168.1.2,...

**ID filter:** ☐ **Exact match**

10.197.2,192.168.1.2,...

**Display:**


ID (label) ▾

☐ **Show broadcast**

☒ **Only confirmed nodes**

Apply

## Links



This dropdown lets you configure visualization options.

## Layout

This dropdown lets you select a layout for the graph. For more details, see [Layout \(on page 181\)](#).

## Play-pause

The play-pause  icon lets you pause, or restart the motion of the graph.

## Increase-Decrease icon size

The increase  and decrease  icons lets you change the size of the icons in the graph.



## Assets

The **Assets** page shows linked assets as graph vertices when available, and defaults to node display when no asset is associated. This view provides a contextual representation of asset relationships within the network topology.




Figure 56. Assets page

### Overview

The asset graph groups nodes by asset when possible, unlike the standard network graph. For example, if an asset includes two nodes, the network graph displays two separate icons, one for each node, while the asset graph displays a single icon that represents the asset.

In the case that a node does not belong to an asset then the asset graph shows the node itself.

### Generate PDF report

The generate PDF  icon lets you create a [PDF](#) report of the selected item, which will show in the **Reports** page when it is ready.

### Filters

This indicates active graph filtering, when present. Filters can be from the filter bar (see R and S below), or activated from the zone/topology graph when you select a link/node in the zone/topology graphs. Once a filter is enabled with a value, the graph is automatically updated. If more than one filter is enabled, then a logical and criteria is applied. Only nodes that satisfy all of the specified filters are shown.

**Note:**

If a node passes the filters, then all of the directly connected nodes are shown in the graph. For example if a specific **IP** filter is used, then the specified node is shown along with all the nodes connected to it.

**Reset**


This resets customizations and reloads the data.

**Live / refresh**

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

**Time**

These icons let you select an activity time range.



For more details, [Magic wand \(on page 183\)](#).

**Nodes**

This dropdown lets you select node visualization configuration options.

Nodes ▼

**Perspective:**

Roles ▼

**Roles:**

Choose a role ▼

**Exclude IDs:**

192.168.1.1,192.168.1.2,...

**ID filter:**

☐ Exact match

10.197.2,192.168.1.2,...

**Display:**

ID (label) ▼

☐ Show broadcast

☒ Only confirmed nodes

Apply

## Links

Links

**Perspective:**

None ▼

Apply

This dropdown lets you configure visualization options.

## Layout

This dropdown lets you select a layout for the graph. For more details, see [Layout \(on page 181\)](#).

### Play-pause

The play-pause  icon lets you pause, or restart the motion of the graph.

### Increase-Decrease icon size

The increase  and decrease  icons lets you change the size of the icons in the graph.

## Physical

The **Physical** page displays a real-time interactive map of all physical device connections in the network. Nodes are shown only if a physical link has been detected for them. The graph, shows how devices connect at the cable level. It is a live, visual way to understand your physical network layout down to the port.




Figure 57. Physical page

### Overview

The Physical graph view provides a visual representation of cable-level connections between devices in the network. It uses data collected through Smart Polling and system integrations to display physical links in a dynamic topology graph that reflects actual hardware wiring, including switch port details.

This view supplements logical graphs by showing real-time or historical physical connectivity between assets. Devices are positioned based on link data, with visual indicators that show port assignments and device types. Use the Physical graph to examine network structure, trace physical paths, and identify connectivity changes.

### Generate PDF report

The generate PDF  icon lets you create a [PDF](#) report of the selected item, which will show in the **Reports** page when it is ready.

## Filters

This indicates active graph filtering, when present. Filters can be from the filter bar (see R and S below), or activated from the zone/topology graph when you select a link/node in the zone/topology graphs. Once a filter is enabled with a value, the graph is automatically updated. If more than one filter is enabled, then a logical and criteria is applied. Only nodes that satisfy all of the specified filters are shown.



### Note:

If a node passes the filters, then all of the directly connected nodes are shown in the graph. For example if a specific *IP* filter is used, then the specified node is shown along with all the nodes connected to it.

## Reset


This resets customizations and reloads the data.

## Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## Time

These icons let you select an activity time range.



For more details, [Magic wand \(on page 183\)](#).

## Nodes

This dropdown lets you select node visualization configuration options.

Nodes ▼

**Perspective:**

Roles ▼

**Roles:**

Choose a role ▼

**Exclude IDs:**

192.168.1.1,192.168.1.2,...

**ID filter:**

☐ Exact match

10.197.2,192.168.1.2,...

**Display:**

ID (label) ▼

☐ Show broadcast

☒ Only confirmed nodes

Apply

## Links

Links

**Perspective:**

None ▼

Apply

This dropdown lets you configure visualization options.

## Layout

This dropdown lets you select a layout for the graph. For more details, see [Layout \(on page 181\)](#).

### Play-pause

The play-pause  icon lets you pause, or restart the motion of the graph.

### Increase-Decrease icon size

The increase  and decrease  icons lets you change the size of the icons in the graph.



## Graph controls

*A list of the different control options in the graph view.*


|                                                                       |                                                                                                                                                    |
|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Move                                                                  | Click and drag anywhere in the graph other than on a node.                                                                                         |
| Zoom (mode 1)                                                         | With the cursor positioned inside the graph window, scroll the mouse forward or backward. Zoom is centered on the mouse position.                  |
| Zoom (mode 2)                                                         | With the cursor positioned inside the graph window, press Z on the keyboard and move the mouse up or down. Zoom is centered on the mouse position. |
| Increase icon and text size.                                          | Select the  icon.                                                 |
| Decrease icon and text size.                                          | Select the  icon.                                                 |
| View detailed information for a node or link in the information pane. | Select a node or link with a single click                                                                                                          |
| Show a new window with additional information for a node              | Select a node with a double click                                                                                                                  |
| Show a node or link                                                   | Move your mouse over the node or link                                                                                                              |
| Show a node or link, and the elements directly connected to it        | Click and hold your mouse button on a node or link without releasing it                                                                            |

## Layout

The **Layout** dropdown lets you select a layout for the graph.

The options are:

- [Standard \(on page 182\)](#)
- [Purdue model \(on page 182\)](#)
- [Grouped \(on page 182\)](#)
- [Clustered \(on page 183\)](#)



### Standard

This is the default layout. The type of visualization depends on the criteria defined in [Group by \(on page 183\)](#):

- [Group by \(on page 183\)](#) not defined: All of the nodes and links are shown
- [Group by \(on page 183\)](#) defined: Nodes that belong to the same group (based on the defined criteria) are collapsed into a single node

### Purdue model

Nodes are arranged in separate rows, according to their level. You can distinguish the levels and isolate potential communication problems that cross two or more levels.

### Grouped

Nodes are grouped according to the criteria defined in [Group\\_by](#). The graph is visualized as follows:

- [Group by \(on page 183\)](#) not defined: All nodes and links are shown.
- [Group by \(on page 183\)](#) defined: Nodes that belong to the same group are shown and are placed inside a circle that represents the group. Links between nodes within the same group are shown. However, links between groups are replaced with lines that connect the circles

## Clustered

Nodes are clustered according to the criteria below. Once nodes are clustered, a single circle represents the node cluster. Upon zoom-in, the circle expands and the internal nodes display. A cluster may contain multiple subclusters. This layout is useful when visualizing large graphs because it provides an overview of the graph, along with sufficient details.

Nodes are clustered depending on the values defined by Group\_by:

- [Group by \(on page 183\)](#) not defined: Nodes are clustered based on connections. Nodes with a large number of links act as a cluster center with neighboring nodes assigned to the same cluster
- [Group by \(on page 183\)](#) defined: At the highest level, a cluster is created for each group. Inside each high level cluster are subclusters created around nodes with a high number of links. For example, if Group\_by=Zones, then a cluster is created for each zone, and inside each zone other subclusters may be created around nodes with a high number of links

## Group by

This dropdown lets you define the group used for Standard, Grouped, and Clustered layouts. Nodes with the chosen property, such as zone or subnet, are assigned to the same group. The group displays depending on the selected layout.

The **Group by** dropdown lets you select from:

- Asset
- Cluster
- Level
- Roles
- Subnet
- Type
- Zone
- Site
- Host

## Magic wand

*The magic wand icon opens a wizard to help filter the graph and view only the desired information to help you reduce visualized data from large graphs.*

The graph wizard gives hints to help you improve the graph performance. Settings that are annotated with an orange exclamation point are considered suboptimal. Settings annotated with green thumbs are considered helpful.




Figure 58. Magic wand dialog

### Show broadcast

Broadcast addresses are not actual network nodes in that no asset is bound to a broadcast address. They are used to represent communications that a node uses towards an entire subnet. Removing broadcast nodes reduces the complexity of a graph.

### Only with confirmed data

You can select this to hide unconfirmed links to reduce the complexity of an entangled graph.

### Only confirmed nodes

You can select this to hide unconfirmed nodes to reduce the size of a large graph.

### Exclude tangled nodes

To improve the readability of the graph, you can select this to exclude nodes whose connections cause the graph to be too complex.

### Protocols

This dropdown lets you filter nodes and edges to show only those items that are communicating with the related protocol(s).

## Chapter 10. Process



*Process is a set of repeatable functions that a business does to deliver a core value.*

Process includes:

- Repeatable tasks
- Data collection
- Resource control in accordance with business policies

Variables model communication between operational devices as they participate in the industrial process.

Individual values within operational devices are represented as variables, and Guardian tracks them over time in **Process**.

The **Process** page has these tabs:

- [List \(on page 188\)](#)
- [Protocol connections \(on page 189\)](#)
- [Settings \(on page 190\)](#)

# List

The **List** page shows detailed information about variables in your environment.




Figure 59. List page

## Export

The **Export**  icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

## Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## Column selection

The columns selection  icon lets you choose which columns to show or hide.



## Protocol connections

The **Protocol connections** page lets you configure the additional parameters necessary to extract information contained inside certain protocols.




Figure 60. Protocol connections page

### Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

# Settings

The **Settings** page lets you configure which strategy to use to extract variables inside the process that are being communicated over different protocols.

Global variables extraction

☐ Disabled

Global variable extraction is disabled. Variables that are already present won't be persisted and will be discarded upon reboots. It prevails over protocol specific settings.

☒ Enabled

Global variable extraction is enabled. Protocol specific settings prevail.

☐ Advanced

Try to extract more variables by applying heuristic techniques to some protocols. Protocol specific settings prevail.

Limit the extraction to the selected zones

Select the zones ▼

Save

Protocol specific variables extraction

Page 1 of 1, 0 entries

Live

| ACTIONS ... | PROTOCOL    | VARIABLES CO... | LEVEL | ZONES |
|-------------|-------------|-----------------|-------|-------|
|             | <div></div> |                 |       |       |

There is no protocol with at least one variable

Figure 61. Process variable extraction tuning

Disabled

This checkbox lets you disable global variables extraction.

Enabled

This checkbox lets you enable global variables extraction.

Advanced

This checkbox lets you try to apply heuristic techniques to some protocols to extract more variables. Protocol specific settings prevail.

Limit the extraction to the selected zones

This dropdown lets you Limit the extraction to the selected zones.

190

guardian-user v25.6.0 2025-11-03

## Configure a variable

The **List** page lets you navigate to related nodes, links, vulnerabilities, or sessions.

### Procedure

1. In the top navigation bar, select  icon > **Process**.

**Result:** The **Process** page opens.

2. Select **List**.

**Result:** The **List** page opens.

3. To the left of the applicable *variable*, select the configure  icon.

**Result:** A dialog shows.

4. In the **Label** field, enter a label for the *Variable*.

Configure **192.168.45.159/0/ptp\_time** ×

**Label**

☐ **Enable history**  
Permits to enable history for this variable.

☐ **Last activity check**  
  
Raise an alert when the variable is not updated for more than the specified amount of seconds

☐ **Invalid quality check**  
  
Raise an alert when the variable keeps the invalid quality for more than the specified amount of seconds

☐ **Disallowed qualities check**  
  
Raise an alert when the variable has one of the specified qualities. Possible values are: invalid, not topical, blocked, substituted, overflow, reserved, questionable, out of range, bad reference, oscillatory, failure, inconsistent, inaccurate, test, alarm. Multiple values can be separated by comma.

**Unit**  
  
The unit of measurement of the variable value

**Scale**  
  
A constant value multiplied to the variable value

**Offset**  
  
A constant value added to the variable value

5. **Optional:** If necessary, select the **Enable history**.

**Note:**

This lets you enable [Variable](#) history.

6. **Optional:** If necessary, select the **Last activity check**.

**Note:**

This triggers an alert when the [Variable](#) is not updated for more than the specified amount of seconds.

7. **Optional:** If necessary, select the **Invalid quality check**.

**Note:**

This triggers an alert when the [Variable](#) keeps the invalid quality for more than the specified amount of seconds.

8. **Optional:** If necessary, select the **Disallowed qualities check**.

**Note:**

This triggers an alert when the [Variable](#) has one of the listed qualities. You can use a comma to separate values.

9. In the **Unit** field, enter a value.  
10. In the **Scale** field, enter a value.  
11. In the **Offset** field, enter a value.

## Results

The [Variable](#) has been configured.



5. **Optional:** To export the results, select **Export** 
6. **Optional:** To update the chart to real-time, select **Live update**.

## Favorite a variable

The **List** page lets you add a [Variable](#) to the favorite variables.

### Procedure

1. In the top navigation bar, select  icon > **Process**.

**Result:** The **Process** page opens.

2. Select **List**.

**Result:** The **List** page opens.

3. To the left of the applicable [Variable](#), select the search  icon.

**Result:** The [Variable](#) is added to the Favorite variables list.



## Navigate from a variable

The **List** page lets you navigate to related nodes, links, vulnerabilities, or sessions.

### Procedure

1. In the top navigation bar, select  icon > **Process**.  
**Result:** The **Process** page opens.
2. Select **List**.  
**Result:** The **List** page opens.
3. To the left of the applicable variable, select the navigate  icon.  
**Result:** A dialog shows.
4. Select the desired link.

Go to **192.168.45.159** [host Node]

Go to **ptpv2-ip** [Protocol]

Go to **192.168.45.159 / Any / ptpv2-ip** [Link]

Go to **Any / 192.168.45.159 / ptpv2-ip** [Link]

Go to **192.168.45.159** [Vulnerabilities]

Go to **192.168.45.159 / Any / ptpv2-ip** [Sessions]


Go to **Any / 192.168.45.159 / ptpv2-ip** [Sessions]



## Chapter 11. Reports



The **Reports** page lets you manage, generate, schedule and view reports.



**Figure 62. Reports page**

The **Reports** page has these tabs:

- [Dashboard](#) (on page 202)
- [Management](#) (on page 203)
- [Generated](#) (on page 206)
- [Scheduled](#) (on page 207)
- [Settings](#) (on page 208)

# Dashboard

The Dashboard page shows an overview of information related to reports, which includes disk availability, report settings, generated reports, report management, and scheduled reports.




Figure 63. Dashboard page

## Disk

This section shows:

- Available disk space
- Disk space used by reports

## Management

This section shows a summary of information from the [Management \(on page 203\)](#) page.

## Settings

This section shows a summary of information from the [Settings \(on page 208\)](#) page.

## Generated

This section shows a summary of information from the [Generated \(on page 206\)](#) page.

## Scheduled

This section shows a summary of information from the [Scheduled \(on page 207\)](#) page.

## Management

The **Management** page lets you manage all your reports.




Figure 64. Management page

### New report

This button lets you [Create a report \(on page 209\)](#).

### Import schema

This button lets you [Import a schema \(on page 216\)](#).

### Report list

This section shows a list of created and saved reports. You can [add folders \(on page 214\)](#) to group the reports in.

### Add page

This button lets you add a page to the bottom of the current report.

### Save

This button lets you save the changes to the current report.

### Edit

This button lets you edit the current report.

### Delete

This button lets you delete the current report.

### Filters

This button lets you filter the contents of the current report.

Edit filters for report 'Alerts'

Filter on assets

where device\_id = yyy

Filter on alerts

where id = 1

Filter on nodes

where ip = 192.168.1.12

Filter on node\_cpes

where node\_id = 1.1.1.2

Filter on links

where protocol = smb

Filter on node\_cves

where node\_id = 192.168.1.12

Filter on captured\_urls

where url = www.youtube.com

Filter on captured\_logs

where id\_src = 192.168.1.12

ⓘ

These filters will not work on the widgets: CISControl\_7, CISControl\_12, Vulnerability scoring overview, Evidences, Vendors, Vulnerability key findings

Ok

Cancel

Figure 65. Filter dialog

### Export schema

This button lets you [export a schema \(on page 217\)](#) for the current report in *JavaScript Object Notation (JSON)* format.



## Generate report

The generate report  icon lets you [generate a report \(on page 211\)](#) in one of these formats:

- [PDF](#)
- [CSV](#)
- Microsoft Excel

# Generated

The **Generated** page lets you view, download, edit, and delete generated reports.




Figure 66. Generated page

## Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## Column selection

The columns selection  icon lets you choose which columns to show or hide.

## Scheduled

The **Scheduled** page lets you view, download, edit, and delete scheduled reports.




Figure 67. Scheduled page

### Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection  icon lets you choose which columns to show or hide.

# Settings

The **Settings** page lets you change report settings, upload custom logos, and configure simple mail transfer protocol (SMTP) settings.

Reports

DashboardManagementGeneratedScheduledSettings

Custom logo

Report custom logo not yet uploaded.

Drop an image here or click to upload

Supported formats: JPG, PNG and GIF. Logo ideal sizes: 360x90 or bigger. Logo ideal ratio: 4:1 or similar

SMTP Server

An SMTP server is required to send scheduled reports by email at each recurrence (if the 'Email recipients' field is set)

ONOFF

To URI

HOST[:PORT]/[ID]

Sender

STARTTLS

Authentication Mechanism:PLAINLOGIN

Username

Password

Save

Figure 68. Settings page

## Custom logo

This section lets you [upload a custom logo \(on page 218\)](#) that will show in your reports.

## SMTP server

If you want to send emails that contain scheduled reports, you need to [configure \(on page 220\)](#) the *simple mail transfer protocol (SMTP)* server settings.

## Create a report

The **Management** page lets you create a new report.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.


**Result:** The **Reports** page opens.

2. Select **Management**.

3. In the section on the left, select **New report**.

**Result:** A dialog shows.

4. In the **Name** field, enter a name for the report.



The dialog box titled "New report" contains the following fields and controls:

- Name:** A text input field with a blue border.
- Layout:** A dropdown menu with the text "Choose a layout ▼".
- Folder:** A dropdown menu with the text "<uncategorized> ▼".
- Group visibility:** A dropdown menu with the text "Choose one or more groups ▼".
- Widget spacing:** A numeric input field with the value "20" and a spinner control.
- Buttons:** "Ok" (blue) and "Cancel" (white) buttons at the bottom right.

5. From the **Layout** dropdown, select a layout for the report.
6. From the **Folder** dropdown, select a folder for the report.
7. From the **Group visibility** dropdown, select the group(s) that will be able to view the report.

8. From the **Widget spacing** dropdown, enter a value.
9. Select **Ok**.

### Results

The report has been created.

## Generate a report

*You can generate both scheduled, or on-demand, reports, in multiple file formats.*

### Procedure

1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.


2. Select **Management**.
3. In the section on the left, select the report that you want to generate.
4. In the top right, select **Generate Report**.

**Result:** A dialog shows.

5. In the **Report type** section, choose a format for the report:

**Choose from:**

- [PDF](#)
- [CSV](#)
- Excel



The dialog box titled "Generate Report" contains the following elements:

- Report type**: Three buttons labeled "PDF", "CSV", and "Excel".
- Report execution**: Two buttons labeled "On-demand" and "Scheduled".
- A checkbox labeled "Include only Alerts following Security Profile [Applies to Alert widgets only]".
- At the bottom right, two buttons: "Save" (blue) and "Cancel" (grey).

6. In the **Report execution** section, choose the type of execution:

**Choose from:**

- On-demand
- Scheduled

7. If you chose **On-demand**, select **Save**.

**Result:** The report starts to generate. When the generation is complete, the report will show in the [Generated \(on page 206\)](#) page.

8. If you chose **Scheduled**, do the steps below.

a. In the **Recurrence (server time)** section, enter the settings that you want.

**Generate Report**

**Report type**

PDF CSV Excel

**Report execution**

On-demand Scheduled

**Schedule report creation**

**Recurrence (server time)**

Daily Weekly Monthly

Hours 0 Minutes 0

ⓘ Schedule occurrences will be relative to server time (current server time: 13:40:14.751 [-2 hours])

**User defined name**

**Email recipients (comma separated)**

☐ Include only Alerts following Security Profile [Applies to Alert widgets only]

**Save** **Cancel**

b. **Optional:** In the **User defined name** field, enter a name for the report.

c. **Optional:** In the **Email recipients (comma separated)** field, enter the email addresses of the people that you would like to receive the reports.

d. **Optional:** If necessary, select the **Include only Alerts following Security Profile [Applies to widgets only]** checkbox.



## Results

The report has been generated, or scheduled, as applicable.

## Download a report

The **Generated** page lets you download reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.  
**Result:** The **Reports** page opens.
2. Select **Generated**.
3. To the left of the applicable report, select the download  icon.  
**Result:** The download starts.

## Results

The report has been downloaded to your downloads folder.

## Delete a report

The **Generated** page lets you delete generated reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.  
**Result:** The **Reports** page opens.
2. Select **Generated**.
3. To the left of the applicable report, select the download  icon.

## Results


The report has been deleted.

## Add a folder

The **Management** page lets you add folders for you to organize your reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.  
**Result:** The **Reports** page opens.
2. Select **Management**.
3. In the **Reports list** section on the left, select **Add folder**.  
**Result:** A dialog shows.
4. In the **Name** field, enter a name for the folder.



The dialog box is titled "New report folder" and has a close button (X) in the top right corner. It contains two main sections: "Name" and "Group visibility". The "Name" section has a text input field with a vertical cursor. The "Group visibility" section has a dropdown menu with the text "Choose one or more groups" and a downward arrow. At the bottom right, there are two buttons: "Ok" (blue) and "Cancel" (white with a grey border).

5. From the **Group visibility** dropdown, select the group(s) that will be able to view the reports.
6. Select **Ok**.

### Results

The folder has been added.

## Edit a folder

The **Management** page lets you delete reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.


2. Select **Management**.

3. In the section on the left, to the right of the applicable folder's name, select the download  icon.

**Result:** A dialog shows.

4. **Optional:**

If necessary, in the **Name** field, edit the name of the folder.



The screenshot shows a dialog box titled "Edit report folder 'Miscellaneous'". It has a close button (X) in the top right corner. Inside the dialog, there are two main sections. The first section is labeled "Name" and contains a text input field with the text "Miscellaneous" and a cursor at the end. The second section is labeled "Group visibility" and contains a dropdown menu with the text "guests" and a downward arrow. At the bottom right of the dialog, there are two buttons: "Ok" (blue) and "Cancel" (white with a grey border).

5. **Optional:** If necessary, in the **Group visibility** field, edit the visibility of the folder.
6. Select **Ok**.

### Results

The report has been edited.

## Delete a folder

The **Management** page lets you delete reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.  
**Result:** The **Reports** page opens.
2. Select **Management**.
3. In the section on the left, to the right of the applicable folder's name, select the download  icon.

### Results

The report has been deleted.

## Import a schema

The **Management** page lets you import a schema that has previously been exported.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.  
**Result:** The **Reports** page opens.
2. Select **Management**.
3. In the section on the left, select **Import Schema**.
4. Select the schema to import.

### Results

The schema has been imported.

## Export a schema

The **Management** page lets you export a schema.

### Procedure


1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.

2. Select **Management**.
3. In the top right, select **Export Schema**.

**Result:** A dialog shows.

4. In the **Export file name** field, enter a name for the schema.



Choose file name

Export file name

reports\_2023927

Export

5. Select **Export**.

### Results

The schema has been exported in **JSON** format.

## Upload a custom logo

You can add a custom logo that will show in your reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.

2. Select **Settings**.

**Result:** The [Settings \(on page 208\)](#) page opens.

3. Choose a method to upload a custom logo:

**Choose from:**

- Drag your image file into the **Drop an image here or click to upload** field
- Click in the **Drop an image here or click to upload** field

4. If you chose the second method, select the correct file to upload.

### Custom logo

Report custom logo not yet uploaded.

Drop an image here or click to upload

Supported formats: JPG, PNG and GIF. Logo ideal sizes: 360x90 or bigger. Logo ideal ratio: 4:1 or similar



**Note:**

Logos should be 360x90 pixels or bigger, with an ideal aspect ratio of 4:1, or similar.



**Note:**

Supported formats are:

- *graphics interchange format (GIF)*
- *joint photographic experts group (JPEG)*
- *portable network graphics (PNG)*

5. Wait for the file to upload.

6. Select **Save**.

## Results

Your custom logo will now be added to your reports.

## Configure SMTP settings

If you want to send emails that contain scheduled reports, you need to configure the simple mail transfer protocol (SMTP) server settings.

### Procedure


1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.

2. Select **Settings**.

**Result:** The [Settings \(on page 208\)](#) page opens.

3. In the **SMTP Server** section, set the toggle to **ON**.



The screenshot shows the 'SMTP Server' configuration section. At the top, there is a title 'SMTP Server' and an information icon with a note: 'An SMTP server is required to send scheduled reports by email at each recurrence (if the 'Email recipients' field is set)'. Below this is a toggle switch currently set to 'OFF'. The form includes several input fields: 'To URI' with a placeholder 'HOST[:PORT][ID]', 'Sender', 'STARTTLS' (unchecked checkbox), 'Authentication Mechanism' with radio buttons for 'PLAIN' (selected) and 'LOGIN', 'Username', and 'Password'. A blue 'Save' button is at the bottom left.

4. In the **To URI** field, enter the host URI information. For example, **HOST[:PORT][ID]**
5. In the **Sender** field, enter the sender identification information.



6. To use encryption, select the **STARTTLS** checkbox.

**Note:**

If you do not select this option, reports will be sent without encryption.

7. To start the authentication process, choose an Authentication Mechanism:

**Choose from:**

- **PLAIN**
- **LOGIN**

**Note:**

The default setting is **PLAIN**.

8. If you chose **LOGIN**, enter your credentials.
- a. In the **Username** field, enter your username.
  - b. In the **Password** field, enter your password.
9. Select **Save**.

## Results

Emails for scheduled reports that have email recipients will now be sent at the next scheduled occurrence.

## Filter a report globally

*You can filter a report globally, which is the default filter. This lets you use a specific category to apply filters to the entire report.*

### Procedure

1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.

2. Select **Management**.

**Result:** The [Management \(on page 203\)](#) page opens.

3. In the top section, select  **Filters**.

**Result:** A dialog shows.

4. Select the category on which to filter, then enter your filter query in the related field.

## Edit filters for report 'Alerts'

**Filter on assets**

where device\_id = yyy

**Filter on alerts**

where id = 1

**Filter on nodes**

where ip = 192.168.1.12

**Filter on node\_cpes**

where node\_id = 1.1.1.2

**Filter on links**

where protocol = smb

**Filter on node\_cves**

where node\_id = 192.168.1.12

**Filter on captured\_urls**

where url = www.youtube.com

**Filter on captured\_logs**

where id\_src = 192.168.1.12

 These filters will not work on the widgets: CISControl\_7, CISControl\_12, Vulnerability scoring overview, Evidences, Vendors, Vulnerability key findings

Ok

Cancel

5. Select **Ok**.

**Note:**

At the bottom of the dialog is a list of widgets on which filters will not work.

## Results


The filter(s) has (have) been applied to the report.

## Add a widget to a report

The **Management** page lets you add widgets to reports.

### Procedure

1. In the top navigation bar, select  icon > **Reports**.  
**Result:** The **Reports** page opens.
2. Select **Management**.  
**Result:** The [Management \(on page 203\)](#) page opens.
3. In the **Reports list** section on the left, select the applicable report.  
**Result:** The report opens.
4. On the right side of the report, choose the section that you want to add the widget to. Select **Add widget**.  
**Result:** A dialog shows.
5. In the left pane, choose the type of widget that you want to add.



6. From the list, select the widget that you want.

**Results**

The widget has been added to the report.

## Filter a report with a widget

*You can use widgets to filter a report.*

### Procedure

1. In the top navigation bar, select  icon > **Reports**.

**Result:** The **Reports** page opens.

2. Select **Management**.

**Result:** The [Management \(on page 203\)](#) page opens.


3. In the **Reports list** section on the left, select the applicable report.

**Result:** The report opens.

4. Find the widget that you would like to use and hover your mouse over it.

**Result:** At the top of the widget, more buttons show.

5. Select **Edit filter**.



6. Select the category on which to filter, then enter your filter query in the related field.

### Edit filters for widget 'Node and asset counters' ✕

**Filter on assets**

**Filter on nodes**

 These filters will not work on the widgets: CISControl\_7, CISControl\_12, Vulnerability scoring overview, Evidences, Vendors, Vulnerability key findings

**Ok** **Cancel**

7. Select **Ok**.

**Note:**

At the bottom of the dialog is a list of widgets on which filters will not work.

## Results

The filter(s) has (have) been applied to the report.



## Chapter 12. Assertions



The **Assertions** page shows all the assertions and lets you configure them.

A valid assertion is a normal query with a special command appended at the end. Assertions can be saved in a specific order and can be continuously executed in the system.

Queries are based on the [N2QL](#), which you can use to ensure that certain conditions are met on the observed system. An assertion is typically either an empty value, or a specific value. When an unexpected value appears, or when the value is different than the expected, the system alerts the user.




Figure 69. Assertions page

## Configure

This lets you configure the execution interval in seconds.

## History button

This button shows a history of the previous queries that have been entered in the query field.

## Query field

This field is where you enter your query.

## Debug button

Because assertions with logical operators and brackets can quickly become complex, the debug icon decomposes the query, and executes each part to show intermediate results.




Figure 70. Complex assertion being debugged

### New group

This lets you create a group to combine assertions to make viewing and management easier.

### Export

This lets you export assertion groups in *JSON* format.

### Import

This lets you import assertion groups in *JSON* format.

## Assertion operators

Table 2. Assertion operators

| Operator                                                       | Description                                                                                               |
|----------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|
| <code>assert_all &lt;field&gt; &lt;op&gt; &lt;value&gt;</code> | The assertion is satisfied when each element in the query result set matches the given condition.         |
| <code>assert_any &lt;field&gt; &lt;op&gt; &lt;value&gt;</code> | The assertion is satisfied when at least one element in the query result set matches the given condition. |
| <code>assert_empty</code>                                      | The assertion is satisfied when the query returns an empty result set.                                    |
| <code>assert_not_empty</code>                                  | The assertion is satisfied when the query returns a non-empty result set.                                 |

## Save an assertion

*You can save assertions to have them continuously executed in the system.*

### Procedure


1. In the top navigation bar, select  icon > **Assertions**.

**Result:** The **Assertions** page opens.

2. In the query field, enter a query.
3. Select **Enter**.
4. To save the assertion, select **Save**.

**Result:** A dialog shows.

5. In the **Name** field, enter a name for the query.



The screenshot shows a 'Save assertion' dialog box with the following fields and options:

- Name**: A text input field, currently empty.
- Description**: A text input field, currently empty.
- Note**: A text input field, currently empty.
- Group**: A dropdown menu with the text 'Choose a group...' and a downward arrow. A 'New group' link is located to the right of the dropdown.
- Is security ?**: A radio button option, currently unselected.
- Is operational ?**: A radio button option, currently selected (indicated by a green dot).
- Assertion Check Interval**: A text input field containing the value '10'.
- Can send alerts**: A checkbox, currently unchecked.
- Choose the asserted table's specific fields to include in the Description**: A dropdown menu with the text 'Choose fields to include...' and a downward arrow.
- Query**: A text input field containing the query 'links | where protocol == telnet | assert\_empty'.
- Buttons**: 'Save' (blue) and 'Cancel' (grey) buttons at the bottom right.

6. In the **Description** field, enter a description.

7. To assign the assertion to a group, in the **Group** field, select one of the following
  - a. From the dropdown menu, select an existing group.
  - b. Select **Save**.
  - c. To create a new group, select **New group**.  
**Result:** A dialog shows.
  - d. In the **Group name** field, enter a group name for the assertion.
  - e. Select **Save**.

8. Choose from one of these options:

**Choose from:**

- **Is security ?**
- **Is operational ?**

9. In the **Assertion Check Interval** field, choose the interval in seconds at which the assertion will be rechecked.



**Note:**

You can select an interval between 10 seconds and 1 day.

10. **Optional:** If you want the assertion to trigger an alert, select the **Can send alerts** checkbox.
11. From the **Choose the asserted table's specific fields to include in the Description** dropdown, select the fields to include in the assertion description.
12. In the **Query** field, enter the assertion query.
13. Select **Save**.

**Result:** The saved assertion will be listed at the bottom of the page with a green or red color to indicate the result.



## Edit an assertion

This lets you edit the details for an existing assertion.

### Procedure

1. In the top navigation bar, select  icon > **Assertions**.

**Result:** The **Assertions** page opens.

2. In the query field, enter a query.
3. To execute the query, elect **Enter**.



#### Note:


You can use the logical operators && (and) and || (or) to combine multiple assertions. Round brackets ( ) change the logical grouping as in a mathematical expression.

4. **Optional:** To the right of the query field, select the debug  icon.



#### Note:

Because assertions with logical operators and brackets can quickly become complex, the debug icon decomposes the query, and executes each part to show intermediate results.



**Assertions** Configure

Query: `((links | where protocol == telnet | assert_empty && links | where protocol == iec104 | assert_empty) && (nodes | where is_learned == false | assert_empty))`

**Result** `((links | where protocol == telnet | assert_empty && links | where protocol == iec104 | assert_empty) && (nodes | where is_learned == false | assert_empty))`

**Debug**

| Query                                            | Result | Query without assertion           |
|--------------------------------------------------|--------|-----------------------------------|
| links   where protocol == telnet   assert_empty  | true   | links   where protocol == telnet  |
| links   where protocol == iec104   assert_empty  | false  | links   where protocol == iec104  |
| nodes   where is_learned == false   assert_empty | false  | nodes   where is_learned == false |

**Live assertions** Current group: links New group Edit group Delete group Export Import

Page 1 of 1 entries

| ACTIONS                                                                                                                                                                                                                                                     | NAME      | FAILED SYNC... | # FAILURES | PACKET FILTER | CAN SEND ALERTS | IS SECURITY | CAN REQUEST TRACE | ALERT DELAY | ALERT RISK | CREATED A...            |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|----------------|------------|---------------|-----------------|-------------|-------------------|-------------|------------|-------------------------|
|    | ldp links | never          | 0          |               | false           | false       | false             | 10          | 0          | 17:22:52.301 links   wh |

**Result:** The debug section shows.

## Configure an assertion

*This lets you configure the execution interval of the assertions, in seconds.*

### Procedure


1. In the top navigation bar, select  icon > **Assertions**.

**Result:** The **Assertions** page opens.

2. In the top right, select **Configure**.

**Result:** A dialog opens.

3. In the **Execution interval (seconds)** field, enter an interval.



Configure assertions

**Execution interval (seconds)**

10

Change the execution interval of the assertions

Save Cancel

4. Select **Save**.

## Configure an assertion on links

*This lets you configure the scope of the assertion for the related links.*

### Procedure

1. In the top navigation bar, select  icon > **Network**.

**Result:** The **Network** page opens.

2. Select **Links**.

**Result:** The **Links** page opens.

3. To the left of the applicable link, select the configure  icon.

**Result:** A dialog opens.

4. **Optional:**

Select **Is persistent**.

Configure 192.168.68.52-255.255.255.255/other 

☐ **Is persistent**

Raise an alert when a new TCP handshake is detected on this link

☐ **Alert on SYN**

Raise an alert when a TCP SYN packet is detected on this link

☐ **Track availability (seconds)**

Notify the link events when the link communication is interrupted or resumed

☐ **Last activity check (seconds)**

Raise an alert when the link become inactive for more than the specified amount of seconds

Save

Cancel

**Note:**

When selected, this check raises a new alert whenever a [TCP](#) handshake is successfully completed on the link.

5. **Optional:** Select **Alert on SYN**.



**Note:**

When selected, this check raises a new alert whenever a client sends a TCP SYN on the link.

6. **Optional:** Select **Track availability (seconds)**.



**Note:**

When selected, a link is considered non-functioning if it is unresponsive for the specified time.

7. **Optional:** Select **Last activity check (seconds)**.



**Note:**

When selected, this check raises an alert when the link is not receiving data for more than the specified time.

8. Select **Save**.

## Results

The assertion has been configured.

## Configure an assertion on variables

*This lets you configure the scope of the assertion for the related variables.*

### Procedure

1. In the top navigation bar, select  icon > **Process**.

**Result:** The **Process** page opens.

2. Select **List**.

**Result:** The **List** page opens.

3. To the left of the applicable link, select the configure  icon.

**Result:** A dialog opens.

#### 4. Optional:

In the **Label** field, enter a label for the assertion.

Configure 10.168.1.54/1/ir9

**Label**

ir9 at RTU 1

**History size**

0

Set the variable history size. When size is 0, history is disabled. When is higher than 0, it is enabled and the size value suggests the system how many values should be kept, according to resources availability.

☐ **Last activity check**

Raise an alert when the variable is not updated for more than the specified amount of seconds

☐ **Invalid quality check**

Raise an alert when the variable keeps the invalid quality for more than the specified amount of seconds

☐ **Disallowed qualities check**

Raise an alert when the variable has one of the specified qualities. Possible values are: invalid, not topical, blocked, substituted, overflow, reserved, questionable, out of range, bad reference, oscillatory, failure, inconsistent, inaccurate, test. Multiple values can be separated by comma.

#### 5. Optional: In the **History size** field, enter a value.

**Note:**

This sets the [Variable](#) history size. When the size is 0, history is disabled. When it is higher than 0, it is enabled, and the size value suggests how many values that the system should keep, depending on the available resources.

6. **Optional:** In the **Last activity check** field, enter a value.



**Note:**

When selected, this check raises an alert when the [Variable](#) is either not measured or is changed for more than the specified number of seconds.

7. **Optional:** In the **Invalid quality check** field, enter a value.



**Note:**

When selected, this check raises an alert when the [Variable](#) maintains an invalid quality for more than the specified amount of seconds.

8. **Optional:** In the **Disallowed quality check** field, enter a value.



**Note:**

When selected, this check raises an alert when the [Variable](#) gains one of the specified qualities.

9. Select **Save**.

## Results

The assertion has been configured.





## Chapter 13. Time machine



Time machine lets you load a snapshot, which is a previously saved state, and go back in time, to analyze the data from a past situation. You can load a single snapshot and use the platform as usual or load two snapshots and compare the user interface to highlight changes.

| ACTIONS | ID         | TIME                    | NODES COUNT | LINKS COUNT | VARIABLES COUNT | ALERTS COUNT |
|---------|------------|-------------------------|-------------|-------------|-----------------|--------------|
|         | 1695389576 | 2023-09-22 15:32:56.000 | 451         | 405         | 0               | 3            |
|         | 1695385975 | 2023-09-22 14:32:55.000 | 455         | 406         | 0               | 3            |
|         | 1695381654 | 2023-09-22 13:20:54.000 | 407         | 351         | 0               | 3            |
|         | 1695373551 | 2023-09-22 11:05:51.000 | 408         | 351         | 0               | 3            |
|         | 1695369950 | 2023-09-22 10:05:50.000 | 408         | 351         | 0               | 3            |
|         | 1695366350 | 2023-09-22 09:05:50.000 | 408         | 351         | 0               | 3            |
|         | 1695361990 | 2023-09-22 07:53:10.000 | 414         | 353         | 0               | 3            |
|         | 1695307422 | 2023-09-21 16:43:42.000 | 414         | 361         | 0               | 3            |
|         | 1695303821 | 2023-09-21 15:43:41.000 | 414         | 361         | 0               | 3            |
|         | 1695300221 | 2023-09-21 14:43:41.000 | 413         | 361         | 0               | 3            |
|         | 1695296620 | 2023-09-21 13:43:40.000 | 413         | 361         | 0               | 3            |
|         | 1695293019 | 2023-09-21 12:43:39.000 | 413         | 361         | 0               | 3            |
|         | 1695289418 | 2023-09-21 11:43:38.000 | 413         | 361         | 0               | 3            |
|         | 1695285817 | 2023-09-21 10:43:37.000 | 413         | 361         | 0               | 3            |
|         | 1695282216 | 2023-09-21 09:43:36.000 | 413         | 361         | 0               | 3            |
|         | 1695278616 | 2023-09-21 08:43:36.000 | 420         | 362         | 0               | 3            |
|         | 1695275015 | 2023-09-21 07:43:35.000 | 430         | 382         | 0               | 3            |

Figure 71. Time machine page

## Reload

If you initiate a diff and then navigate to another area of the software, when you return to this page you might not see the progress of the diff. The **Reload** button lets you either:

- Reload the progress bar (if the diff is still in progress)
- View the results (if the process has finished)

## Exclude frequently changing fields

You can select the **Exclude frequently changing fields**  toggle to on to exclude the fields that change frequently. This excludes the diff all fields that are affected from normal traffic handling. Examples of frequently changing fields are the number of bytes received / sent, and the last activity time.

## Diff

The **Diff** button starts the diff process. The system evaluates the diff baseline - target files and estimates how **CPU** / memory intensive the diff operation is going to be. If there is not enough free memory at the moment, the diff will be aborted with the appropriate message. If the diff is estimated to take more than a few minutes, a warning will show and a confirmation dialog will show.

## Live

The **LIVE** button lets you choose the current view as part of the diff.

## Step forward

The step forward  icon lets you go back to the present time view after you have viewed a snapshot.

### Live / refresh

The **Live**   icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Load snapshot

The load snapshot  icon lets you select a historical snapshot.

### Select for diff

The select for diff  icon to choose the related snapshot as part of the diff.

## Time machine diffs

You can use time machine to view diffs between historical snapshots, or an historical snapshot and the current live view.

### Snapshots

When you view a snapshot, the [graphical user interface \(GUI\)](#) will change to gray.



The graph view and the use of color let you quickly see the nodes, or links, that have been added, removed, or changed:

- Added items are green
- Removed items are red
- Changed items are blue

### Diff views

| Changes for 172.20.10.2 |                                  |                               |                               |
|-------------------------|----------------------------------|-------------------------------|-------------------------------|
| Field                   | Before                           | After                         |                               |
| created_at              | 2023-07-25<br>12:32:20.138       | 12:07:05.787                  | +5441685649                   |
| device_id               | f2:c9:98:64:c3:f3c:e9:f7:5e:31:f | f23c:e9e9:98f7:645e:c331:5bfc |                               |
| label                   | iPhone-106.local                 | PTNB08.local                  | iPhone-106PTNB08.local        |
| mac_address             | f2:c9:98:64:c3:f3c:e9:f7:5e:31:f | f23c:e9e9:98f7:645e:c331:5bfc |                               |
| mac_vendor              | Private Address                  | Intel Corporate               | PrivateIntel AddressCorporate |
| product_name            | iPhone                           |                               | iPhone                        |
| type                    | mobile_phone -                   |                               | mobile_phone-                 |
| vendor                  | Apple                            | Intel Corporate               | AppleIntel Corporate          |

Figure 72. Table view

In the graph view, you can select a link or node to see more information in the pane on the right side.




Figure 73. Graph view

## Load a snapshot

*To create a diff, you must first load a snapshot.*

### Procedure

1. In the top navigation bar, select  icon > **Time machine**.

**Result:** The **Time machine** page opens.

2. To the left of the applicable snapshot, select the load snapshot  icon.

**Result:** The user interface turns gray to highlight that you are viewing a static snapshot.



3. To return to the present time view, select the  icon.

## Request a diff

*The time machine lets you create a diff between two historical snapshots, or a snapshot and the current view.*

### Procedure

1. In the top navigation bar, select  icon > **Time machine**.  
**Result:** The **Time machine** page opens.
2. To select the baseline of the diff, to the left of the applicable snapshot, select the select for diff  icon.  
**Result:** At the top of the table, the details of the snapshot are loaded next to the **Diff** icon.
3. Choose a target for the diff:  
**Choose from:**
  - To select another snapshot from the past, to the left of the applicable snapshot, select the load snapshot  icon
  - To select the current, live environment, at the top of the table, select the **LIVE** icon
4. **Optional:** Select the **Exclude frequently changing fields** toggle to on.
5. Now that the baseline and the target have been set, select the **Diff** icon.  
**Result:** The system evaluates the diff baseline / target files and estimates how **CPU** / memory intensive the diff operation is going to be. If there is not enough free memory at the moment, the diff will be aborted with the appropriate message. If the diff is estimated to take more than a few minutes, a warning will show and a confirmation dialog will show.
6. As soon as the diff operation starts, a dialog shows the progress. To stop the diff operation, select **Abort**.

### Results

After the diff has been computed, the diff results show.



## Reload the diff operation progress

*Diff operations can take a long time to conclude. While an operation is in progress, you can continue to use the software as normal.*

### Procedure

1. In the top navigation bar, select  icon > **Time machine**.

**Result:** The **Time machine** page opens.

2. At the top of the table, select **Reload**.

**Result:** If the diff operation is still in progress, the progress dialog shows. If the operation has finished, the diff results show.

## View a diff from an alert

*This automatic feature will use the previous and subsequent snapshots according to the time of the alert.*

### Procedure

1. In the top navigation bar, select **Alerts**.

**Result:** The **Alerts** page opens.

2. Choose a method to open the actions menu.

**Choose from:**

- In the table, select the hyperlink to open the details page. Select **Actions**
- In the table, select the  icon

3. Select **Time machine diff**.

**Result:** The time diff shows.

4. To see more details on the right side of the graph, select the applicable node or link.

## Chapter 14. Vulnerabilities



*The Nozomi Networks software continuously discovers vulnerabilities in monitored assets.*

The Nozomi Networks software continuously discover vulnerabilities. To do this, it matches the [Common Platform Enumeration \(CPE\)](#) of a device with the [National Vulnerability Database](#), and other data sources.

The Vulnerabilities page has these tabs:

- [Assets \(on page 258\)](#)
- [List \(on page 259\)](#)
- [Stats \(on page 260\)](#)

# Assets

The **Assets** page shows a list of assets with known vulnerabilities, along with a summary of the severity of the vulnerability.




Figure 74. Assets page

## Only most likely


This toggle lets you filter the view to show only the assets the match the criteria that you have set for likelihood threshold.

## Likelihood threshold settings

**Likelihood threshold** is a value between 0.1 and 1.0 where 1.0 represents the maximum likelihood of the *Common Vulnerabilities and Exposures (CVE)* to be present. Likelihood is the confidence of the software's correct assignment of a *CPE* to the hardware of the monitored asset. The higher the likelihood, the higher the software's confidence that the vulnerabilities assigned to an asset are in fact are relevant to that asset. **Likelihood threshold** is the minimum likelihood a vulnerability needs in order for it to be shown in this page when the **Only most likely** toggle is set to on. As a guideline, we suggest that you use:

- 0.8 for a high level of confidence
- 0.5 for a medium level of confidence
- 0.3 for a low level of confidence

## Live / refresh

The **Live**  icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

## List

The **List** page shows a comprehensive list of vulnerabilities in the environment. This lets you perform global, in-depth analysis.

| ACTIONS | CVE                           | NODE              | SCORE | CWE | CWE NAME                                                                             | CVE CREATION DATE       | DISCOVERY DATE                  |
|---------|-------------------------------|-------------------|-------|-----|--------------------------------------------------------------------------------------|-------------------------|---------------------------------|
|         | <a href="#">CVE-2003-0904</a> | 172.16.37.24      | 6     | 200 | Exposure of Sensitive Information to an Unauthorized Actor                           | 2004-01-20 06:00:00.000 | 2023-09-11 12:20:20.513 cpe/lan |
|         | <a href="#">CVE-2004-0119</a> | 172.16.37.24      | 7.5   | 476 | NULL Pointer Dereference                                                             | 2004-06-01 06:00:00.000 | 2023-09-11 12:20:20.799 cpe/lan |
|         | <a href="#">CVE-2004-0840</a> | 172.16.37.24      | 10    | 20  | Improper Input Validation                                                            | 2004-11-03 06:00:00.000 | 2023-09-11 12:20:20.805 cpe/lan |
|         | <a href="#">CVE-2005-1987</a> | 172.16.37.24      | 7.5   | 120 | Buffer Copy without Checking Size of Input ('Classic Buffer Overflow')               | 2005-10-13 12:02:00.000 | 2023-09-11 12:20:20.802 cpe/lan |
|         | <a href="#">CVE-2005-3921</a> | 6c:41:6a:60:99:23 | 2.6   | 79  | Improper Neutralization of Input During Web Page Generation ('Cross-site Scripting') | 2005-11-30 12:03:00.000 | 2023-09-11 12:17:58.491 cpe/lan |
|         | <a href="#">CVE-2006-4950</a> | 6c:41:6a:60:99:23 | 10    | 20  | Improper Input Validation                                                            | 2006-09-23 12:07:00.000 | 2023-09-11 12:17:58.491 cpe/lan |
|         | <a href="#">CVE-2007-0066</a> | 172.16.37.24      | 7.1   | 20  | Improper Input Validation                                                            | 2008-01-08 21:46:00.000 | 2023-09-11 12:20:20.510 cpe/lan |
|         | <a href="#">CVE-2007-0199</a> | 6c:41:6a:60:99:23 | 5     | 20  | Improper Input Validation                                                            | 2007-01-11 12:28:00.000 | 2023-09-11 12:17:58.496 cpe/lan |
|         | <a href="#">CVE-2007-2587</a> | 6c:41:6a:60:99:23 | 6.3   | 20  | Improper Input Validation                                                            | 2007-05-10 02:19:00.000 | 2023-09-11 12:17:58.497 cpe/lan |
|         | <a href="#">CVE-2007-3034</a> | 172.16.37.24      | 9.3   | 189 | Numeric Errors                                                                       | 2007-08-14 23:17:00.000 | 2023-09-11 12:20:20.512 cpe/lan |
|         | <a href="#">CVE-2007-3898</a> | 172.16.37.24      | 6.4   | 16  | Configuration                                                                        | 2007-11-14 02:46:00.000 | 2023-09-11 12:20:20.796 cpe/lan |
|         | <a href="#">CVE-2007-5133</a> | 172.16.37.24      | 7.1   | 189 | Numeric Errors                                                                       | 2007-09-27 21:37:00.000 | 2023-09-11 12:20:20.511 cpe/lan |
|         | <a href="#">CVE-2008-1436</a> | 172.16.37.24      | 9     | 264 | Permissions, Privileges, and Access Controls                                         | 2008-04-21 19:05:00.000 | 2023-09-11 12:20:20.486 cpe/lan |
|         | <a href="#">CVE-2008-1441</a> | 172.16.37.24      | 5.4   | 20  | Improper Input Validation                                                            | 2008-06-12 04:32:00.000 | 2023-09-11 12:20:20.803 cpe/lan |
|         | <a href="#">CVE-2008-1454</a> | 172.16.37.24      | 9.4   | 20  | Improper Input Validation                                                            | 2008-07-09 01:41:00.000 | 2023-09-11 12:20:20.551 cpe/lan |
|         | <a href="#">CVE-2008-2249</a> | 172.16.37.24      | 9.3   | 189 | Numeric Errors                                                                       | 2008-12-10 15:00:00.000 | 2023-09-11 12:20:20.552 cpe/lan |
|         | <a href="#">CVE-2008-2250</a> | 172.16.37.24      | 7.2   | 264 | Permissions, Privileges, and Access Controls                                         | 2008-10-15 02:12:00.000 | 2023-09-11 12:20:20.552 cpe/lan |
|         | <a href="#">CVE-2008-2251</a> | 172.16.37.24      | 7.2   | 399 | Resource Management Errors                                                           | 2008-10-15 02:12:00.000 | 2023-09-11 12:20:20.553 cpe/lan |

Figure 75. List page

### Export

The **Export** icon lets you export the current list in either [CSV](#) or Microsoft Excel format.

### Only resolved

This lets you show only **Unresolved** vulnerabilities. Vulnerability status options are:

- Unresolved
- Mitigated
- Accepted

**Mitigated** and **Accepted** lead to a resolution status that equals true.

### Live / refresh

The **Live** icon lets you change live view on, or off. When live mode is on, the page will refresh approximately every five seconds.

### Column selection

The columns selection icon lets you choose which columns to show or hide.

## Stats

The **Stats** page shows high level information in a graphical format that shows the top common platform enumerations (CPEs), common vulnerabilities and exposures (CVEs), and common weakness enumerations (CWEs).




Figure 76. Stats page

### Top CPEs

This section shows the:

- Title of vulnerability
- Percentage of the total vulnerabilities
- Actual count of that vulnerability

### Top CWEs

This section shows the:

- Title of vulnerability
- Percentage of the total vulnerabilities
- Actual count of that vulnerability

### Top CVEs

This section shows the:

- Title of vulnerability
- Date of vulnerability type
- Percentage of the total vulnerabilities
- Actual count of that vulnerability



## Details page

*The details page shows you all the details for the related vulnerability.*

| Details for CVE-2001-0131 |                                                                                                                                                                                                                                                                                             |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Node:                     | 204.93.163.124                                                                                                                                                                                                                                                                              |
| Score:                    | <div><div></div></div> 3.3                                                                                                                                                                                                                                                                  |
| EPSS score:               |                                                                                                                                                                                                                                                                                             |
| CVE source:               | NVD                                                                                                                                                                                                                                                                                         |
| CWE name:                 | Improper Link Resolution Before File Access (Link Following)                                                                                                                                                                                                                                |
| CWE:                      | 59                                                                                                                                                                                                                                                                                          |
| Matching CPEs:            | cpe:/a:apache:http_server:2.*                                                                                                                                                                                                                                                               |
| CVE creation date:        | 2001-03-12 06:00:00.000                                                                                                                                                                                                                                                                     |
| CVE update date:          | 2020-10-09 19:52:00.000                                                                                                                                                                                                                                                                     |
| Discovery date:           | 2023-09-25 08:25:49.018                                                                                                                                                                                                                                                                     |
| Summary:                  | htpasswd and htdigest in Apache 2.0a9, 1.3.14, and others allows local users to overwrite arbitrary files via a symlink attack.                                                                                                                                                             |
| References:               | Source "DEBIAN", Type "VENDOR_ADVISORY"<br><a href="#">DSA-021</a><br>Source "BUGTRAQ", Type "VENDOR_ADVISORY"<br><a href="#">20010110:immunix.Org Security update for lots of terna file problems</a><br>Source "XF", Type "VENDOR_ADVISORY"<br><a href="#">linux.apache-symlink(5926)</a> |

**Figure 77. Details page**



## Chapter 15. Administration



## Administration page

*The administration page lets a user with administrator privileges configure settings and do other tasks.*

For more details, see the **Guardian - Administrator Guide**.



## Chapter 16. Personal settings






*The personal settings page lets you do actions that are specific to your profile.*

## General

You can select the  icon to access the personal settings menu.



**Figure 78. Personal settings menu**

The personal settings page has these two sections:


- [Other actions](#) (on page 270)
- [Zone filters](#) (on page 281)

## Logout

A button in the personal settings menu lets you log out of the software.

## Other actions

The **Other actions** page provides access to essential user settings, including options to clear personal settings, manage trace requests, and customize the UI theme with Auto, Light, or Dark modes.



**Figure 79. Other actions page**

The other actions page lets you access these options:

- [Change your password \(on page 271\)](#)
- [Edit an OpenAPI key \(on page 272\)](#)
- [Clear your personal settings \(on page 275\)](#)
- [Request a continuous trace \(on page 276\)](#)
- [Request a custom trace \(on page 277\)](#)
- [Show requested traces \(on page 279\)](#)

The **Appearance** section lets you customize the visual appearance of the [UI](#). You can choose one of these themes:

- Auto: Automatically adjusts the theme based on system settings
- Light: Uses a bright interface for better visibility in well-lit environments
- Dark: Uses a dark interface for reduced eye strain in low-light environments

## Change your password

*The profile settings menu lets you change your password.*

### Procedure

1. In the top navigation bar, select 

**Result:** A menu shows.

2. Select **Other actions**.
3. Select **Change password**.

**Result:** A dialog shows.

4. In the **Password** field, enter a new password.

**Update password** to guarantee your security please change your password.

**Password**

Password must be minimum of 12 characters and must contain at least 1 digit, 1 lowercase char, 1 uppercase char

**Password confirmation**

5. In the **Password confirmation** field, enter the password again.
6. Select **Update and proceed**.

### Results

Your password has been changed.

## Edit an OpenAPI key

The profile settings menu lets you edit your OpenAPI keys.

### Procedure

1. In the top navigation bar, select 

**Result:** A menu shows.

2. Select **Other actions**.
3. Select **Edit OpenAPI keys**.

**Result:** A dialog shows.

4. Edit the OpenAPI keys as necessary.

Edit OpenAPI keys

Page 1 of 1,0 entries

Live ☒   Generate

| ACTIONS | NAME                 | DESCRIPTION          | ALLOWED IPS          | LAST SIGN IN IP      | LAST SIGN IN TIME | REVOKE TIME |
|---------|----------------------|----------------------|----------------------|----------------------|-------------------|-------------|
|         | <input type="text"/> | <input type="text"/> | <input type="text"/> | <input type="text"/> |                   |             |

Close

5. Select **Close**.

### Results

Your OpenAPI keys have been edited.

## Generate an OpenAPI key

The profile settings menu lets you generate an OpenAPI key.

### Procedure

1. In the top navigation bar, select 


**Result:** A menu shows.

2. Select **Other actions**.

3. Select **Edit OpenAPI keys**.


**Result:** A dialog shows.

4. In the top right, select **+ Generate**.



**Result:** A dialog shows.

5. In the **Description** field, enter a description for the OpenAPI key.



6. In the **Allowed IPs** field, enter the details of the allowed *IP* addresses.

7. Select **Generate**.

## Results

Your OpenAPI key has been generated.

## Clear your personal settings

*The profile settings menu lets you clear your personal settings that are stored in the local browser local.*

### Procedure

1. In the top navigation bar, select 

**Result:** A menu shows.

2. Select **Other actions**.
3. Select **Clear personal settings**.

**Result:** A dialog shows.

4. Select **OK**.

|                      |
|----------------------|
| Are you sure?        |
| <div>Cancel OK</div> |

### Results

Your personal settings have been cleared from the local browser.

## Request a continuous trace

The profile settings menu lets you request a trace that has only the disk size constraint.

### About this task


The maximum count of packets, and the run time, constrain regular traces. For example, being constrained to capture at most 1000 packets in no more than one minute. A continuous trace does not have such limits. It collects packets without constraints, as long as the disk has free space to store the captured traffic. The packets are then saved as individual files that are 100 *MB* in size.

### Procedure

1. In the top navigation bar, select 

**Result:** A menu shows.
2. Select **Other actions**.
3. Select **Continuous trace**.
 

**Result:** A dialog shows.
4. In the **Packet filter** field, enter a *BPF* filter.



Continuous trace

Request new continuous trace

Packet filter [BPF syntax help](#) [BPF examples](#)

▶ Start

Requested traces

Page 1 of 1, 0 entries Live

| TIME | ID | USER | PACKET FILTER | IN PROGRESS |
|------|----|------|---------------|-------------|
|------|----|------|---------------|-------------|

Cancel

5. Select **Start**.

### Results

The trace has been requested.



## Request a custom trace

The profile settings menu lets you request a trace specifying a custom packet filter.

### Procedure


1. In the top navigation bar, select 

**Result:** A menu shows.

2. Select **Other actions**.
3. Select **Request custom trace**.

**Result:** A dialog shows.

4. To set the maximum packet size, in the **Trace max size (packets)** field, enter a value.



**Note:**

The default size is 5000 packets.

5. To set the maximum duration of the trace, in the **Trace max duration (seconds)** field, enter a value.



**Note:**

The default value is 60 seconds.

6.

**Note:**

The **Packet filter** field is automatically populated with a [BPF](#) that captures the packets to/from the selected node, but you can customize this.

If necessary, customize this field.

**Note:**

You can select **BPF syntax help** to show more information on [BPF](#) syntax.

**Note:**

You can select **BPF examples** to see some examples.

7. Select **Send trace request**.

## Results

The trace has been requested.

## Show requested traces

*The profile settings menu lets you show all the traces that you have requested.*

### Procedure

1. In the top navigation bar, select   
**Result:** A menu shows.
2. Select **Other actions**.
3. Select **Show requested traces**.

### Results

All your requested traces show.

## Download a requested trace

Once you have requested a trace, and it is ready, you can download it.

### Procedure

- 1. In the top navigation bar, select 

**Result:** A menu shows.

- 2. Select **Other actions**.
- 3. Select **Show requested traces**.

**Result:** All your requested traces show.

- 4. For the applicable trace, select **Download trace**.

| Requested traces  |                                                                                                                           |       |               |
|------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|-------|---------------|
| TIME                                                                                                 | ID                                                                                                                        | USER  | PACKET FILTER |
| 10:59:40.013                                                                                         |  <a href="#">Download trace</a> bb7e1fee | admin | not ip        |

### Results

The trace has been downloaded.

## Zone filters

*The personal settings menu lets you filter zones.*

Zone filters

Search for zone...

Only the zones listed here will be visible (BETA)

AllNone

☐ Broadcast

☐ Loopback

☐ Internet

☐ Test Zone 1

☐ Layer2

☐ Multicast

☐ Undefined

☐ kmkH2-test-guardian

☐ Link-local

☐ Unspecified

☐ TEstingtesting

☐ testing scope

Apply

**Figure 80.** Zone filters page



# Glossary





### **Amazon Machine Image**

An AMI is a type of virtual appliance that is used to create a virtual machine for the Amazon Elastic Compute Cloud (EC2), and is the basic unit of deployment for services that use EC2 for delivery.

### **Amazon Web Services**

AWS is a subsidiary of the Amazon company that provides on-demand cloud computing platforms governments, businesses, and individuals on a pay-as-you-go basis.

### **Application Programming Interface**

An API is a software interface that lets two or more computer programs communicate with each other.

### **Assertion Consumer Service**

An ACS is a version of the SAML standard that is used to exchange authentication and authorization identities between security domains.

### **Asset Intelligence™**

Asset Intelligence is a continuously expanding database of modeling asset behavior used by N2OS to enrich asset information, and improve overall visibility, asset management, and security, independent of monitored network data.

### **Berkeley Packet Filter**

The BPF is a technology that is used in some computer operating systems for programs that need to analyze network traffic. A BPF provides a raw interface to data link layers, permitting raw link-layer packets to be sent and received.

### **Central Management Console**

The Central Management Console (CMC) is a Nozomi Networks product that has been designed to support complex deployments that cannot be addressed with a single sensor. A central design principle behind the CMC is the unified experience, that lets you access information in a similar way as on the sensor.

### **Central Processing Unit**

The main, or central, processor that executes instructions in a computer program.

### **Certificate Authority**

A certificate, or certification authority (CA) is an organization that stores, signs, and issues digital certificates. In cryptography, a digital certificate certifies the ownership of a public key by the named subject of the certificate.

### **Classless Inter-Domain Routing**

CIDR is a method for IP routing and for allocating IP addresses.

### **Command-line interface**

A command-line processor uses a command-line interface (CLI) as text input commands. It lets you invoke executables and provide information for the actions that you want them to do. It also lets you set parameters for the environment.

### **Comma-separated Value**

A CSV file is a text file that uses a comma to separate values.

### **Common Event Format**

CEF is a text-based log file format that is used for event logging and information sharing between different security devices and software applications.

### **Common Platform Enumeration**

CPE is a structured naming scheme for information technology (IT) systems, software, and packages. CPE is based on the generic syntax for Uniform Resource Identifiers (URI) and includes a formal name format, a method for checking names against a system, and a description format for binding text and tests to a name.

### **Common Vulnerabilities and Exposures**

CVEs give a reference method information-security vulnerabilities and exposures that are known to the public. The United States' National Cybersecurity FFRDC maintains the system.

### **Common Weakness Enumeration**

CWE is a category system for software and hardware weaknesses and vulnerabilities. It is a community project with the aim to understand flaws in software and hardware and create automated tools that can be used to identify, fix, and prevent those flaws.

### **Configuration file**

A CFG file is a configuration, or config, file. They are files that are used to configure the parameters and initial settings for a computer program.

### **curl**

curl is a command-line tool and library used to transfer data to or from a server. It supports many protocols, including HTTP, HTTPS, FTP, and more. In API contexts, curl is commonly used to test and interact with endpoints by sending requests and receiving responses.

## **cURL**

### **Domain Name Server**

The DNS is a distributed naming system for computers, services, and other resources on the Internet, or other types of Internet Protocol (IP) networks.

## **ESXi**

VMware ESXi (formerly ESX) is an enterprise-class, type-1 hypervisor developed by VMware for deploying and serving virtual computers. As a type-1 hypervisor, ESXi is not a software application that is installed on an operating system (OS). Instead, it includes and integrates vital OS components, such as a kernel.

## **Extensible Markup Language**

XML is a markup language and file format for the storage and transmission of data. It defines a set of rules for encoding documents in a format that is both human-readable and machine-readable.

## **Federal Information Processing Standards**

FIPS are publicly announced standards developed by the National Institute of Standards and Technology for use in computer systems by non-military American government agencies and government contractors.

## **File Allocation Table**

FAT is a file system architecture used in computers for managing disk space. It maintains a table to track the allocation of files on a disk, supporting efficient data storage, access, and management.

## **File Transfer Protocol**

FTP is a standard communication protocol that is used for the transfer of computer files from a server to a client on a computer network. FTP is built on a client-server model architecture that uses separate control and data connections between the client and the server.

## **Fully qualified domain name**

An FQDN is a complete and specific domain name that specifies the exact location in the hierarchy of the Domain Name System (DNS). It includes all higher-level domains, typically consisting of a host name and domain name, and ends in a top-level domain.

## **Gigabit per second**

Gigabit per second (Gb/s) is a unit of data transfer rate equal to: 1,000 Megabits per second.

## **Gigabyte**

The gigabyte is a multiple of the unit byte for digital information. One gigabyte is one billion bytes.

## **Graphical User Interface**

A GUI is an interface that lets humans interact with electronic devices through graphical icons.

## **Graphics Interchange Format**

GIF is a bitmap image format that is widely used on the internet.

## **High Availability**

High Availability is a mode that permits the CMC to replicate its own data on another CMC.

## **Host-based intrusion-detection system**

HIDS is an internal Nozomi Networks solution that uses sensors to detect changes to the basic firmware image, and record the change.

## **Hypertext Markup Language**

Hypertext Markup Language (HTML) is the standard markup language used to structure and display content on the web. It defines the structure of web pages using elements represented by tags.

## **Hypertext Transfer Protocol**

HTTP is an application layer protocol in the Internet protocol suite model for distributed, collaborative, hypermedia information systems. HTTP is the foundation of data communication for the World Wide Web, where hypertext documents include hyperlinks to other resources that the user can easily access, for example by a mouse click or by tapping the screen in a web browser.

## **Hypertext Transfer Protocol Secure**

HTTPS is an extension of the Hypertext Transfer Protocol (HTTP). It is used for secure communication over a computer network, and is widely used on the Internet. In HTTPS, the communication protocol is encrypted using Transport Layer Security (TLS) or, formerly, Secure Sockets Layer (SSL). The protocol is therefore also referred to as HTTP over TLS, or HTTP over SSL.

## **Identifier**

A label that identifies the related item.

**Identity Provider**

An IdP is a system entity that creates, maintains, and manages identity information. It also provides authentication services to applications within a federation, or a distributed network.

**Industrial Control Systems**

An ICS is an electronic control system and related instrumentation that is used to control industrial processes.

**Industrial Internet of Things**

The IIoT is a name for interconnected devices, sensors, instruments, which are networked together with industrial applications. This connectivity allows for analysis and data collection, which can facilitate improvements in efficiency and productivity.

**Information Object Addresses**

An Information Object Address (IOA) is a unique identifier used in IEC 60870-5-101 and IEC 60870-5-104 protocols to specify individual data points, such as sensors or actuators, within a telecontrol system. The IOA format can vary and is configurable, typically appearing as either a 1-byte–2-byte or a 1-byte–1-byte–1-byte structure, depending on the system requirements.

**Internet Control Message Protocol**

ICMP is a supporting protocol in the internet protocol suite. Network devices use it to send error messages and operational information to indicate success or failure when communicating with another IP address. ICMP differs from transport protocols such as TCP and UDP in that it is not typically used to exchange data between systems.

**Internet of Things**

The IoT describes devices that connect and exchange information through the internet or other communication devices.

**Internet Protocol**

An Internet Protocol address, or IP address, identifies a node in a computer network that uses the Internet Protocol to communicate. The IP label is numerical.

**Intrusion Detection System**

An intrusion detection system (IDS), which can also be known as an intrusion prevention system (IPS) is a software application, or a device, that monitors a computer network, or system, for malicious activity or policy violations. Such intrusion activities, or violations, are typically reported either to a system administrator, or collected centrally by a security information and event management (SIEM) system.

**IPv6**

Internet Protocol version 6 is the most recent version of the Internet Protocol, designed to replace IPv4. It uses 128-bit numerical addresses to identify devices, allowing for a vastly larger address space.

**JavaScript Object Notation**

JSON is an open standard file format for data interchange. It uses human-readable text to store and transmit data objects, which consist of attribute–value pairs and arrays.

**Joint Photographic Experts Group**

JPEG, or JPG, is a method of lossy compression that is used for digital images. The degree of compression can be adjusted, allowing a selectable tradeoff between storage size and image quality.

**Lightweight Directory Access Protocol**

LDAP is an open, vendor-neutral, industry standard application protocol that lets you access and maintain distributed directory information services over an internet protocol (IP) network.

**Lightweight Directory Access Protocol Secure**

LDAP over SSL or Secure LDAP is the secure version of LDAP.

**Link Layer Discovery Protocol**

LLDP is a vendor-neutral link layer protocol used by network devices for advertising identity, capabilities, and neighbors on a local area network.

**Management Information Base**

An MIB is a collection of definitions that specify the properties of the managed resources within a network device (like routers or switches) and how they can be accessed using SNMP (Simple Network Management Protocol).

**Media Access Control**

A MAC address is a unique identifier for a network interface controller (NIC). It is used as a network address in network segment communications. A common use is in most IEEE 802 networking technologies, such as Bluetooth, Ethernet, and Wi-Fi. MAC addresses are most commonly assigned by device manufacturers and are also referred to as a hardware address, or physical address. A MAC address normally includes a manufacturer's organizationally unique identifier (OUI). It can be stored in hardware, such as the card's read-only memory, or by a firmware mechanism.

**Megabyte**

The megabyte is a multiple of the unit byte for digital information. One megabyte is one million bytes.

**Message Queuing Telemetry Transport**

Message Queuing Telemetry Transport is a lightweight, publish-subscribe network protocol designed for constrained devices and low-bandwidth, high-latency, or unreliable networks. It is commonly used in Internet of Things (IoT) applications.

**National Vulnerability Database**

The National Vulnerability Database (NVD) is the U.S. government repository of standards-based vulnerability management data represented using the Security Content Automation Protocol (SCAP). This data enables automation of vulnerability management, security measurement, and compliance. NVD includes databases of security checklists, security related software flaws, misconfigurations, product names, and impact metrics.

**Network Address Translation**

NAT is a method of mapping an internet protocol (IP) address space into another one. This is done by modifying network address information in the IP header of packets while in transit across a traffic routing device.

**Network-Attached Storage**

NAS is a dedicated file storage system that provides local-area network (LAN) users with centralized, shared access to data through standard protocols such as NFS or SMB.

**Network Interface Controller**

A network interface controller (NIC), sometimes known as a network interface card, is a computer hardware component that lets a computer connect to a computer network.

**Network Time Protocol**

The NTP is a networking protocol to synchronize clocks between computer systems over variable-latency, packet-switched data networks.

**Nozomi Networks Operating System**

N2OS is the operating system that the core suite of Nozomi Networks products runs on.

**Nozomi Networks Query Language (N2QL)**

N2QL is the language used in queries in Nozomi Networks software.

**Open Virtual Appliance**

An OVA file is an open virtualization format (OVF) directory that is saved as an archive using the .tar archiving format. It contains files for distribution of software that runs on a virtual machine. An OVA package contains a .ovf descriptor file, certificate files, an optional .mf file along with other related files.

**Operating System**

An operating system is computer system software that is used to manage computer hardware, software resources, and provide common services for computer programs.

**Operational Technology**

OT is the software and hardware that controls and/or monitors industrial assets, devices and processes.

**Packet Capture**

A pcap is an application programming interface (API) that captures live network packet data from the OSI model ( layers 2-7).

**Packet Capture Next Generation**

A pcapNg is the latest version of a pcap file, an application programming interface (API) that captures live network packet data from the OSI model ( layers 2-7).

**Portable Document Format**

PDF is a Adobe file format that is used to present documents. It is independent of operating systems (OS), application software, hardware.

***Portable Network Graphics***

PNG is a raster graphics file format that supports lossless data compression. PNG was developed as an improved, non-patented replacement for graphics interchange format (GIF).

***Privacy-Enhanced Mail***

PEM is a standard file format that is used to store and send cryptographic keys, certificates, and other data. It is based on a set of 1993 IETF standards.

***Programmable Logic Controller***

A PLC is a ruggedized, industrial computer used in industrial and manufacturing processes.

***Protected Extensible Authentication Protocol***

PEAP is a protocol that encloses the Extensible Authentication Protocol (EAP) within an encrypted and authenticated Transport Layer Security (TLS) tunnel.

***Random-access Memory***

Computer memory that can be read and changed in any order. It is typically used to store machine code or working data.

***Representational State Transfer***

Representational State Transfer (REST) is an architectural style for designing networked applications. It uses stateless, client-server communication via standard HTTP methods (GET, POST, PUT, DELETE) to access and manipulate web resources represented in formats like JSON or XML.

***Seamless Message Protocol***

Seamless Message Protocol is a communication protocol used primarily in industrial automation for device-level communication. It enables data exchange between controllers and devices over Ethernet networks.

***Secure Copy Protocol***

SCP is a protocol for the secure transfer of computer files between a local host and a remote host, or between two remote hosts. It is based on the secure shell (SSH) protocol.

***Secure Shell***

A cryptographic network protocol that let you operate network services securely over an unsecured network. It is commonly used for command-line execution and remote login applications.

***Secure Sockets Layer***

A secure sockets layer ensures secure communication between a client computer and a server.

***Security Assertion Markup Language***

SAML is an open standard, XML-based markup language for security assertions. It allows for the exchange of authentication and authorization data different parties such as a service provider and an identity provider.

***Security Information and Event Management***

SIEM is a field within the computer security industry, where software products and services combine security event management (SEM) and security information management (SIM). SIEMs provide real-time analysis of security alerts.

***Server Message Block***

Is a communication protocol which provides shared access to files and printers across nodes on a network of systems. It also provides an authenticated interprocess communication (IPC) mechanism.

***Simple File Transfer Protocol***

SFTP was proposed as an unsecured file transfer protocol with a level of complexity intermediate between TFTP and FTP. It was never widely accepted on the internet.

***Simple Mail Transfer Protocol***

SMTP is an internet standard communication protocol that is used for the transmission of email. Mail servers and other message transfer agents use SMTP to send and receive mail messages.

***Simple Network Management Protocol***

SNMP is an Internet Standard protocol for the collection and organization of information about managed devices on IP networks. It also lets you modify that information to change device behavior. Typical devices that support SNMP are: printers, workstations, cable modems, switches, routers, and servers.

***Simple Text Oriented Messaging Protocol***

STOMP is a simple text-based protocol, for working with message-oriented middleware (MOM). It provides an interoperable wire format that allows STOMP clients to talk with any message broker supporting the protocol.



**Spanning Tree Protocol**

Spanning Tree Protocol is a network protocol that prevents loops in Ethernet networks by creating a spanning tree topology. It selectively blocks redundant paths and ensures a loop-free logical topology.

**Structured Threat Information Expression**

STIX™ is a language and serialization format for the exchange of cyber threat intelligence (CTI). STIX is free and open source.

**Supervisory control and data acquisition**

SCADA is a control system architecture which has computers, networked data communications and graphical user interfaces for high-level supervision of processes and machines. It also covers sensors and other devices, such as programmable logic controllers (PLC), which interface with process plant or machinery.

**Text-based User Interface**

In computing, a text-based (or terminal) user interfaces (TUI) is a retronym that describes a type of user interface (UI). These were common as an early method of human-computer interaction, before the more modern graphical user interfaces (GUIs) were introduced. Similar to GUIs, they might use the entire screen area and accept mouse and other inputs.

**Threat Intelligence™**

Nozomi Networks **Threat Intelligence™** feature monitors ongoing OT and IoT threat and vulnerability intelligence to improve malware anomaly detection. This includes managing packet rules, YARA rules, STIX indicators, Sigma rules, and vulnerabilities. **Threat Intelligence™** allows new content to be added, edited, and deleted, and existing content to be enabled or disabled.

**Transmission Control Protocol**

One of the main protocols of the Internet protocol suite.

**Transport Layer Security**

TLS is a cryptographic protocol that provides communications security over a computer network. The protocol is widely used in applications such as: HTTPS, voice over IP, instant messaging, and email.

**Uniform Resource Identifier**

A URI is a unique string of characters used to identify a logical or physical resource on the internet or local network.

**Uniform Resource Locator**

An URL is a reference to a resource on the web that gives its location on a computer network and a mechanism to retrieving it.

**Uninterruptible Power Supply**

A UPS is an electric power system that provides continuous power. When the main input power source fails, an automated backup system continues to supply power.

**Universally unique identifier**

A UUID is a 128-bit label that is used for information in computer systems. When a UUID is generated with standard methods, they are, for all practical purposes, unique. Their uniqueness is not dependent on an authority, or a centralized registry. While it is not impossible for the UUID to be duplicated, the possibility is generally considered to be so small, as to be negligible. The term globally unique identifier (GUID) is also used in some, mostly Microsoft, systems.

**Universal Plug and Play**

UPnP is a network protocol that enables devices to automatically discover and communicate with each other using broadcast messages. While it facilitates easy device identification and connectivity, UPnP lacks robust authentication, making it vulnerable to unauthorized access in cybersecurity contexts.

**Universal Serial Bus**

Universal Serial Bus (USB) is a standard that sets specifications for protocols, connectors, and cables for communication and connection between computers and peripheral devices.

**User Datagram Protocol**

UDP is a lightweight, connectionless communication protocol used for fast, time-sensitive data transmission, such as video streaming, online gaming, and VoIP. UDP prioritizes speed and low latency over guaranteed delivery or error correction.

**User Interface**

An interface that lets humans interact with machines.

**Variable**

In the context of control systems, a variable can refer to process values that change over time. These can be temperature, speed, pressure etc.

**Virtual DOM**

A virtual DOM, or vdom, is a lightweight JavaScript representation of the Document Object Model (DOM). It is used in declarative web frameworks such as Elm, React, and Vue.js. It enables the updating of the virtual DOM is comparatively faster than updating the actual DOM.

**Virtual Hard Disk**

VHD is a file format that represents a virtual hard disk drive (HDD). They can contain what is found on a physical HDD, such as disk partitions and a file system, which in turn can contain files and folders. They are normally used as the hard disk of a virtual machine (VM). They are the native file format for Microsoft's hypervisor (virtual machine system), Hyper-V.

**Virtual Local Area Network**

A VLAN is a broadcast domain that is isolated and partitioned in a computer network at the data link layer (OSI layer 2).

**Virtual Machine**

A VM is the emulation or virtualization of a computer system. VMs are based on computer architectures and provide the functionality of a physical computer.

**ZIP**

An archive file format that supports lossless data compression. The format can use a number of different compression algorithms, but DEFLATE is the most common one. A ZIP file can contain one or more compressed files or directories.

