OUICK START GUIDE

Nozomi Networks P550 Guardian Sensor Getting Started

1. Unpacking the System

Inspect the chassis to see whether the appliance has been damaged in any way. If the appliance appears to be damaged, please contact Nozomi Networks support at: support@nozominetworks.com.



Box contents:

- · Nozomi Networks P550 Guardian sensor
- · 1x Grounding cable
- 1x USB Console cable
- · 1x External power adapter
- · 1x Power cord
- 1x R345 ethernet cable
- · 1x Wall mounting kit
- · 1x 2pin terminal block

2. Setup precautions and considerations

Please follow the *General Safety Guidelines* included in the box to prevent potential property damage, personal injury or even death.

Furthermore, observe the following rules:


- Before performing any of the following procedures, ensure that power has been removed from the AC or DC circuit.
- Read the installation instructions before you connect the system to its power source.
- Warning: To prevent the system from overheating, do not operate it in an area that exceeds the maximum recommended temperature:

Operating Environment	Temperature: 0 – 55°C (32 – 131°F)
Storage Environment	Temperature: -10 – 70°C (14 – 158°F) Humidity: 5 – 95 % RH @ 55°C

3. Unbox the appliance

The external PSU, the power cord and the wall mounting kit are included in the pizza box on the side of the package.


· Unbox all the components



4. Wall Mounting (optional)


Wall mounting brackets and their mounting screws are included in the pizza box on the side of the package.

- Unscrew and remove the four rubber pads at the bottom of the Guardian sensor
- Affix each bracket to the appliance, using four of the provided screws




5. Connect management port

Connect the default management port, labeled MGMT (1), to the designated network switch or equipment. One RJ45 cable is included in the box for this purpose.




6. Connect monitoring ports

Connect the other monitoring ports (2) to the proper network mirror sources as needed.




7. Connect the power cables

Connect the external PSU to the sensor using the green DC-IN port (3), then to the power supply.



8. Power ON


Turn on the appliance by pressing the power on/off button (4) on the front of the sensor.



9. Connect Serial Console

Attach to the serial console port using the DB9 Console port (5) on the back of the sensor with a null modem cable.

Connect to the serial console using 9600 bauds and no parity bit set.



10. Documentation

Continue the setup using *User Manual, Chapter 2: Installation*.

You can find the manual at:



https://support.nozominetworks.com/manuals



You will need a Nozomi Networks support account to view the manual.

You can request access credentials at:



https://www.nozominetworks.com/support/

